

PacT Series

ComPacT NS

Catalog 2022

Molded Case Circuit Breakers
and Switch-Disconnectors
from 630b to 3200 A



se.com

Life Is On

Schneider
Electric



Green Premium™



More than 75% of our product sales offer superior transparency on the material content, regulatory information and environmental impact of our products:

- RoHS compliance
- REACH substance information
- Industry leading # of PEP's*
- Circularity instructions



Discover what we mean by green
Check your products!

The Green Premium program stands for our commitment to deliver customer valued sustainable performance. It has been upgraded with recognized environmental claims and extended to cover all offers including Products, Services and Solutions.

CO₂ and P&L impact through... Resource Performance

Green Premium brings improved resource efficiency throughout an asset's lifecycle. This includes efficient use of energy and natural resources, along with the minimization of CO₂ emissions.

Cost of ownership optimization through... Circular Performance

We're helping our customers optimize the total cost of ownership of their assets. To do this, we provide IoT-enabled solutions, as well as upgrade, repair, retrofit, and remanufacture services.

Peace of mind through... Well-being Performance

Green Premium products are RoHS and REACH compliant. We're going beyond regulatory compliance with step-by-step substitution of certain materials and substances from our products.

Improved sales through... Differentiation

Green Premium delivers strong value propositions through third-party labels and services. By collaborating with third-party organizations we can support our customers in meeting their sustainability goals such as green building certifications.

*PEP: Product Environmental Profile (i.e. Environmental Product Declaration)

Life Is On

Schneider
Electric™

Meet the New Face of Connected Breaker Technology

70 Years of Innovative and Reliable Protection

The Schneider Electric™ ComPacT™ range is built on 70 years of expertise and leadership in industrial circuit breakers.

Today Schneider Electric is launching its new generation of ComPacT molded case circuit breakers.

The comprehensive, optimized ComPacT range covers your protection and has been redesigned with a superior customer experience in mind.

The range combines wireless intelligent metering and monitoring, along with advanced protective functions.

This range can be connected to Schneider Electric's open, interoperable, IoT-enabled EcoStruxure™ Power architecture. Through this platform we deliver enhanced value in terms of safety, reliability, efficiency, sustainability, and connectivity.

We leverage technologies in IoT, mobility, sensing, cloud, analytics, and cybersecurity to deliver Innovation at Every Level. This includes connected products, edge control, apps, analytics and services.



1952

Compact NW



1974

Compact C



1994

Compact NS




Discover the New
Generation of ComPacT

se.com/compact-ns



2008

Compact NSX



2008

Compact NS



2017

Compact NSXm



2020

ComPact NS



2018

ComPact NSX
& NSXm with
MicroLogic Vigi



2022

ComPact NS
New Generation



2021

ComPact NSX
& NSXm
New Generation

Design Electrical Solutions

More than 10 years of long-felt techniques and technologies ahead quite simple and convenient.

Win More Projects and Deliver the Best Solution for Your Customers

- Enhance power availability with total control of selectivity and power management with advanced trip unit.
- Optimize panel cost with cascading; the ComPact NS technology covers all your needs from 630 to 3200 A, with a breaking capacity from 50 to 200 kA.
- Equipped with electronic control units, the ComPact NS circuit breakers ensure protection and measurement of your electrical installation.
- Provide efficiency to your customer with small size and multi-ways of installation and highly immune protection system insensitive to disturbances (IEC 60947-2 Annex F).

Standards

ComPact NS circuit breakers and auxiliaries comply with:

- IEC/EN 60947-1: General rules
- IEC/EN 60947-2: Circuit-breakers
- IEC/EN 60947-3: Switch-disconnectors
- IEC/EN 60947-4-1: Contactors and motor-starters
- IEC/EN 60947-5-1: Control circuit devices




The ComPact NS Range Covers all Ratings from 630 to 3200 A

ComPact NS630b to 1600

- ComPact NS from 630 to 1600 A, fixed or withdrawable, front or rear connection, manual operating mechanism or motor mechanism. A 200 kA breaking performance completes the ComPact NS range

ComPact NS1600b to 3200

- ComPact NS from 1600 to 3200 A, fixed, front connection, with manual operating mechanism



The MasterPact and ComPact range circuit breakers, switch-disconnectors and source changeover are the best choice for all standards and specific applications.

> MasterPact
MTZ



LVPED216026EN

> ComPact NSX/NSXm/
ComPact INS/INV



LVPED217032EN

> Source-changeover
Systems



LVPED216028EN

> Complementary
Technical Information



LVPED318033EN

Build and Install Electrical Equipment

Make Your Business More Profitable

Gain space in your switchboard

- The ComPacT NS range is available in 2 sizes only in order to homogenize installation dimensions (volume, depth, pole pitch).
- Easy to select and to order with new Schneider Electric™ online tools.

Gain time, the installation is facilitated


- More space to connect your cables.
- Withdrawable version also available.




Design and Build Machines

Installation


Fixed Device




Withdrawable Device



Manually operated device



Electrically operated device



Withdrawable device

Optimize Your Solution

- **Minimum distances** (safety clearance) between 2 circuit breakers are reduced thanks to the arc chute filters.
- **A solution for all your applications:**
 - Generator protection
 - Motor protection up to 750 kW with coordination between breakers and contactors (coordination type 1 and type 2)
 - Source-changeover.
- **Best combination** of size (small depth), performance with no derating up to 65 °C (vertical connection) and flexible mounting options.
- **Ensure continuity of service:**
 - Total control of selectivity for the whole Schneider Electric circuit breakers range from molded circuit breaker to air circuit breaker
 - High withstand of the devices to various environmental stresses.
- **Bring flexibility to your installation:**
Interchangeable trip units, standardized accessories, adjustable rating and scalable indication and control functions.



Operate the Installation

Operate and Manage the Installation

Continuity of service

- Electrical energy is available, prevent nuisance power outages using total control of selectivity.

Power monitoring

- Power consumption is optimized with on-site, real-time monitoring and control, plus online energy management services
- Maintenance is simplified
- Installation is scalable
- Using ComPacT NS will decrease permanent consumption with lower power dissipations.



Schneider Electric is proud to introduce the new generation of Com**PacT** MCCBs. These breakers talk to you, wherever you are, in all transparency. New design complements new wireless connectivity capabilities with our latest wireless indication auxiliary.

New

New

Com**PacT** Design

Wireless Indication Auxiliary




New signature design

- Schneider Electric green signature style for the entire Com**PacT** range
- Estimated 40% reduction of wiring time for panel builders
- Experience easier installation thanks to a new ergonomic front-plate design
- Gain the confidence that all auxiliaries are on the right spot, and simply double check that you have the right coil rating
- Ergonomic new toggle for easier breaker manual operation

Wireless breaker status

- Plug & play technology for clear connection status (0 or 1, no half-way wired)
- Placed in the same position as the wired version, its LED light will give you direct indication in case of a tripping
- If you are away, your Com**PacT** will send you an immediate notification via EcoStruxure Facility Expert for instance
- Wireless auxiliary accelerates overall wiring time: status communication is done very simply and commissioned wirelessly
- Communication architecture is fully EcoStruxure Power validated, with any application

Ready to meet the new face of Com**PacT**?



In 2022 you will meet the new generation of Com**PacT**™ circuit breakers with semi-transparent faceplate, screwless auxiliaries and remote monitoring features.

Learn about the benefits of the Com**PacT** range here:
se.com/compactns

Contribute to a Better World. Enhance Sustainability with Com**PacT** Range

Achieve Green Building Certification with Green Premium Ecolabel

In compliance with ISO 14025 PEP ecopassport program, we publish a comprehensive Life Cycle Analysis of our product, providing the environmental data you need to achieve Green Building certifications.

For example, Com**PacT** NS contribute to 3 LEED™ points in the Building Product Disclosure and Optimization section:

- Environmental Product Declaration
- Material Ingredients



Com**PacT** range is now enriched with the new Com**PacT** NS, designed according to the EcoDesign Way™ by Schneider. It now features new space saving frame size for reduced resource consumption, and more.



New Generation, Simpler

Commercial References

New Meaningful References

to Make your Life Easier

We know any change in commercial references will be an adjustment, but in the long run we believe this change is needed, and will make your life easier.

ComPacT type	Frame rating	Breaking capacity	Number of poles	MicroLogic trip unit	Mounting	Control	Suffix
NS = C	NS630 = 063	N = N	3P = 3	2.0 = 20	Fixed = F	Manually operated = M	Extended rotary handle = E
	NS800 = 080	H = H	4P = 4	5.0 = 50	Withdrawable = W		Direct rotary handle = D
	NS1000 = 100	L = L		6.0 = 60			No handle = no suffix
	NS1250 = 125	LB = B		2.0A = 2A			
	NS1600 = 160	NA = S		5.0A = 5A			
	NS1600b = 16b			6.0A = 6A			
	NS2000 = 200			7.0A = 7A			
	NS2500 = 250			2.0E = 2E			
	NS3200 = 320			5.0E = 5E			
				6.0E = 6E			
				5.0P = 5P			
				6.0P = 6P			
				7.0P = 7P			
				NA = NA			

For example, C080N32EFM is ComPacT breaker NS800 N 50kA 3P MicroLogic 2.0E Fixed Manually Operated.

Scan QR code for breaker updates

Each breaker is equipped with a QR code that allows you to get the latest information on your breaker.



Simpler Names for our Offers

We are making it easier for you to navigate across the wide range of our world-class digital offerings and select with confidence the offers that are right for you and your needs.

EcoStruxure Architecture

To enable brand consistency, relevance and impact, we are reinforcing our EcoStruxure™ architecture and digital customer lifecycle tools to ensure a seamless experience from the CAPEX to OPEX phases of each project, bridging our entire ecosystem of partners, services providers and end users.

EcoStruxure is our IoT-enabled open and interoperable system architecture and platform. EcoStruxure delivers enhanced values around safety, reliability, efficiency, sustainability and connectivity for our customers. EcoStruxure leverages advancements in IoT, mobility, sensing, cloud, analytics, and cybersecurity technologies to deliver Innovation At Every Level from Connected Products; Edge Control; and Apps, Analytics & Services: our IoT technology Levels.

Old names	New names
Ecodial	EcoStruxure Power Design
Ecoreal	EcoStruxure Power Build
Ecoreach	EcoStruxure Power Commission
Masterpact MTZ mobile App	EcoStruxure Power Device App

PacT Series

Future-proof your installation with Schneider Electric's low and medium voltage **PacT** Series. Built on legendary Schneider Electric innovation, the **PacT** Series comprises world-class circuit breakers, switches, residual current devices and fuses, for all standard and specific applications. Experience robust performance with this comprehensive range of EcoStruxure- ready switchgear, for all applications from 16 to 6300 A.

Old names	New names
Compact	Com PacT
Masterpact	Master PacT
Micrologic	MicroLogic
Transferpact	Transfer PacT
Fupact	Fu PacT
Vigirex	Vigi PacT



General Contents

ComPacT NS630b to 3200

Functions and Characteristics

A

Installation Recommendations

B

Dimensions and Connection

C

Electrical Diagrams

D


Additional Characteristics

E

Catalogue Numbers and Order Form

F

ComPacT NS, Even More Applications...



Protection of LV distribution systems


> pages **A-2** et **A-25**

Protection for:

- Distribution systems supplied by transformers
- Distribution systems supplied by engine generator sets
- Long cables in IT and TN systems.

Installation:

- In power switchboards.
- All circuit breakers in the ComPacT NS range offer positive contact indication and are suitable for isolation in compliance with standards IEC 60947-1 and 2.




Protection of motors feeders (AC 220/690 V)

> page **A-44**

When combined with a motor starter, ComPacT NS circuit breakers protect the cables and the starter against short-circuits. Equipped with an electronic trip unit, ComPacT NS circuit breakers also protect the cables, starter and motor against overloads.

The exceptional current-limiting capacity of ComPacT NS circuit breakers automatically ensures type-2 coordination with the motor starter, in compliance with standard IEC 60947-4-1.




Earth-leakage

> page **A-45**

Additional earth-leakage protection protects life and property against the risks of faulty insulation in the installation.

Depending on the circuit breaker, earth-leakage protection is provided by:

- Using a specific MicroLogic control unit
- Using a VigiPacT relay and separate toroids.




Service connection

ComPacT NS service connection circuit breakers are specially designed for the service-connection function:

- Lead seals and locking systems
- Tripping curves certified by utilities
- Fast overload curves to limit the power supplied, etc.

ComPacT INV switch-disconnectors offering visible break (see the corresponding catalog) can be combined with ComPacT NS circuit breakers to constitute the various types of service connections and meet the needs of all installation configurations.



Control and isolation using switch-disconnectors


> page **A-46**

A switch-disconnector version of ComPacT NS circuit breakers exists for circuit control and isolation.

All the additional functions may be combined with the basic switch-disconnector function, including:

- Earth-leakage protection
- Motor mechanism.

For information on other switch-disconnector ranges, see the ComPacT INS/INV (offering positive contact indication and visible break) and FuPacT (fuse switch) catalogs.



Source-changeover systems

> page **A-52**

To ensure a continuous supply of power, some electrical installations are connected to two power sources:

- A source "S1"
- A source "S2" to supply the installation when the source "S1" is not available.

A mechanical and/or electrical interlocking system between two circuit breakers or switch-disconnectors avoids all risk of parallel connection of the sources during switching.

A source-changeover system can be:

- Manual with mechanical device interlocking
- Remote controlled with mechanical and/or electrical device interlocking
- Automatic by adding a controller to manage switching from one source to the other on the basis of external parameters.

(See Source-changeover catalog for dimensions, connections and electrical drawings).

They can be combined with the FDM121 switchboard display unit to provide all the functions of a Power Meter as well as operating assistance.

Power Meter Functions

> Page A-18

All ComPacT circuit breakers are equipped with a MicroLogic control unit that can be changed on site. Control units are designed to protect power circuits and loads. Alarms may be programmed for remote indications. In addition to protection functions, MicroLogic S/A/E/P control units offer all the functions of Power Meter products as well as operating-assistance for the circuit breaker.



Operating-Assistance Functions

> Page A-20

Integration of measurement functions provides operators with operating assistance functions including alarms tripped by user-selected measurement values, time-stamped event tables and histories, and maintenance indicators.



Switchboard-Display Unit Functions

> Page A-21

The main measurements can be read on the built-in screen of MicroLogic 2/5/6/7 trip units. They can also be displayed on the FDM switchboard display unit along with pop-up windows signalling the main alarms.



Communication

> Page A-30

ComPacT NS equipped with MicroLogic provide communication capabilities. Simple RJ45 cords connect to a Modbus interface module.


- IFM: Modbus interface module.
- IFE: Ethernet interface module.
- I/O application module.
- EcoStruxure Power Commission software.



Introduction


General Characteristics for NS630b to 3200 Range

DB421306.eps

Compact			
NS1600 H 			
Ui 800 V	Uimp 8 kV		
Ue (V)	Icu (kA)	Ics (kA)	
220/240 a	70	37	
380/415 a	70	37	
440 a	65	37	
500/525 a	50	30	
660/690 a	42	22	
Icw 19.2kA / 1s cat B			
50/60Hz IEC 60947-2			



Electrically operated Compact NS circuit breaker.

DB439170.eps

NS1250 N 			
Ui 1000V	Uimp 8kV		
Ue (V~)	Icu (kA)	Ics (kA)	
220/240	85	50	
380/415	50	50	
440	50	50	
500/525	40	40	
660/690	30	30	
Icw 19.2kA / 1s cat B			
50/60Hz IEC/EN 60947-2			


Manually operated ComPacT NS circuit breaker.

DB439363.eps

NS1600b N 			
Ui 800V	Uimp 8kV		
Ue (V~)	Icu (kA)	Ics (kA)	
220/240	85	64	
380/415	70	52	
440	65	65	
500/525	65	65	
660/690	65	65	
Icw 32kA / 3s cat B			
50/60Hz IEC/EN 60947-2			

Manually operated ComPacT NS circuit breaker.

Standardized characteristics indicated on the rating plate:

Ui: rated insulation voltage
 Uimp: rated impulse withstand voltage
 Icu: ultimate breaking capacity, for various values of the rated operational voltage Ue
 cat: utilization category
 Icw: rated short-time withstand current
 Ics: service breaking capacity
 In: rated current
 suitable for isolation

 Not applicable for IT networks

Compliance with Standards

ComPacT NS circuit breakers and auxiliaries comply with the following:

- International recommendations:
 - IEC 60947-1 - general rules
 - IEC 60947-2 - circuit breakers
 - IEC 60947-3 - switches, disconnectors, switch-disconnectors, etc.
 - IEC 60947-4 - contactors and motor starters
 - IEC 60947-5.1 and following - control circuit devices and switching elements; automatic control components
- European (EN 60947-1 and EN 60947-2) and the corresponding national standards:
 - France NF
 - Germany VDE
 - U.K. BS
 - Australia AS
 - Italy CEI
- The specifications of the marine classification companies (Veritas, Lloyd's Register of Shipping, Det Norske Veritas, etc.)
- French standard NF C 79-130 and the recommendations issued by the CNOMO organization for the protection of machine tools.

For U.S. UL, Canadian CSA, Mexican NOM and Japanese JIS standards, please consult us.

Pollution Degree

ComPacT NS circuit breakers are certified for operation in pollution-degree 3 environments as defined by IEC standard 60947 (industrial environments).

Tropicalization

ComPacT NS circuit breakers have successfully passed the tests prescribed by the following standards for extreme atmospheric conditions:

- IEC 60068-2-1 - dry cold (-55 °C)
- IEC 60068-2-2 - dry heat (+85 °C)
- IEC 60068-2-30 - damp heat (95 % relative humidity at 55 °C)
- IEC 60068-2-52 - salt mist (severity level 2).

Environmental Protection

ComPacT NS circuit breakers take into account important concerns for environmental protection. Most components are recyclable and the parts of ComPacT NS630b to NS3200 circuit breakers are marked as specified in applicable standards.


Ambient Temperature

- ComPacT NS circuit breakers may be used between -25 °C and +70 °C.
 For temperatures higher than 40 °C (65 °C for circuit breakers used to protect motor feeders), devices must be derated as indicated in the documentation.
- Circuit-breakers should be put into service under normal ambient operating-temperature conditions. Exceptionally, the circuit breaker may be put into service when the ambient temperature is between -35 °C and -25 °C.

Permissible storage-temperature range for ComPacT NS circuit breakers in the original packing is -50 °C ^[1] to +85 °C.

Selectivity

By design, the ComPacT NS range embeds selectivity between two circuit breakers positioned in series in an installation.



^[1] -40 °C for MicroLogic control units with an LCD screen.

Introduction

General Characteristics for NS630b to 3200 Range

Positive Contact Indication

All ComPacT NS circuit breakers are suitable for isolation as defined in IEC standard 60947-2:

- The isolation position corresponds to the O (OFF) position.
- The operating handle cannot indicate the "OFF" position unless the contacts are effectively open.
- Padlocks may not be installed unless the contacts are open.

Installation of a rotary handle or a motor mechanism does not alter the reliability of the position-indication system.

The isolation function is certified by tests giving:

- The mechanical reliability of the position indication system.
- The absence of leakage currents.
- Overvoltage withstand capacity between upstream and downstream connections.



Installation in Class II Switchboards

All ComPacT NS circuit breakers are class II front face devices. They may be installed through the door of class II switchboards (as per IEC standard 60664), without downgrading switchboard insulation. Installation requires no special operations, even when the circuit breaker is equipped with a rotary handle or a motor mechanism.




Degree of Protection


As per standards IEC 60529 (IP degree of protection) and EN 50102 (IK degree of protection against external mechanical impacts).

Bare Circuit Breaker with Terminal Shields

	With toggle	IP40	IK07
	With direct rotary handle standard/VDE	IP40	IK07

Circuit Breaker Installed in a Switchboard

	With toggle	IP40	IK07
	With direct rotary handle standard/VDE	IP40	IK07
	MCC CNOMO	IP435 IP547	
	With extended rotary handle	IP55	IK08



DB439038.eps





Presentation

Protection of Distribution Systems

Overview of Solutions

Protection of distribution systems means protection of:

- Systems supplied by a transformer
- Systems supplied by an engine generator set
- Long cables in IT and TN systems.



Power Distribution

Selection of Circuit Breakers from 630 to 3200 A - Page A-2

Rated current (A)	630	800	1000	1250	1600
ComPacT	NS630b	NS800	NS1000	NS1250	NS1600

CO80N35EFM.psd



PB104831_ME.epa



Breaking capacity	N	50	50	50	50
(kA rms)	H	70	70	70	70
380/415 V	L	150	150	-	-
	LB [1]	200	200	-	-

Rated current (A)	1600	2000	2500	3200
ComPacT	NS1600b	NS2000	NS2500	NS3200

C250N3FM.psd



Breaking capacity	N	70	70	70
(kA rms)	H	85	85	85
380/415 V				

Associated Control Units up to 3200 A - Page A-20

MicroLogic electronic control units may be used on all ComPacT NS630b to NS3200 circuit breakers and can be changed by Schneider Electric qualified personnel.

[1] Only for manually operated version.

Functions and Characteristics

A

Protection of Distribution Systems	
ComPacT NS Circuit Breakers from 630b up to 3200 A.....	A-2
MicroLogic Control Units	
Overview of Functions.....	A-6
For ComPacT NS630b to 3200.....	A-8
MicroLogic A "Ammeter".....	A-10
MicroLogic E "Energy".....	A-12
MicroLogic Control Units	
MicroLogic P "Power".....	A-14
Power Meter Functions	
MicroLogic A/E/P Control Unit with COM Option Via Breaker Communication Module (BCM ULP) and COM Ethernet Gateway.....	A-18
Operating-Assistance Functions	
MicroLogic A/E/P Control Unit with COM Option Via Breaker Communication Module (BCM ULP).....	A-20
FDM121 Switchboard-Display Functions	
MicroLogic A/E/P Control Unit with COM Option Via Breaker Communication Module (BCM ULP).....	A-21
MicroLogic A/E/P Control Unit with COM Ethernet Gateway.....	A-23
Protection of Distribution Systems	
MicroLogic Control Units for ComPacT NS630b to 3200.....	A-25
Service Interface and Power Supplies	A-26
Communication	
Communication Wiring System.....	A-30
Overview of Functions.....	A-31
COM Option in ComPacT.....	A-32
Communication Architecture.....	A-33
IFE Ethernet Interface	A-34
IFM Modbus Communication Interface	A-36
Connection of the IFE to a Fixed or Withdrawable ComPacT NS	A-38
Connection of the IFM to a Fixed or Withdrawable ComPacT NS	A-39
I/O Application Module	A-40
Motor Protection	
Overview of Solutions.....	A-44
Earth-Leakage Protection	
Overview of Solutions.....	A-45
Control and Isolation	
Overview of Solutions.....	A-46
Control and Disconnection	
ComPacT NS630bNA to 1600NA Switch-Disconnectors.....	A-48
ComPacT NS1600bNA to 3200NA Switch-Disconnectors.....	A-50
Source-Changeover Systems	
Presentation.....	A-52
Manual Source-Changeover Systems.....	A-53
Electrical Interlocking	
IVE Unit.....	A-54
Remote-Operated Systems.....	A-55
Source-Changeover Systems	
Associated Controllers.....	A-56
Electrical and Mechanical Accessories	
ComPacT NS630b to 1600 (Fixed Version).....	A-58
ComPacT NS630b to 1600 (Withdrawable Version).....	A-59
ComPacT NS630b to 1600.....	A-60
ComPacT NS1600b to 3200 (Fixed Version).....	A-77
ComPacT NS1600b to 3200.....	A-78
Indication and Measurement Accessories	
PowerLogic™ PowerTag Energy Rope 200 A to 2000 A.....	A-82

Protection of Distribution Systems

ComPacT NS Circuit Breakers from 630b up to 3200 A

A

C090N3SEFM.pdf



ComPacT NS800N manually operated

PB104831_ME.epa



ComPacT NS1600H electrically operated

C250N3FM.pdf



ComPacT NS1600b N manually operated

[1] 65 °C with vertical connections. See the temperature derating tables for other types of connections.

ComPacT Circuit Breakers

Number of poles

Control	manual	toggle
		direct or extended rotary handle
	electric	

Type of Circuit Breaker

Connections	fixed	front connection
		rear connection
	withdrawable (on chassis)	front connection with bare cables
		front connection
		rear connection

Electrical characteristics as per IEC/EN 60947-2

Rated current (A)	In	50 °C
		65 °C [1]
Rated insulation voltage (V)	Ui	
Rated impulse withstand voltage (kV)	Uimp	
Rated operational voltage (V)	Ue	AC 50/60 Hz

Type of Circuit Breaker

Ultimate breaking capacity (kA rms)	Manual	Icu	AC 50/60 Hz	220/240 V
				380/415 V
				440 V
				500/525 V
				660/690 V
		Ics	AC 50/60 Hz	220/240 V
				380/415 V
				440 V
				500/525 V
				660/690 V
	Electrical	Icu	AC 50/60 Hz	220/240 V
				380/415 V
				440 V
				500/525 V
				660/690 V
		Ics	AC 50/60 Hz	220/240 V
				380/415 V
				440 V
				500/525 V
				660/690 V

Short-time withstand current (kA rms)	Icw	AC 50/60 Hz	1 s
			3 s

Integrated instantaneous protection kA peak ±10 %

Suitability for isolation

Utilization category





































































Durability (C-O cycles)	mechanical		
	electrical	440 V	In/2
			In
		690 V	In/2
			In

Pollution degree

Protection of Distribution Systems

ComPacT NS Circuit Breakers from 630b up to 3200 A

A

	NS630b			NS800		NS1000			NS1250		NS1600		NS1600b		NS2000		NS2500		NS3200	
	3, 4					3, 4			3, 4		3, 4		3, 4		3, 4		3, 4		3, 4	
																				
												-		-		-		-		-
	 (except LB)											-		-		-		-		-
	N	H	L	LB	N	H	L	N	H	N	H	N	H	N	H	N	H	N	H	
				-																
													-	-	-	-	-	-	-	
			-	-			-			-	-	-	-	-	-	-	-	-	-	
													-	-	-	-	-	-	-	
													-	-	-	-	-	-	-	
	630		800		1000			1250		1600		1600		2000		2500		3200		
	630		800		1000			1250		1510		1550		1900		2500		2970		
	1000				1000			1000		1000		800		800		800		800		
	8				8			8		8		8		8		8		8		
	690				690			690		690		690		690		690		690		
	N	H	L	LB	N	H	L	N	H	N	H	N	H	N	H	N	H	N	H	
	85	85	150	200	85	85	150	85	85	85	85	85	125	85	125	85	125	85	125	
	50	70	150	200	50	70	150	50	70	50	70	70	85	70	85	70	85	70	85	
	50	65	130	200	50	65	130	50	65	50	65	65	85	65	85	65	85	65	85	
	40	50	100	100	40	50	100	40	50	40	50	65	-	65	-	65	-	65	-	
	30	42	-	75	30	42	-	30	42	30	42	65	-	65	-	65	-	65	-	
	50	50	150	200	50	50	150	50	50	37	37	64	94	64	94	64	94	64	94	
	50	50	150	200	50	50	150	50	50	37	37	52	64	52	64	52	64	52	64	
	50	50	130	200	50	50	130	50	50	37	37	65	64	65	64	65	64	65	64	
	40	40	100	100	40	40	100	40	40	30	30	65	-	65	-	65	-	65	-	
	30	30	-	75	30	30	-	30	30	22	22	65	-	65	-	65	-	65	-	
	50	70	150	-	50	70	150	50	70	50	70	-	-	-	-	-	-	-	-	
	50	70	150	-	50	70	150	50	70	50	70	-	-	-	-	-	-	-	-	
	50	65	130	-	50	65	130	50	65	50	65	-	-	-	-	-	-	-	-	
	40	50	100	-	40	50	100	40	50	40	50	-	-	-	-	-	-	-	-	
	30	42	-	-	30	42	-	30	42	30	42	-	-	-	-	-	-	-	-	
	37	37	150	-	37	37	150	37	37	37	37	-	-	-	-	-	-	-	-	
	37	37	150	-	37	37	150	37	37	37	37	-	-	-	-	-	-	-	-	
	37	37	130	-	37	37	130	37	37	37	37	-	-	-	-	-	-	-	-	
	30	30	100	-	30	30	100	30	30	30	30	-	-	-	-	-	-	-	-	
	22	22	-	-	22	22	-	22	22	22	22	-	-	-	-	-	-	-	-	
	19.2	19.2	-	-	19.2	19.2	-	19.2	19.2	19.2	19.2	-	-	-	-	-	-	-	-	
	-	-	-	-	-	-	-	-	-	-	-	32	32	32	32	32	32	32	32	
	40	40	-	-	40	40	-	40	40	40	40	130	130	130	130	130	130	130	130	
																				
	B	B	A	A	B	B	A	B	B	B	B	B	B	B	B	B	B	B	B	
	10000				10000			10000		10000		5000		5000		5000		5000		
	6000	6000	4000	4000	6000	6000	4000	5000	5000	5000	5000	3000	3000	3000	3000	3000	3000	3000	3000	
	5000	5000	3000	3000	5000	5000	3000	4000	4000	2000	2000	2000	2000	2000	2000	2000	2000	2000	2000	
	4000	4000	3000	3000	4000	4000	3000	3000	3000	2000	2000	2000	2000	2000	2000	2000	2000	2000	2000	
	2000	2000	2000	2000	2000	2000	2000	2000	2000	1000	1000	1000	1000	1000	1000	1000	1000	1000	1000	
	3				3			3		3		3		3		3		3		

Protection of Distribution Systems

ComPacT NS Circuit Breakers from 630b up to 3200 A

A

C080N5EFA1.pptd



ComPacT NS800N manually operated

PB104831_ME.pptd



ComPacT NS1600H electrically operated

C250N6FM.pptd



ComPacT NS1600b N manually operated

ComPacT Circuit Breakers

Protection and Measurements

Interchangeable control units

Overload protection long time I_r ($I_n \times \dots$)Short-circuit protection short time I_{sd} ($I_r \times \dots$)instantaneous I_i ($I_n \times \dots$)Earth-fault protection I_g ($I_n \times \dots$)Residual earth-leakage protection $I_{\Delta n}$

Zone selective interlocking ZSI

Protection of the fourth pole

Current measurements

Power measurements

Advanced protection

Quick view

Remote Communication by Bus

Device-status indication

Device remote operation [2]

Transmission of settings

Indication and identification of protection devices and alarms

Transmission of measured current values

ComPacT Circuit Breakers

Additional indication and control auxiliaries

Indication contacts

Voltage releases

MX shunt release/MN undervoltage release

Installation

Accessories

terminal extensions and spreaders

terminal shields and interphase barriers

escutcheons

Dimensions fixed devices, front connections (mm) 3P

H x W x D 4P

Weight fixed devices, front connections (kg) 3P

4P

Source changeover system (see section on "source changeover systems")

Manual, remote-operated and automatic source changeover systems

[1] Except 1600b-3200.

[2] With NS630b...NS1600, remote operation is possible with electrically operated device.
With NS1600...NS3200, remote operation is not possible.

Protection of Distribution Systems

ComPacT NS Circuit Breakers from 630b up to 3200 A

A

NS630b NS800 NS1000 NS1250 NS1600 NS1600b NS2000 NS2500 NS3200														
	MicroLogic													
	2.0	5.0	6.0	2.0A	5.0A	6.0A	7.0A	2.0E	5.0E	6.0E	5.0P ^[1]	6.0P ^[1]	7.0P ^[1]	
	⊙	⊙	⊙	⊙	⊙	⊙	⊙	⊙	⊙	⊙	⊙	⊙	⊙	
	-	⊙	⊙	-	⊙	⊙	⊙	-	⊙	⊙	⊙	⊙	⊙	
	⊙	⊙	⊙	⊙	⊙	⊙	⊙	⊙	⊙	⊙	⊙	⊙	⊙	
	-	-	⊙	-	-	⊙	-	-	-	⊙	-	⊙	-	
	-	-	-	-	-	-	⊙	-	-	-	-	-	⊙	
	-	-	-	⊙	⊙	⊙	⊙	⊙	⊙	⊙	⊙	⊙	⊙	
	⊙	⊙	⊙	⊙	⊙	⊙	⊙	⊙	⊙	⊙	⊙	⊙	⊙	
	-	-	-	⊙	⊙	⊙	⊙	⊙	⊙	⊙	⊙	⊙	⊙	
	-	-	-	-	-	-	-	⊙	⊙	⊙	⊙	⊙	⊙	
	-	-	-	-	-	-	-	-	-	-	⊙	⊙	⊙	
	-	-	-	-	-	-	-	⊙	⊙	⊙	-	-	-	
	⊙	⊙	⊙	⊙	⊙	⊙	⊙	⊙	⊙	⊙	⊙	⊙	⊙	
	⊙	⊙	⊙	⊙	⊙	⊙	⊙	⊙	⊙	⊙	⊙	⊙	⊙	
	-	-	-	⊙	⊙	⊙	⊙	⊙	⊙	⊙	⊙	⊙	⊙	
	-	-	-	⊙	⊙	⊙	⊙	⊙	⊙	⊙	⊙	⊙	⊙	
	-	-	-	⊙	⊙	⊙	⊙	⊙	⊙	⊙	⊙	⊙	⊙	
NS630b NS800 NS1000 NS1250 NS1600 NS1600b NS2000 NS2500 NS3200														
	⊙							⊙						
	⊙							⊙						
	⊙							-						
	⊙							⊙						
	⊙							⊙						
	327 x 210 x 147							350 x 420 x 160						
	327 x 280 x 147							350 x 535 x 160						
	14							24						
	18							36						
	⊙							-						

MicroLogic Control Units

Overview of Functions

A

All ComPacT circuit breakers are equipped with a MicroLogic control unit that can be changed on site. Control units are designed to protect Power circuits and loads. Alarms may be programmed for remote indications. Measurements of current, voltage, frequency, power and power quality optimize continuity of service and energy management.

MicroLogic Name Codes

2.0 E

X Y Z

X: type of protection

- 2 for basic protection
- 5 for selective protection
- 6 for selective + earth-fault protection
- 7 for selective + earth-leakage protection.

Y: control-unit generation

Identification of the control-unit generation.

"0" signifies the first generation.

Z: type of measurement

- No letter: no measurements
- A for "ammeter"
- E for "energy"
- P for "power meter"



Dependability

Integration of protection functions in an ASIC electronic component used in all MicroLogic control units ensures a high degree of reliability and immunity to conducted or radiated disturbances.

On MicroLogic A, E and P control units, advanced functions are managed by an independent microprocessor.


Accessories

Certain functions require the addition of MicroLogic control unit accessories, described on [page A-30](#).

The rules governing the various possible combinations can be found in the documentation accessible via the Products and services menu of the www.se.com web site.

Current Protection


MicroLogic 2: basic protection



Protection:

- Long time (L)
- Instantaneous (I)



MicroLogic 5: selective protection



Protection:

- Long time (L)
- Short time (S)
- Instantaneous (I)



MicroLogic 6: selective + earth-fault protection



Protection:

- Long time (L)
- Short time (S)
- Instantaneous (I)
- Earth fault (G)

MicroLogic 7: selective + earth leakage protection



Protection:














- Long time (L)
- Short time (S)
- Instantaneous (I)
- Earth leakage up to 3200A (R)

Functions and Characteristics

MicroLogic Control Units

Overview of Functions

A


MicroLogic without Measurement	Measurements and Programmable Protection		
	<p>A: Ammeter</p> <ul style="list-style-type: none"> ■ I_1, I_2, I_3, I_N, $I_{\text{earth-fault}}$, $I_{\text{earth-leakage}}$ and maximeter for these measurements ■ Fault indications ■ Settings in amperes and in seconds. <p>E: Energy</p> <p>Incorporates all the rms measurements of MicroLogic A, plus voltage, power factor, power and energy metering measurements.</p> <ul style="list-style-type: none"> ■ Calculates the current demand value ■ "Quickview" function for the automatic cyclical display of the most useful values (as standard or by selection). <p>P: A + Power meter + programmable protection</p> <ul style="list-style-type: none"> ■ Measurements of V, A, W, VAR, VA, Wh, VARh, VAh, Hz, V_{peak}, A_{peak}, power factor and maximeters and minimeters ■ IDMTL long-time protection, minimum and maximum voltage and frequency, voltage and current imbalance, phase sequence, reverse power ■ Load shedding and reconnection depending on power or current ■ Measurements of interrupted currents, differentiated fault indications, maintenance indications, event histories and time-stamping, etc. 		
Without measurement	MicroLogic A	MicroLogic E	MicroLogic P
			
			
			
			

MicroLogic Control Units

For ComPacT NS630b to 3200

A

MicroLogic 2.0, 5.0 and 6.0 control units protect power circuits. MicroLogic 5.0 and 6.0 offers time selectivity for short-circuits as well.



- A** Long-time threshold and tripping delay
- B** Overload alarm (LED)
- C** Short-time pick-up and tripping delay
- D** Instantaneous pick-up
- E** Fixing screw for long-time rating plug
- F** Test connector
- G** Indication of tripping cause
- H** Earth-leakage or earth-fault pick-up and tripping delay

Note: MicroLogic control units are equipped with a transparent lead-seal cover as standard.

Protection

Protection thresholds and delays are set using the adjustment dials.

Overload protection

True rms long-time protection.

Thermal memory: thermal image before and after tripping.

Setting accuracy may be enhanced by limiting the setting range using a different long-time rating plug.

Overload protection can be cancelled using a specific LT rating plug "Off".

Short-circuit protection

Short-time (rms) and instantaneous protection.

Selection of I^2t type (ON or OFF) for short-time delay.

Earth-fault protection

Residual or source ground return earth fault protection.

Selection of I^2t type (ON or OFF) for delay.

Neutral protection

On three-pole circuit breakers, neutral protection is not possible.

On four-pole circuit breakers, neutral protection may be set using a three-position switch: neutral unprotected (4P 3d), neutral protection at 0.5 Ir (4P 3d + N/2) or neutral protection at Ir (4P 4d).

Indications

Overload indication by alarm LED on the front; the LED goes on when the current exceeds the long-time trip threshold.

Test

A mini test kit or a BTM may be connected to the test connector on the front to check circuit-breaker operation after installing the trip unit or accessories.

Fault Indications (Only for Micrologic 6.0)

LEDs indicate the type of fault:

- Overload (long-time protection Ir)
- Short-circuit (short-time Isd or instantaneous Ii protection)
- Earth fault or earth leakage (Ig)
- Internal fault (Ap).

Battery power

The fault indication LEDs remain on until the test/reset button is pressed. Under normal operating conditions, the battery supplying the LEDs has a service life of approximately 10 years.


Functions and Characteristics

MicroLogic Control Units

For ComPacT NS630b to 3200

A

MicroLogic 2.0



Long-time

Current setting (A)	$I_r = I_n \times \dots$	0.4	0.5	0.6	0.7	0.8	0.9	0.95	0.98	1	
tripping between 1.05 and 1.20 x I_r		other ranges or disable by changing long-time rating plug									
Time setting	t_r (s)	$t_r = 0.5$ s to 24 s, step 0.5 s for 6 I_r									
Time setting example:	Accuracy: 0 to -30 %	1.5 x I_r	12.5	25	50	100	200	300	400	500	600
time delay (s)	Accuracy: 0 to -20 %	6 x I_r	0.5 [1]	1	2	4	8	12	16	20	24
	Accuracy: 0 to -20 %	7.2 x I_r	0.7 [2]	0.69	1.38	2.7	5.5	8.3	11	13.8	16.6
Thermal memory		20 minutes before and after tripping									


Thermal memory

20 minutes before and after tripping

Instantaneous

Pick-up (A)	$I_{sd} = I_r \times \dots$	1.5	2	2.5	3	4	5	6	8	10
Accuracy: ± 10 %										
Time delay		Max resettable time: 20 ms Max break time: 80 ms								

MicroLogic 5.0/6.0/7.0



Long-time

Current setting (A)	I_r = I_n x ...	0.4	0.5	0.6	0.7	0.8	0.9	0.95	0.98	1	
Tripping between 1.05 and 1.20 x I _r		Other ranges or disable by changing long-time rating plug									
Time setting	t _r (s)	0.5	1	2	4	8	12	16	20	24	
Time setting example:	Accuracy: 0 to -30 %	1.5 x I _r	12.5	25	50	100	200	300	400	500	600
time delay (s)	Accuracy: 0 to -20 %	6 x I _r	0.5 ^[1]	1	2	4	8	12	16	20	24
	Accuracy: 0 to -20 %	7.2 x I _r	0.7 ^[2]	0.69	1.38	2.7	5.5	8.3	11	13.8	16.6
Thermal memory		20 minutes before and after tripping									

Thermal memory

20 minutes before and after tripping


Short-time

Pick-up (A)	$I_{sd} = I_r \times \dots$	1.5	2	2.5	3	4	5	6	8	10
Accuracy: ± 10 %										
Time setting tsd (s)	Settings	I^2t Off	0	0.1	0.2	0.3	0.4			
		I^2t On	-	0.1	0.2	0.3	0.4			
Operating time at 10 x I_r	max resettable time		20	80	140	230	350			
I^2t Off or I^2t On	max break time		80	140	200	320	500			

Instantaneous

Pick-up (A)	$I_i = I_n \times \dots$	2	3	4	6	8	10	12	15	off
Accuracy: ± 10 %										
Operating time		Standard								
	max resettable time	20 ms								
	max break time	50 ms								

MicroLogic 6.0



Earth fault

Pick-up (A)	I _g = ln x ...	A	B	C	D	E	F	G	H	J
Accuracy: ±10 %	ln ≤ 400 A	0.3	0.3	0.4	0.5	0.6	0.7	0.8	0.9	1
	400 A < ln < 1250 A	0.2	0.3	0.4	0.5	0.6	0.7	0.8	0.9	1
	ln ≥ 1250 A	500	640	720	800	880	960	1040	1120	1200
Time setting t _g (s)	Settings	I ² t Off	0	0.1	0.2	0.3	0.4			
		I ² t On	-	0.1	0.2	0.3	0.4			
Time delay (ms) at ln or 1200 A (I ² t Off or I ² t On)	t _g = max resettable time	20	80	140	230	350				
	t _g = max break time	80	140	200	320	500				

Note: All current-based protection functions require no auxiliary source.

The test/reset button resets maximeters, clears the tripping indication and tests the battery.

[1] 0 to -40 %


[2] 0 to -60 %

MicroLogic Control Units

MicroLogic A "Ammeter"

A

MicroLogic A control units protect power circuits. They also offer measurements, display, communication and current maximeters. Version 6 provides earth-fault protection, version 7 provides earth-leakage protection.



- A** Long-time threshold and tripping delay
- B** Overload alarm (LED) at 1.125 I_r
- C** Short-time pick-up and tripping delay
- D** Instantaneous pick-up
- E** Earth-leakage or earth-fault pick-up and tripping delay
- F** Earth-leakage or earth-fault test button
- G** Long-time rating plug screw
- H** Test connector
- I** Lamp test, reset and battery test
- J** Indication of tripping cause
- K** Digital display
- L** Three-phase bargraph and ammeter
- M** Navigation buttons

Note: MicroLogic A control units come with a transparent lead-seal cover as standard.

"Ammeter" Measurements

MicroLogic A control units measure the true (rms) value of currents. They provide continuous current measurements from 0.2 to 1.2 I_n and are accurate to within 1.5 % (including the sensors).

A digital LCD screen continuously displays the most heavily loaded phase (I_{max}) or displays the I_1 , I_2 , I_3 , I_n , I_g , $I_{\Delta n}$, stored-current (maximeter) and setting values by successively pressing the navigation button.

The optional external power supply makes it possible to display currents < 20 % I_n . Below 0.1 I_n , measurements are not significant. Between 0.1 and 0.2 I_n , accuracy changes linearly from 4 % to 1.5 %.

Communication Option (COM)

In conjunction with the communication option, the control unit transmits the following:

- Settings
- All "ammeter" measurements
- Tripping causes
- Maximeter readings.

Protection

Protection thresholds and delays are set using the adjustment dials.

Overload protection

True rms long-time protection.

Thermal memory: thermal image before and after tripping.

Setting accuracy may be enhanced by limiting the setting range using a different long-time rating plug.

Overload protection can be cancelled using a specific LT rating plug "Off".

Short-circuit protection

Short-time (rms) and instantaneous protection.

Selection of I^2t type (ON or OFF) for short-time delay.

Earth-fault protection

Residual or source ground return earth fault protection.

Selection of I^2t type (ON or OFF) for delay.

Residual earth-leakage protection (Vigi).

Operation without an external power supply. I_n Protected against nuisance tripping.

\hat{I}_{dc} DC-component withstand class A up to 10 A.

Neutral protection

On three-pole circuit breakers, neutral protection is not possible. On four-pole circuit breakers, neutral protection may be set using a three-position switch: neutral unprotected (4P 3d), neutral protection at 0.5 I_r (4P 3d + N/2), neutral protection at I_r (4P 4d).

Zone selective interlocking (ZSI)

A ZSI terminal block may be used to interconnect a number of control units to provide total selectivity for short-time and earth-fault protection, without a delay before tripping.

Overload Alarm

A yellow alarm LED goes on when the current exceeds the long-time trip threshold.

Fault Indications

LEDs indicate the type of fault:

- Overload (long-time protection I_r)
- Short-circuit (short-time I_{sd} or instantaneous I_i protection)
- Earth fault or earth leakage (I_g or $I_{\Delta n}$)
- Internal fault (A_p).

Battery power

The fault indication LEDs remain on until the test/reset button is pressed. Under normal operating conditions, the battery supplying the LEDs has a service life of approximately 10 years.

Test

A mini test kit or a BTM may be connected to the test connector on the front to check circuit-breaker operation. For MicroLogic 6.0 A and 7.0 A control units, the operation of earth-fault or earth-leakage protection can be checked by pressing the test button located above the test connector.


Functions and Characteristics

MicroLogic Control Units

MicroLogic A "Ammeter"


A

MicroLogic 2.0 A




Long-time	ANSI Code 49		0.4	0.5	0.6	0.7	0.8	0.9	0.95	0.98	1
Current setting (A)	$I_r = I_n \times \dots$		Other ranges or disable by changing long-time rating plug								
Time setting example:		tr (s)	0.5	1	2	4	8	12	16	20	24
time delay (s)	Accuracy: 0 to -30 %	$1.5 \times I_r$	12.5	25	50	100	200	300	400	500	600
	Accuracy: 0 to -20 %	$6 \times I_r$	0.7 ^[1]	1	2	4	8	12	16	20	24
	Accuracy: 0 to -20 %	$7.2 \times I_r$	0.7 ^[2]	0.69	1.38	2.7	5.5	8.3	11	13.8	16.6
Thermal memory			20 minutes before and after tripping								
Instantaneous	ANSI Code 50		1.5	2	2.5	3	4	5	6	8	10
Pick-up (A)	$I_{sd} = I_r \times \dots$										
Accuracy: $\pm 10\%$											
Time delay			Max resettable time: 20 ms Max break time: 80 ms								

MicroLogic 5.0/6.0/7.0 A




Long-time	ANSI Code 49		0.4	0.5	0.6	0.7	0.8	0.9	0.95	0.98	1
Current setting (A)	$I_r = I_n \times \dots$		Other ranges or disable by changing long-time rating plug								
Tripping between 1.05 and 1.20 x I_r											
Time setting example:		tr (s)	0.5	1	2	4	8	12	16	20	24
time delay (s)	Accuracy: 0 to -30 %	$1.5 \times I_r$	12.5	25	50	100	200	300	400	500	600
	Accuracy: 0 to -20 %	$6 \times I_r$	0.7 ^[1]	1	2	4	8	12	16	20	24
	Accuracy: 0 to -20 %	$7.2 \times I_r$	0.7 ^[2]	0.69	1.38	2.7	5.5	8.3	11	13.8	16.6
Thermal memory			20 minutes before and after tripping								
Short-time	ANSI Code 51		1.5	2	2.5	3	4	5	6	8	10
Pick-up (A)	$I_{sd} = I_r \times \dots$										
Accuracy: $\pm 10\%$											
Time setting tsd (s)	Settings	I^2t Off	0	0.1	0.2	0.3	0.4				
		I^2t On	-	0.1	0.2	0.3	0.4				
Operating time at 10 x I_r	tsd (max resettable time)		20	80	140	230	350				
I^2t Off or I^2t On	tsd (max break time)		80	140	200	320	500				
Instantaneous	ANSI Code 50		2	3	4	6	8	10	12	15	off
Pick-up (A)	$I_i = I_n \times \dots$										
Accuracy: $\pm 10\%$											
Operating time	max resettable time		20 ms								
	max break time		50 ms								

MicroLogic 6.0 A



Earth fault	ANSI Code 51N		A	B	C	D	E	F	G	H	J
Pick-up (A)	$I_g = I_n \times \dots$		0.3	0.3	0.4	0.5	0.6	0.7	0.8	0.9	1
Accuracy: $\pm 10\%$	$I_n \leq 400$ A		0.2	0.3	0.4	0.5	0.6	0.7	0.8	0.9	1
	400 A < I_n < 1250 A		500	640	720	800	880	960	1040	1120	1200
	$I_n \geq 1250$ A										
Time setting t_g (s)	Settings	I^2t Off	0	0.1	0.2	0.3	0.4				
		I^2t On	-	0.1	0.2	0.3	0.4				
Time delay (ms)	t_g = max resettable time		20	80	140	230	350				
at I_n or 1200 A	t_g = max break time		80	140	200	320	500				
(I^2t Off or I^2t On)											

MicroLogic 7.0 A



Residual earth leakage (Vigi) ANSI Code 51G			0.5	1	2	3	5	7	10	20	30
Sensitivity (A)	$I_{\Delta n}$										
Accuracy: 0 to -20 %											
Time delay Δt (ms)	Settings		60	140	230	350	800				
	max resettable time		60	140	230	350	800				
	max break time		140	200	320	500	1000				

MicroLogic 5.0/6.0/7.0 A

Ammeter				
Instantaneous currents	I_1, I_2, I_3, I_n	$0.2 \times I_n$ to $1.2 \times I_n$	$\pm 1.5\%$	
	I_g (6.0 A)	$0.2 \times I_n$ to I_n	$\pm 10\%$	
	$I_{\Delta n}$ (7.0 A)	0 to 30 A	$\pm 1.5\%$	
Current maximizers of	I_1, I_2, I_3, I_n	$0.2 \times I_n$ to $1.2 \times I_n$	$\pm 1.5\%$	

Note: All current-based protection functions require no auxiliary source.


The test/reset button resets maximizers, clears the tripping indication and tests the battery.

[1] 0 to -40 % - [2] 0 to -60 %

MicroLogic Control Units

MicroLogic E “Energy”

MicroLogic E control units protect power circuits. They also offer measurements, display, communication and current maximeters. Version 6 provides earth-fault protection.



- A** Long-time threshold and tripping delay
- B** Overload alarm (LED) at 1.125 Ir
- C** Short-time pick-up and tripping delay
- D** Instantaneous pick-up
- E** Earth-leakage or earth-fault pick-up and tripping delay
- F** Earth-leakage or earth-fault test button
- G** Long-time rating plug screw
- H** Test connector
- I** Lamp test, reset and battery test
- J** Indication of tripping cause
- K** Digital display
- L** Three-phase bargraph and ammeter
- M** Navigation button "quick View" (only with MicroLogic E)
- N** Navigation button to view menu contents
- O** Navigation button to change menu

[1] Display on FDM121 only.

Note: MicroLogic E control units come with a transparent lead-seal cover as standard.

"Energy Meter" Measurements

In addition to the ammeter measurements of MicroLogic A

MicroLogic E control units measure and display:

- Current demand
- Voltages: phase to phase, phase to neutral, average [1] and unbalanced [1]
- Instantaneous power: P, Q, S
- Power factor: PF
- Power demand: P demand
- Energy: Ep, Eq [1], Es [1]

Accuracy of active energy Ep is 2 % (including the sensors). The range of measurement is the same as current with MicroLogic A, depending of an external power supply module (24 V DC).

Communication Option (COM)

In conjunction with the communication option, the control unit transmits the following:

- Settings
- All "ammeter" and "energy" measurements
- Enable connection to FDM128
- Tripping causes
- Maximeter/minimeter readings.

Protection

Protection thresholds and delays are set using the adjustment dials.

Overload protection

True rms long-time protection.

Thermal memory: thermal image before and after tripping.

Setting accuracy may be enhanced by limiting the setting range using a different long-time rating plug. Overload protection can be cancelled using a specific LT rating plug "Off".

Short-circuit protection

Short-time (rms) and instantaneous protection.

Selection of I²t type (ON or OFF) for short-time delay.

Earth-fault protection

Residual or source ground return earth fault protection.

Selection of I²t type (ON or OFF) for delay.

Neutral protection

On three-pole circuit breakers, neutral protection is not possible.

On four-pole circuit breakers, neutral protection may be set using a three-position switch: neutral unprotected (4P 3d), neutral protection at 0.5 Ir (4P 3d + N/2), neutral protection at Ir (4P 4d).

Zone selective interlocking (ZSI)

A ZSI terminal block may be used to interconnect a number of control units to provide total selectivity for short-time and earth-fault protection, without a delay before tripping.

Overload Alarm

A yellow alarm LED goes on when the current exceeds the long-time trip threshold.

Fault Indications

LEDs indicate the type of fault:

- Overload (long-time protection Ir)
- Short-circuit (short-time Isd or instantaneous Ii protection)
- Earth fault (Ig)
- Internal fault (Ap).

Trip history

The trip history displays the list of the last 10 trips. For each trip, the following indications are recorded and displayed:

- The tripping cause: Ir, Isd, Ii, Ig or Auto-protection (Ap) trips
- The date and time of the trip (requires communication option).

Battery power

The fault indication LEDs remain on until the test/reset button is pressed. Under normal operating conditions, the battery supplying the LEDs has a service life of approximately 10 years.

Test

A mini test kit or a BTM may be connected to the test connector on the front to check circuit-breaker operation. For MicroLogic 6.0 E control units, the operation of earth-fault or earth-leakage protection can be checked by pressing the test button located above the test connector.


Functions and Characteristics

MicroLogic Control Units

MicroLogic E “Energy”


A

MicroLogic 2.0 E




Long-time		ANSI Code 49									
Current setting (A)	$I_r = I_n \times \dots$	0.4	0.5	0.6	0.7	0.8	0.9	0.95	0.98	1	
		Other ranges or disable by changing long-time rating plug									
Time setting example:	tr (s)	0.5	1	2	4	8	12	16	20	24	
time delay (s)	Accuracy: 0 to -30 %	1.5 x Ir	12.5	25	50	100	200	300	400	500	600
	Accuracy: 0 to -20 %	6 x Ir	0.7 ^[1]	1	2	4	8	12	16	20	24
	Accuracy: 0 to -20 %	7.2 x Ir	0.7 ^[2]	0.69	1.38	2.7	5.5	8.3	11	13.8	16.6
Thermal memory	20 minutes before and after tripping										
Instantaneous		ANSI Code 50									
Pick-up (A)	$I_{sd} = I_r \times \dots$	1.5	2	2.5	3	4	5	6	8	10	
Accuracy: ±10 %											
Time delay	Max resettable time: 20 ms Max break time: 80 ms										

MicroLogic 5.0/6.0 E



Long-time		ANSI Code 49									
Current setting (A)	$I_r = I_n \times \dots$	0.4	0.5	0.6	0.7	0.8	0.9	0.95	0.98	1	
Tripping between 1.05 and 1.20 x Ir		Other ranges or disable by changing long-time rating plug									
Time setting example:	tr (s)	0.5	1	2	4	8	12	16	20	24	
time delay (s)	Accuracy: 0 to -30 %	1.5 x Ir	12.5	25	50	100	200	300	400	500	600
	Accuracy: 0 to -20 %	6 x Ir	0.7 ^[1]	1	2	4	8	12	16	20	24
	Accuracy: 0 to -20 %	7.2 x Ir	0.7 ^[2]	0.69	1.38	2.7	5.5	8.3	11	13.8	16.6
Thermal memory		20 minutes before and after tripping									
Short-time		ANSI Code 51									
Pick-up (A)	$I_{sd} = I_r \times \dots$	1.5	2	2.5	3	4	5	6	8	10	
Accuracy: ±10 %											
Time setting tsd (s)	Settings	I ² t Off	0	0.1	0.2	0.3	0.4				
		I ² t On	-	0.1	0.2	0.3	0.4				
Operating time at 10 x Ir	tsd (max resettable time)	20	80	140	230	350					
I ² t Off or I ² t On	tsd (max break time)	80	140	200	320	500					
Instantaneous		ANSI Code 50									
Pick-up (A)	$I_i = I_n \times \dots$	2	3	4	6	8	10	12	15	off	
Accuracy: ±10 %											
Operating time	max resettable time	20 ms									
	max break time	50 ms									

MicroLogic 6.0 E



Earth fault		ANSI Code 51N									
Pick-up (A)	$I_g = I_n \times \dots$	A	B	C	D	E	F	G	H	J	
Accuracy: $\pm 10\%$	$I_n \leq 400\text{ A}$	0.3	0.3	0.4	0.5	0.6	0.7	0.8	0.9	1	
	$400\text{ A} < I_n < 1250\text{ A}$	0.2	0.3	0.4	0.5	0.6	0.7	0.8	0.9	1	
	$I_n \geq 1250\text{ A}$	500	640	720	800	880	960	1040	1120	1200	
Time setting t_g (s)	Settings	I^2t Off	0	0.1	0.2	0.3	0.4				
		I^2t On	-	0.1	0.2	0.3	0.4				
Time delay (ms)	t_g = max resettable time	20	80	140	230	350					
	t_g = max break time	80	140	200	320	500					
at I_n or 1200 A											
(I ² t Off or I ² t On)											

MicroLogic 5.0/6.0/7.0 E

Energy			
Instantaneous currents	I ₁ , I ₂ , I ₃ , I _N	0.2 x I _n to 1.2 x I _n	±1.5 %
	I _g (6.0 E)	0.2 x I _n to I _n	±10 %
Current maximizers of	I ₁ , I ₂ , I ₃ , I _N	0.2 x I _n to 1.2 x I _n	±1.5 %
Demand currents		0.2 x I _n to 1.2 x I _n	±1.5 %
of I ₁ , I ₂ , I ₃ , I _g			
Voltages	V12, V23, V31, V1N, V2N, V3N	100 to 690 V	±0.5 %
Active power	P	30 to 2000 kW	±2 %
Power factor	PF	0 to 1	±2 %
Demand power	P demand	30 to 2000 kW	±2 %
Active energy	Ep	-10 ¹⁰ GWh to 10 ¹⁰ GWh	±2 %

Note: All current-based protection functions require no auxiliary source.

The test/reset button resets maximizers, clears the tripping indication and tests the battery.


^[1] 0 to -40 % - ^[2] 0 to -60 %

MicroLogic Control Units

MicroLogic P "Power"

A

MicroLogic P control units include all the functions offered by MicroLogic A. In addition, they measure voltages and calculate power and energy values. They also offer new protection functions based on currents, voltages, frequency and power reinforce load protection in real time.



- A** Long-time current setting and tripping delay
- B** Overload signal (LED)
- C** Short-time pick-up and tripping delay
- D** Instantaneous pick-up
- E** Earth-leakage or earth-fault pick-up and tripping delay
- F** Earth-leakage or earth-fault test button
- G** Long-time rating plug screw
- H** Test connector
- I** Lamp + battery test and indications reset
- J** Indication of tripping cause
- K** High-resolution screen
- L** Measurement display
- M** Maintenance indicators
- N** Navigation buttons
- O** Navigation buttons
- P** Hole for settings lockout pin on cover

Note: MicroLogic P control units come with a non-transparent lead-seal cover as standard.

Protection

Protection Settings

The adjustable protection functions are identical to those of MicroLogic A (overloads, short-circuits, earth-fault and earth-leakage protection).

Fine adjustment

Within the range determined by the adjustment dial, fine adjustment of thresholds (to within one ampere) and time delays (to within one second) is possible on the keypad or remotely using the COM option.

IDMTL (Inverse Definite Minimum Time Lag) setting

Coordination with fuse-type or medium-voltage protection systems is optimized by adjusting the slope of the overload-protection curve. This setting also ensures better operation of this protection function with certain loads.

Neutral protection

On three-pole circuit breakers, neutral protection may be set using the keypad or remotely using the COM option, to one of four positions: neutral unprotected (4P 3d), neutral protection at 0.5 Ir (4P 3d + N/2), neutral protection at Ir (4P 4d) and neutral protection at 1.6 Ir (4P 3d + 1.6N). Neutral protection at 1.6 Ir is used when the neutral conductor is twice the size of the phase conductors (major load imbalance, high level of third order harmonics).

On four-pole circuit breakers, neutral protection may be set using a three-position switch or the keypad: neutral unprotected (4P 3d), neutral protection at 0.5 Ir (4P 3d + N/2), neutral protection at Ir (4P 4d). Neutral protection produces no effect if the long-time curve is set to one of the IDMTL protection settings.

Programmable Alarms and Other Protection

Depending on the thresholds and time delays set using the keypad or remotely using the COM option, the MicroLogic P control unit monitors currents and voltage, power, frequency and the phase sequence. Each threshold overrun is signalled remotely via the COM option. Each threshold overrun may be combined with tripping (protection) or an indication carried out by an optional I/O module (alarm), or both (protection and alarm).

Load Shedding and Reconnection

Load shedding and reconnection parameters may be set according to the power or the current flowing through the circuit breaker. Load shedding is carried out by a supervisor via the COM option or by I/O application module.

Indication Option Via I/O Application Module

I/O application module may be used to signal threshold overruns or status changes. They can be programmed using the COM option via Breaker Communication Module (BCM ULP) and EcoStruxure Power Commission software.


Communication Option (COM)

The communication option may be used to:

- Remotely read and set parameters for the protection functions
- Transmit all the calculated indicators and measurements
- Signal the causes of tripping and alarms
- Consult the history files and the maintenance-indicator register
- Maximeter reset.


An event log and a maintenance register, stored in control-unit memory but not available locally, may be accessed in addition via the COM option via Breaker Communication Module (BCM ULP).

MicroLogic 5.0/6.0/7.0 P (Protection)




Long-time		ANSI Code 49										
Current setting (A)	$I_r = I_n \times \dots$	0.4	0.5	0.6	0.7	0.8	0.9	0.95	0.98	1		
Tripping between 1.05 and 1.20 x I_r		Other ranges or disable by changing long-time rating plug										
Time setting example:		t_r (s)	0.5	1	2	4	8	12	16	20	24	
time delay (s)	Accuracy: 0 to -30 %	1.5 x I_r	12.5	25	50	100	200	300	400	500	600	
IDMTL (EIT)	Accuracy: 0 to -20 %	6 x I_r	0.7 ^[1]	1	2	4	8	12	16	20	24	
	Accuracy: 0 to -20 %	7.2 x I_r	0.7 ^[2]	0.69	1.38	2.7	5.5	8.3	11	13.8	16.6	
IDMTL setting	Curve slope	SIT	VIT	EIT	HVFuse	DT						
Thermal memory	20 minutes before and after tripping											
Short-time		ANSI Code 51										
Pick-up (A)	$I_{sd} = I_r \times \dots$	1.5	2	2.5	3	4	5	6	8	10		
Accuracy: ± 10 %												
Time setting tsd (s)	Settings	I^2t Off	0	0.1	0.2	0.3	0.4					
		I^2t On	-	0.1	0.2	0.3	0.4					
Operating time at 10 x I_r	tsd (max resettable time)	20	80	140	230	350						
I^2t Off or I^2t On	tsd (max break time)	80	140	200	320	500						
Instantaneous		ANSI Code 50										
Pick-up (A)	$I_i = I_n \times \dots$	2	3	4	6	8	10	12	15	off		
Accuracy: ± 10 %												
Operating time	max resettable time	20 ms										
	max break time	50 ms										

MicroLogic 6.0 P (Protection)




Earth fault		ANSI Code 51N									
Pick-up (A)	I_g = I _n x ...	A	B	C	D	E	F	G	H	J	
Accuracy: ±10 %	I _n ≤ 400 A	0.3	0.3	0.4	0.5	0.6	0.7	0.8	0.9	1	
	400 A < I _n < 1250 A	0.2	0.3	0.4	0.5	0.6	0.7	0.8	0.9	1	
	I _n ≥ 1250 A	500	640	720	800	880	960	1040	1120	1200	
Time setting t _g (s)	Settings	I ² t Off	0	0.1	0.2	0.3	0.4				
		I ² t On	-	0.1	0.2	0.3	0.4				
Time delay (ms)	t_g = max resettable time	20	80	140	230	350					
at I _n or 1200 A (I ² t Off or I ² t On)	t_g = max break time	80	140	200	320	500					

MicroLogic 7.0 P (Protection)




Residual earth leakage (Vigi) ANSI Code 51G										
Sensitivity (A)	$I_{\Delta n}$	0.5	1	2	3	5	7	10	20	30
Accuracy: 0 to -20 %										
Time delay Δt (ms)	Settings	60	140	230	350	800				
	max resettable time	60	140	230	350	800				
	max break time	140	200	320	500	1000				

MicroLogic 5.0/6.0/7.0 P (Alarms and Other Protection)



Current		ANSI Code 46		Threshold		Delay	
Current unbalance	$I_{unbalance}$	0.05 to 0.6 Iaverage		1 to 40 s			
Max. demand current	$I_{max\ demand: I1, I2, I3, IN}$	0.2 I_n to I_n		15 to 1500 s			
Earth fault alarm							
	I_{Δ}	10 to 100 % I_n ^[3]		1 to 10 s			
Voltage		ANSI Code					
Voltage unbalance	$U_{unbalance}$	47	2 to 30 % x $U_{average}$	1 to 40 s			
Minimum voltage	U_{min}	27	100 to U_{max} between phases	1.2 to 10 s			
Maximum voltage ^[4]	U_{max}	59	U_{min} to 1200 between phases	1.2 to 10 s			
Power							
Reverse power	rP	32P	5 to 500 kW	0.2 to 20 s			
Frequency							
Minimum frequency	F_{min}	81L	45 to F_{max}	1.2 to 5 s			
Maximum frequency	F_{max}	81H	F_{min} to 440 Hz	1.2 to 5 s			
Phase sequence							
Sequence (alarm)	$\Delta\emptyset$	$\emptyset 1/2/3$ or $\emptyset 1/3/2$		0.3 s			

MicroLogic 5.0/6.0/7.0 P (Load Shedding and Reconnection)



Measured value		Threshold		Delay	
Current	I	0.5 to 1 I_r per phase		20 % t_r to 80 % t_r	
Power	P	200 kW to 10 MW		10 to 3600 s	

MicroLogic 5.0/6.0/7.0 P (Power)

Type of measurements		Range		Accuracy	
Current maximeters of	$I1, I2, I3, IN$	0.2 x I_n to 1.2 x I_n		± 1.5 %	
Volatges	$V12, V23, V31, V1N, V2N, V3N$	100 to 690 V		± 0.5 %	
Power factor	PF	0 to 1		± 2 %	
Frequency (Hz)				0.1 %	

[1] 0 to -40 % - [2] 0 to -60 % - [3] $I_n \leq 400$ A 30 % 400 A < $I_n < 1250$ A 20 % $I_n \leq 1250$ A 10 % -

[4] For 690 V applications, a step-down transformer must be used if the voltage exceeds the nominal value of 690 V by more than 10 %.


Note: All current-based protection functions require no auxiliary source.

Voltage-based protection functions are connected to AC power via a voltage measurement input built into the circuit breaker.


MicroLogic Control Units

MicroLogic P "Power"


A




Default display




Display of a maximum current




Display of a voltage



Display of a power



Display of a frequency



Display of a demand power



Distance management with EcoStruxure™ Facility Expert on Smartphone, tablet, PC

Measurements

The MicroLogic P control unit calculates in real time all the electrical values (V, A, W, VAR, VA, Wh, VARh, VAh, Hz), power factors and cosφ factors.

The MicroLogic P control unit also calculates demand current and demand power over an adjustable time period. Each measurement is associated with a minimeter and a maximeter.

In the event of tripping on a fault, the interrupted current is stored. The optional external power supply makes it possible to display the value with the circuit breaker open or not supplied.

Instantaneous values

The value displayed on the screen is refreshed every second.

Minimum and maximum values of measurements are stored in memory (minimeters and maximeters).

Currents

I rms	A	1	2	3	N
	A	E-fault		E-leakage	
I max rms	A	1	2	3	N
	A	E-fault		E-leakage	

Voltages

U rms	V	12	23	31
V rms	V	1N	2N	3N
U average rms	V	(U12 + U23 + U31)/3		
U unbalance	%			

Power, energy

P active, Q reactive, S apparent	W, Var, VA	Totals
E active, E reactive, E apparent	Wh, VARh, VAh	Totals consumed - supplied
		Totals consumed
		Totals supplied
Power factor	PF	Total

Frequencies

F	Hz
---	----

Demand metering

The demand is calculated over a fixed or sliding time window that may be programmed from 5 to 60 minutes. According to the contract signed with the power supplier, an indicator associated with a load shedding function makes it possible to avoid or minimize the costs of overrunning the subscribed power. Maximum demand values are systematically stored and time stamped (maximeter).

Currents

I demand	A	1	2	3	N
	A	E-fault		E-leakage	
I max demand	A	1	2	3	N
	A	E-fault		E-leakage	

Power

P, Q, S demand	W, Var, VA	Totals
P, Q, S max demand	W, Var, VA	Totals

Minimeters and maximeters

Only the current and power maximeters may be displayed on the screen.

Time-stamping

Time-stamping is activated as soon as time is set manually or by a supervisor.

No external power supply module is required (max. drift of 1 hour per year).

Reset

An individual reset, via the keypad or remotely, acts on alarms, minimum and maximum data, peak values, the counters and the indicators.

Additional measurements accessible with the COM option via Breaker Communication Module (BCM ULP)

Some measured or calculated values are only accessible with the COM communication option:

- $I_{peak}/\sqrt{2}$, $(I_1 + I_2 + I_3)/3$, I unbalance
- Load level in % Ir
- Total power factor.

The maximeters and minimeters are available only via the COM option via Breaker Communication Module (BCM ULP) for use with a supervisor.

Additional info

Accuracy of measurements (including sensors):

- Voltage (V) 0.5 %
- Current (A) 1.5 %
- Frequency (Hz) 0.1 %
- Power (W) and energy (Wh) 2 %.

Functions and Characteristics

MicroLogic Control Units

MicroLogic P "Power"

Histories and Maintenance Indicators

The last ten trips and alarms are recorded in two separate history files that may be displayed on the screen:

- Tripping history:
 - ☐ Type of fault
 - ☐ Date and time
 - ☐ Values measured at the time of tripping (interrupted current, etc.)
- Alarm history:
 - ☐ Type of alarm
 - ☐ Date and time
 - ☐ Values measured at the time of the alarm.

All the other events are recorded in a third history file which is only accessible through the communication network.

- Event log history (only accessible through the communication network)
 - ☐ Modifications to settings and parameters
 - ☐ Counter resets
 - ☐ System faults
 - ☐ Fallback position
 - ☐ Thermal self-protection
 - ☐ Loss of time
 - ☐ Overrun of wear indicators
 - ☐ Test-kit connections
 - ☐ Etc.

Note: All the events are time stamped: time-stamping is activated as soon as time is set manually or by a supervisor. No external power supply module is required (max. drift of 1 hour per year).

Maintenance Indicators with COM Option Via Breaker Communication Module (BCM ULP)

A number of maintenance indicators may be called up on the screen to better plan for device maintenance:

- Contact wear
- Operation counter:
 - ☐ Cumulative total
 - ☐ Total since last reset.

Additional maintenance indicators are also available through the COM network, and can be used as an aid in troubleshooting:

- Highest current measured
- Number of test-kit connections
- Number of trips in operating mode and in test mode.

Additional Technical Characteristics

Protections and measurements

Measurement functions are independent of the protection functions. The high-accuracy measurement module operates independently of the protection module.

Simplicity and multi-language

Navigation from one display to another is intuitive. The six buttons on the keypad provide access to the menus and easy selection of values. When the setting cover is closed, the keypad may no longer be used to access the protection settings, but still provides access to the displays for measurements, histories, indicators, etc.

MicroLogic is also multi-language, including the following languages: English, Spanish, Portuguese, Russian, Chinese, French, German...

Intelligent measurement

Measurement-calculation mode:


- Energies are calculated on the basis of the instantaneous power values, in two manners:
 - ☐ The traditional mode where only positive (consumed) energies are considered
 - ☐ The signed mode where the positive (consumed) and negative (supplied) energies are considered separately
- Measurement functions implement the new "zero blind time" concept which consists in continuously measuring signals at a high sampling rate. The traditional "blind window" used to process samples no longer exists. This method ensures accurate energy calculations even for highly variable loads (welding machines, robots, etc.).

Always powered


All current-based protection functions require no auxiliary source. Voltage-based protection functions are connected to AC power via a voltage measurement input built into the circuit breaker.

Stored information

The fine setting adjustments, the last 100 events and the maintenance register remain in the control-unit memory even when power is lost.



Display of a tripping history




Display after tripping

A


Power Meter Functions

MicroLogic A/E/P Control Unit with COM Option via Breaker Communication Module (BCM ULP) and COM Ethernet Gateway


In addition to protection functions, MicroLogic A/E/P control units offer all the functions of Power Meter products as well as operating-assistance for the circuit breaker.




FDM121 display: navigation




FDM128 display: navigation




FDM121 display: current




FDM128 display: current




FDM121 display: power




FDM128 display: voltage



FDM121 display: consumption



FDM128 display: power



FDM128 display: consumption

Examples of measurement screens on the FDM121 display unit

MicroLogic A/E/P measurement functions are made possible by MicroLogic intelligence and the accuracy of the sensors. They are handled by a microprocessor that operates independent of protection functions.

Display

FDM121 Display Unit (One to One)

The FDM121 switchboard display unit can be connected to a COM option via Breaker Communication Module (BCM ULP) using a breaker ULP cord to display all measurements on a screen [1]. The result is a veritable 96 x 96 mm Power Meter. The FMD121 display unit requires a 24 V DC power supply. The COM option via Breaker Communication Module (BCM ULP) unit is supplied by the same power supply via the breaker ULP cord connecting it to the FDM121.

[1] See page A-28.

FDM128 Display Unit (One to Eight)

Using an IFE Ethernet interface for LV breakers.

For all FDM, in addition to the information displayed on the MicroLogic LCD, the FDM screen shows demand, power quality and maximeter/minimeter values along with histories and maintenance indicators.

Measurements

Instantaneous Rms Measurements

The MicroLogic continuously display the RMS value of the highest current of the three phases and neutral (Imax). The navigation buttons can be used to scroll through the main measurements.

In the event of a fault, the trip cause is displayed.

The MicroLogic A measures phase, neutral, ground fault currents.

The MicroLogic E offers voltage, power, Power Factor, measurements in addition to the measurements provided by MicroLogic A.

The MicroLogic P offer frequency, cos.φ in addition to the measurements provided by MicroLogic E.

Maximeters/Minimeters

Every instantaneous measurement provided by MicroLogic A or E can be associated with a maximeter/minimeter. The maximeters for the highest current of the 3 phases and neutral, the demand current and power can be reset via the FDM display unit or the communication system.

Energy Metering

The MicroLogic E/P also measures the energy consumed since the last reset of the meter. The active energy meter can be reset via MicroLogic keypad or the FDM display unit or the communication system.

Demand and Maximum Demand Values

MicroLogic E/P also calculates demand current and power values. These calculations can be made using a block or sliding interval that can be set from 5 to 60 minutes in steps of 1 minute. The window can be synchronized with a signal sent via the communication system. Whatever the calculation method, the calculated values can be recovered on a PC via Modbus communication.

Ordinary spreadsheet software can be used to provide trend curves and forecasts based on this data. They will provide a basis for load shedding and reconnection operations used to adjust consumption to the subscribed power.

Power Meter Functions

MicroLogic A/E/P Control Unit with COM Option via Breaker Communication Module (BCM ULP) and COM Ethernet Gateway



A

MicroLogic A/E/P Integrated Power Meter Functions			Type		Display	
			A/E	P	MicroLogic LCD	FDM display
Display of protection settings						
Pick-ups (A) and delays	All settings can be displayed	I _r , I _{tr} , I _{sd} , I _{tsd} , I _i , I _g , I _{tg}	A/E	P	●	-
Measurements						
Instantaneous Rms Measurements						
Currents (A)	Phases and neutral	I ₁ , I ₂ , I ₃ , I _N	A/E	P	●	●
	Average of phases	I _{avg} = (I ₁ + I ₂ + I ₃)/3	A/E	P	-	●
	Highest current of the 3 phases and neutral	I _{max} of I ₁ , I ₂ , I ₃ , I _N	A/E	P	●	●
	Ground fault (MicroLogic 6)	% I _g (pick-up setting)	A/E	P	●	●
	Current unbalance between phases	% I _{avg}	-/E	P	-	●
Voltages (V)	Phase-to-phase	V ₁₂ , V ₂₃ , V ₃₁	-/E	P	●	●
	Phase-to-neutral	V _{1N} , V _{2N} , V _{3N}	-/E	P	●	●
	Average of phase-to-phase voltages	V _{avg} = (V ₁₂ + V ₂₃ + V ₃₁)/3	-/E	P	-	●
	Average of phase-to-neutral voltages	V _{avg} = (V _{1N} + V _{2N} + V _{3N})/3	-/E	P	-	●
	Ph-Ph and Ph-N voltage unbalance	% V _{avg} and % V _{avg}	-/E	P	-	●
	Phase sequence	1-2-3, 1-3-2	-/-	P	●	● [3]
Frequency (Hz)	Power system	f	-/-	P	●	●
Power	Active (kW)	P, total	-/E	P	●	●
		P, per phase	-/E	P	● [2]	●
	Reactive (kVAR)	Q, total	-/E	P	●	●
		Q, per phase	-/-	P	●	●
	Apparent (kVA)	S, total	-/E	P	●	●
		S, per phase	-/-	P	●	●
	Power Factor	PF, total	-/E	P	●	●
		PF, per phase	-/-	P	●	●
	Cos.φ	Cos.φ, total	-/-	P	●	●
		Cos.φ, per phase	-/-	P	●	●
Maximeters/Minimeters						
	Associated with instantaneous rms measurements	Reset via FDM display unit and MicroLogic keypad	A/E	P	●	●
Energy Metering						
Energy	Active (kW), reactive (kVARh), apparent (kVAh)	Total since last reset	-/E	P	●	●
Demand and Maximum Demand Values						
Demand current (A)	Phases and neutral	Present value on the selected window	-/E	P	●	●
		Maximum demand since last reset	-/E	P	● [2]	●
Demand power	Active (kWh), reactive (kVAR), apparent (kVA)	Present value on the selected window	-/E	P	●	●
		Maximum demand since last reset	-/E	P	● [2]	●
		Adjustable from 5 to 60 minutes in 1 minute steps [1]	-/E	P	-	-

[1] Available via the communication system only.

[2] Available for MicroLogic P only.

[3] FDM121 only.

Operating-Assistance Functions

MicroLogic A/E/P Control Unit with COM Option via Breaker Communication Module (BCM ULP)

Histories

- Trip indications in clear text in a number of user-selectable languages.
- Time-stamping: date and time of trip.

Maintenance Indicators

MicroLogic control unit have indicators for, among others, the number of operating cycles, contact wear P, load profile and operating times (operating hours counter) of the MasterPact circuit breaker.

It is possible to assign an alarm to the operating cycle counter to plan maintenance.

The various indicators can be used together with the trip histories to analyse the level of stresses the device has been subjected to.

Management of Installed Devices

Each circuit breaker equipped with a COM option via Breaker Communication Module (BCM ULP) can be identified via the communication system:

- Serial number
- Firmware version
- Hardware version
- Device name assigned by the user.

This information together with the previously described indications provides a clear view of the installed devices.

MicroLogic A/E/P Operating Assistance Functions			Type		Display	
			A/E	P	MicroLogic LCD	FDM121/ FDM128 display
Operating assistance						
Trip History						
Trips	Cause of tripping	Ir, Isd, li, Ig, lAn	-/E	P		
Maintenance Indicators						
Counter	Mechanical cycles	Assignable to an alarm	A/E	P	-	
	Electrical cycles	Assignable to an alarm	A/E	P	-	
	Hours	Total operating time (hours) ^[1]	A/E	P	-	-
Indicator	Contact wear	%	-/-	P	-	
Load profile	Hours at different load levels	% of hours in four current ranges: - 0-49 % In - 50-79 % In - 80-89 % In - ≥ 90 % In	A/E	P	-	

[1] Also available via the communication system.

Additional Technical Characteristics

Contact wear

Each time ComPacT opens, the MicroLogic P trip unit measures the interrupted current and increments the contact-wear indicator as a function of the interrupted current, according to test results stored in memory. Breaking under normal load conditions results in a very slight increment. The indicator value may be read on the FDM121 display. It provides an estimation of contact wear calculated on the basis of the cumulative forces affecting the circuit breaker. When the indicator reaches 100 %, it is advised to inspect the circuit breaker to ensure the availability of the protected equipment.

Circuit breaker load profile

MicroLogic A/E/P calculates the load profile of the circuit breaker protecting a load circuit. The profile indicates the percentage of the total operating time at four current levels (% of breaker In):

- 0 to 49 % In
- 50 to 79 % In
- 80 to 89 % In
- ≥ 90 % In.

This information can be used to optimize use of the protected equipment or to plan ahead for extensions.

FDM121 Switchboard-Display Functions

MicroLogic A/E/P Control Unit with COM Option via Breaker Communication Module (BCM ULP)

A

MicroLogic measurement capabilities come into full play with the FDM121 switchboard display. It connects to COM option via Breaker Communication Module (BCM ULP) via a breaker ULP cord and displays MicroLogic information. The result is a true integrated unit combining a circuit breaker and a Power Meter. Additional operating assistance functions can also be displayed.

FDM121 Switchboard Display

An FDM121 switchboard display unit can be connected to a ULP IMU using a prefabricated cord to display all measurements, alarms, histories and event tables, maintenance indicators, management of installed devices on a screen. The result is a veritable 96 x 96 mm Power Meter.

The FMD121 display unit requires a 24 V DC power supply.

The FDM121 is a switchboard display unit that can be integrated in the ComPacT NSX100 to 630 A, PowerPact H/J/L/P/R, ComPacT NS or MasterPact systems. It uses the sensors and processing capacity of the MicroLogic trip unit. It is easy to use and requires no special software or settings. It is immediately operational when connected to the ComPacT NSX by a simple cord.

Also, it provides monitoring and control with the use of the I/O application module, the motor mechanism module, or the Breaker Status module.

The FDM121 is a large display, but requires very little depth. The anti-glare graphic screen is backlit for very easy reading even under poor ambient lighting and at sharp angles.

Display of MicroLogic Measurements and Alarms

The FDM121 displays MicroLogic 5/6 measurements, alarms and operating information. It cannot be used to modify the protection settings. Measurements may be easily accessed via a menu. All user-defined alarms are automatically displayed. The display mode depends on the priority level selected during alarm set-up:

- High priority: a pop-up window displays the time-stamped description of the alarm and the orange LED flashes
- Medium priority: the orange "Alarm" LED goes steady on
- Low priority: no display on the screen.

All faults resulting in a trip automatically produce a high-priority alarm, without any special settings required. In all cases, the alarm history is updated. MicroLogic registers the information in its non-volatile memory in the event of an FDM121 power failure.

Status Indications and Remote Control

When the circuit breaker is equipped with the Breaker Status Module, the FDM121 display can also be used to view circuit breaker status conditions:

- O/F: ON/OFF
- SD: trip indication
- SDE: Fault-trip indication (overload, short-circuit, ground fault).

When the circuit breaker system is equipped with the I/O application module, the FDM121 can monitor and control:

- Cradle management
- Circuit breaker operation
- Light and load control
- Custom application.

When the circuit breaker system is equipped with the motor mechanism module, the FDM121 offers remote closing and opening control.

Main Characteristics

- 96 x 96 x 30 mm screen requiring 10 mm behind the door (or 20 mm when the 24 V power supply connector is used).
- White backlighting.
- Wide viewing angle: vertical $\pm 60^\circ$, horizontal $\pm 30^\circ$.
- High resolution: excellent reading of graphic symbols.
- Alarm LED: flashing orange for alarm pick-up, steady orange after operator reset if alarm condition persists.
- Operating temperature range -10°C to $+55^\circ\text{C}$.
- CE/UL/CSA marking (pending).
- 24 V DC power supply, with tolerances 24 V -20% (19.2 V) to 24 V $+10\%$ (26.4 V). When the FDM121 is connected to the communication network, the 24 V DC can be supplied by the communication system wiring system.
- Consumption 40 mA.

Mounting

The FDM121 is easily installed in a switchboard.

- Standard door cut-out 92 x 92 mm.
- Attached using clips.

To avoid a cut-out in the door, an accessory is available for surface mounting by drilling only two 22 mm diameter holes. The FDM121 degree of protection is IP54 in front. IP54 is maintained after switchboard mounting by using the supplied gasket during installation.

Connection

The FDM121 is equipped with:


- A 24 V DC terminal block:
 - Plug-in type with 2 wire inputs per point for easy daisy-chaining
 - Power supply range of 24 V DC -20% (19.2 V) to 24 V DC $+10\%$ (26.4 V).

A 24 V DC type auxiliary power supply must be connected to a single point on the ULP system. The FDM121 display unit has a 2-point screw connector on the rear panel of the module for this purpose. The ULP module to which the auxiliary power supply is connected distributes the supply via the ULP cable to all the ULP modules connected to the system and therefore also to MicroLogic.

- Two RJ45 jacks.



FDM121 display




Surface mount accessory




Connection with FDM121 display unit

FDM121 Switchboard-Display Functions


MicroLogic A/E/P Control Unit with COM Option via Breaker Communication Module (BCM ULP)




- 1 Escape
- 2 Down
- 3 Ok
- 4 Up
- 5 Context
- 6 Alarm LED




Product identification



Metering: meter



Metering: sub-menu.



Services

The MicroLogic connects to the internal communication terminal block on the MasterPact via the breaker ULP cord. Connection to one of the RJ45 connectors on the FDM121 automatically establishes communication between the MicroLogic and the FDM121 and supplies power to the MicroLogic measurement functions. When the second connector is not used, it must be fitted with a line terminator.

Navigation

Five buttons are used for intuitive and fast navigation.

The "Context" button may be used to select the type of display (digital, bargraph, analogue).

The user can select the display language (Chinese, English, French, German, Italian, Portuguese, Spanish, etc.).

Screens

Main menu

When powered up, the FDM121 screen automatically displays the ON/OFF status of the device.



When not in use, the screen is not backlit. Backlighting can be activated by pressing one of the buttons. It goes off after 3 minutes.


Fast access to main information

- "Quick view" provides access to five screens that display a summary of operating information (I, U, f, P, E, THD, circuit breaker On/Off).

Access to detailed information

- "Metering" can be used to display the measurement data (I, U-V, f, P, Q, S, E, THD, PF) with the corresponding min/max values.
- Alarms displays active alarms and the alarm history.
- Services provides access to the operation counters, energy and maximeter reset
- Function, maintenance indicators, identification of modules connected to the internal bus and FDM121 internal settings (language, contrast, etc.).

Communication Components and FDM121 Connections



- A Modbus network
- B Ethernet network
- C Breaker ULP cord

- D FDM121 display
- E ULP termination
- F ULP cable

Connections

- ComPacT NS is connected to the ULP devices (FDM121 display, IFM, IFE or I/O application module) unit via the breaker ULP cord.
 - Cord available in three lengths: 0.35 m, 1.3 m, 3 m and 5 m.
 - Lengths up to 10 m possible using extensions.

FDM128 Switchboard-Display Functions

MicroLogic A/E/P Control Unit with COM Ethernet Gateway

A

MicroLogic measurement capabilities come into full play with the FDM128 switchboard display. It connects to Ethernet communication via RJ45 port and displays MicroLogic information. The result is a true integrated unit combining a circuit breaker and a Power Meter. Additional operating assistance functions can also be displayed.

FDM128 Switchboard Display

The FDM128 is an intelligent Ethernet display. It collects the data from up to 8 devices via Ethernet network. The FDM128 switchboard display unit can be connected to a MicroLogic COM option (BCM ULP via IFE). It uses the sensors and processing capacity of the MicroLogic control unit. It is easy to use and requires no special software or settings.

The FDM128 is a large display, but requires very little depth. The anti-glare graphic screen is backlit for very easy reading even under poor ambient lighting and at sharp angles.

FDM128 switchboard display is designed to manage up to 8 devices (MasterPact, ComPacT NS, ComPacT NSX or Smartlink).

Display of MicroLogic Measurements and Trips

The FDM128 displays MicroLogic A/E/P measurements, trips and operating information.

It cannot be used to modify the protection settings.

Measurements may be easily accessed via a menu.

Trips are automatically displayed.

A pop-up window displays the time-stamped description of the trip.

Status Indications

When the circuit breaker is equipped with the Breaker Status Command Module (BSCM) and NSX cord, the FDM128 display can also be used to view circuit breaker status conditions:

- O/F: ON/OFF
- SDE: Fault-trip indication (overload, short-circuit, ground fault)
- CE, CD, CT cradle management with I/O application module.

Remote Control

When the circuit breaker is equipped with the COM option via Breaker Communication Module (BCM ULP) (including its kit for connection to communication voltage releases), the FDM128 display can also be used to control (open/close) the circuit breaker.

Two operating mode are available:

- Local mode: open/close commands are enabled from FDM128 while disabled from communication network
- Remote mode: open/close commands are disabled from FDM128 while enabled from communication network.

Main Characteristics

- 115.2 x 86.4 mm with 5.7" QVGA display 320 x 240 pixels.
- Color TFT LCD, LED backlight.
- Wide viewing angle: vertical $\pm 80^\circ$, horizontal $\pm 70^\circ$.
- High resolution: excellent reading of graphic symbols.
- Operating temperature range -10°C to $+55^\circ\text{C}$.
- CE/UL/CSA marking (pending).
- 24 V DC power supply, with tolerances 24 V (limit 20.4 - 28.8 V DC).
- Consumption ≤ 6.8 W.

Mounting

The FDM128 is easily installed in a switchboard.

- Standard door hole $\varnothing 22$ mm.

The FDM128 degree of protection is IP65 in front and IP54.

Connection

The FDM128 is equipped with:

- A 24 V DC terminal block:
 - Power supply range of 24 V DC (limit 20.4 - 28.8 V DC). The FDM128 display unit has a 2-point screw connector on the rear panel of the module for this purpose.
- One RJ45 Ethernet jack.

The MicroLogic connects to the internal communication terminal block on the MasterPact via the breaker ULP cord and Ethernet connection through IFE.



FDM128 display




Surface mount accessory




FDM128 Switchboard-Display Functions

MicroLogic A/E/P Control Unit with COM Ethernet Gateway



Metering: meter



Services

Navigation

Touch screen is used for intuitive and fast navigation.

The user can select the display language (Chinese, English, French, German, Italian, Portuguese, Spanish, etc.).

Screens

Main menu



Quick view



Alarms



Metering



Maintenance



Control

When not in use, the screen is automatically shifted to low back-lighting.

Fast access to main information

- "Quick view" provides access to five screens that display a summary of operating information (I, U, f, P, E, THD, circuit breaker On/Off).

Access to detailed information

- "Metering" can be used to display the measurement data (I, U-V, f, P, Q, S, E, THD, PF) with the corresponding min/max values.
- Alarms displays the trip history.
- Services provides access to the operation counters, energy and maximeter reset function, maintenance indicators, identification of modules connected to the internal bus and FDM128 internal settings (language, contrast, etc.).

Protection of Distribution Systems

MicroLogic Control Units for ComPacT NS630b to 3200

External Sensors

External sensor for earth-fault and neutral protection

The sensors, used with the 3P circuit breakers, are installed on the neutral conductor for:

- Neutral protection (with MicroLogic P)
- Residual type earth-fault protection (with MicroLogic A, E and P).

The rating of the sensor (CT) has to be compatible with the rating of the circuit breaker:

- NS630b to 1600 A - 400/1600 CT
- NS1600b to 3200 A - 1000/4000 CT.

Rectangular sensor for earth-leakage protection

The sensor is installed around the busbars (phases + neutral) to detect the zero-phase sequence current required for the earth-leakage protection. Rectangular sensors are available in two sizes.

Inside dimensions (mm)

- 280 x 115 up to 1600 A for ComPacT NS630b to 1600 A (L1)
- 470 x 160 up to 3200 A for ComPacT NS1600b to 3200 A (L2).

External sensor for source ground return protection

The sensor is installed around the connection of the transformer neutral point to earth and connects to the MicroLogic 6.0 control unit via an MDGF module to provide the source ground return (SGR) protection.

Long-Time Rating Plug

Four interchangeable plugs may be used to limit the long-time threshold setting range for higher accuracy.

The time delay settings indicated on the plugs are for an overload of 6 Ir (for further details, see the characteristics on [page A-13](#) and [page A-17](#)).

As standard, control units are equipped with the 0.4 to 1 plug.

Setting ranges

Standard	Ir = In x...	0.4	0.5	0.6	0.7	0.8	0.9	0.95	0.98	1
Low-setting	Ir = In x...	0.4	0.45	0.50	0.55	0.60	0.65	0.70	0.75	0.8
High-setting	Ir = In x...	0.80	0.82	0.85	0.88	0.90	0.92	0.95	0.98	1
Off plug	No long-time protection (Ir = In for Isd setting)									

Important: Long-time rating plugs must always be removed before carrying out insulation or dielectric withstand tests.

Battery Module

The battery module maintains display operation and communication with the supervisor if the power supply to the MicroLogic control unit is interrupted.

It is installed in series between the MicroLogic control unit and the AD module.

Characteristics

- Battery run-time: 4 hours (approximately).
- Mounted on vertical backplate or symmetrical rail.

Spare Parts

Lead-seal covers

A lead-seal cover controls access to the adjustment dials.

When the cover is closed:

- It is impossible to modify settings using the keypad unless the settings lockout pin on the cover is removed
- The test connector remains accessible
- The test button for the earth-fault and earth-leakage protection function remains accessible.

Characteristics


- Transparent cover for basic MicroLogic and MicroLogic A, E control units.
- Non-transparent cover for MicroLogic P control units.

Spare battery

A battery supplies power to the LEDs identifying the tripping causes. Battery service life is approximately ten years.

A test button on the front of the control unit is used to check the battery condition.

The battery may be replaced on site when discharged.




External sensor (CT)



External sensor for earth leakage protection



Battery module



Lead-seal cover

Service Interface and Power Supplies



BTM (Breaker Test Module)



External 24 V DC power supply module (AD)

Service Interface

The Service Interface is a portable instrument designed for field testing. The Service Interface is to be used together with EPC software for testing and configuration of MicroLogic trip units mounted in the following low voltage circuit breakers:

- ComPacT NS 630b-1600 circuit breakers
- ComPacT NS 1600b-3200 circuit breakers
- PowerPacT P- and R- frame circuit breakers
- MasterPact NT/NW circuit breakers

EcoStruxure Power Commission (EPC) is a global software with test functions features for testing the circuit breakers and communication accessories through the Service Interface.

EPC software allows you to perform the following actions on communicating MicroLogic trip unit through the Service Interface:

1. Automatic trip curve tests
2. Device check up (Force trip test)
3. Zone-selective interlocking test (ZSI)
4. Preparation for primary injection tests

The main features of Service Interface are:

- Single connector interface for testing different circuit breakers.
- 24 Vdc at 120 mA power output for external devices.
- 12 kV safety impulse protection between user interface and test port.
- Magnet mountable.
- EPC user interface for test and configuration.

External 24 V DC Power-Supply Module (AD)

The external power-supply module makes it possible:

- To use the display even if the circuit breaker is open or not supplied (for the exact conditions of use, see the "electrical diagrams" part of this catalog)
- To display fault currents after tripping
- To modify settings when the circuit breaker is open (OFF position)

An external 24 V DC power supply is required for installation with communication, whatever the type of trip unit.

This module powers both the control unit and the M2C programmable contacts.

Proper operation of MicroLogic control unit is not guaranteed when other non-qualified power supplies are used.

If the COM option is used, a second dedicated power supply shall be used.

Characteristics

- Power supply AC-to-DC or DC-to-DC
- Output voltage: 24 V DC $\pm 5\%$.
- Output current: 1 A.
- DIN rail or mounting plate fixing with Acti9 form factor
- Conducted emissions power line: class B per EN 61000-6-3.

24 V DC Universal Phaseo™ ABL8 Power Supplies

The Universal Phaseo ABL8 RPS 24050 and ABL8 RPS 24030 power supplies can be connected phase-to-neutral or phase-to-phase.

They deliver a voltage that is precise to 3 %, whatever the load and whatever the value of the AC supply, within the ranges 85 to 132 V AC and 170 to 550 V AC.

The Universal Phaseo ABL8 powers:

- Circuit breaker communication module and interface.

Characteristics

- Power supply AC-to-DC.
- Network frequency: 50/60 Hz (± 5 %).
- Output voltage: 24 V DC ± 3 %.
- Output current: 3 or 5 A.
- DIN rail or mounting plate fixing.
- Conducted emissions power line: class B per EN 61000-6-3.

Sufficient clearance around the universal range Phaseo power supplies must be taken for assisting the unit cooling:

- 50 mm above and below
- 10 mm on the side.

	ABL8RPS●●●●	Module AD
Over Voltage Category	Cat I per VDE 0106-1	Cat IV per IEC 62477-1 (AC model) Cat III per IEC 62477-1 (DC model) Cat III per UL 61010-1
Degree of pollution as per IEC 60664-1	2	3
Input supply voltage AC	100...120 V AC and 200...500 V AC	110/130 or 200/240 V AC
Input supply voltage DC	N/A	24/30 or 48/60 or 100/125 V DC
Dielectric	4 kV rms - 1 mn.	3 kV rms - 1 mn.
		(110/130 V AC and 200/240 V AC model)
		3 kV rms - 1 mn. (110/125 V DC model)
		2 kV rms - 1 mn. (24/30 V DC and 48/60 V DC model)
Input/Ground	3.5 kV rms - 1 mn.	3 kV rms - 1 mn.
Output /Ground	0,5 kV rms - 1 mn.	1.5 kV rms - 1 mn.
Temperature	50 °C 60 °C with 80 % of the rated current maximum	70 °C
Output current	3 A (ABL8RPS24030) 5 A (ABL8RPS24050)	1 A
Inrush current for 2 ms	< 30 A	< 20 A
Ripple	200 mV peak-peak	200 mV peak-peak
Output voltage limits	24 to 28.8 V DC	22.8 to 25.2 V DC
Protection degree	IP20	IP4x front face/IP2x terminals/IP3x other

Note: For the applications requiring an over voltage category higher than 2, a surge arrester shall be associated to ABL8 RPS power supplies. The iQuick-PRD type 2 surge arrester is recommended.



ABL8 RPS power supply

PF106349SE_ABL8RPS24050.eps

A

A










Ethernet has become the universal link between switchboards, computers and communication devices inside the building. The large amount of information which can be transferred makes the connection of Enerlin'X digital system to hosted web services of Schneider Electric a reality. More advantages are offered to integrators thanks to configuration web pages available remotely or on the local Ethernet network.

The diagram illustrates a smart switchboard system architecture. It features a Main Switchboard (top left) and a Final distribution switchboard (bottom left), both equipped with ComPacT NS + MicroLogic and ComPacT + MicroLogic components. The Main Switchboard is connected to the Final distribution switchboard via an Ethernet network (green line). An Energy Server (A) is connected to the Ethernet network and communicates with the Internet (cloud icon). The Final distribution switchboard is connected to the Ethernet network via a Sigfox module (G). The diagram also shows two physical switchboard units on the right, labeled DB406880-55 and DB406888-302 eps. A legend at the bottom identifies the connection types: Ethernet (green line), Modbus (black line), ULP (grey line), Hard wired (blue line), and Sigfox Wireless IEEE 802.15.4 (green wireless icon).

Functions and Characteristics

Enerlin'X Digital System

Overview

Enerlin'X digital devices and displays								
		Name	Function	Port (to device)	(to server)	Inputs	Outputs	Cial. Ref.
A		Com'X 510 24 V DC + PoE	Energy server + Ethernet Gateway	Ethernet Modbus Smartlink SI B, Zigbee (to wireless meters)	Ethernet cable + WiFi	64 devices: 6 binary 2 analog 32 Modbus devices + other Ethernet devices (Modbus TCP)	-	EBX510
B		FDM128	Ethernet LCD color touch screen	-	Ethernet		-	LV434128
C		FDM121	LCD display for circuit breaker	ULP	-	1 circuit breaker	-	TRV00121
D		IFE Switchboard server	Switchboard server	Modbus Smartlink SI B & ULP	Ethernet	20 circuit breakers	-	LV434002
		IFE interface	Ethernet interface for circuit breakers	ULP	Ethernet	1 circuit breaker	-	LV434001
E		IFM	Modbus interface for circuit breaker	ULP	Modbus Smartlink SI B	1 circuit breaker	-	LV434000
F		I/O	Input/Output application module for circuit breaker	ULP	ULP	6 binary 1 analog (PT100 sensor)	3	LV434063
G		Smartlink SI B Ethernet wireless	Ethernet server for I/O and Modbus Smartlink SI B devices	Modbus Smartlink SI B & Wireless to PowerTag	Ethernet	14 binary 2 analog	7	A9XMZA08
H		Smartlink Modbus Smartlink SI B	Modbus interface with Input/Output functions	-	Modbus Smartlink SI B	22 binary	11	A9XMSB11
I		HeatTag	Detection of overheating cables	-	-	-	-	SMT10020

> EcoStruxure Power Connected Products Catalog



LVCATENLX_EN

Ethernet Gateway or Interface: routes an internal traffic (ULP or other protocols) to the Internet, the outgoing messages are coded with Modbus TCP/IP protocol.

Server (Switchboard, Energy): routes the internal traffic to the Internet. Other complementary functions such as data logging and storage. Provides devices status and energy trends on internal web pages...

PowerLogic™ HeatTag: HeatTag is a smart sensor for early detection of overheating wire connections or overheating cables. HeatTag helps prevent electrical switchboards from being damaged, by analyzing gas and particles in the air and sending alerts before any smoke or insulator browning.

Note: For more information, see [Configuration & commissioning guide of connected devices & software - New buildings](#)

Communication


Communication Wiring System

A

Wiring system ULP

The wiring system is designed for low-voltage power switchboards. Installation requires no tools or special skills. The prefabricated wiring ensures both data transmission (Modbus protocol) and 24 V DC power distribution for the communications modules on the MicroLogic control units.

DB43925.ppt



A Breaker Communication Module with ULP port (BCM ULP)

B MicroLogic control unit

C Breaker ULP cord	0.35 m	LV434195
	1.3 m	LV434196
	3 m	LV434197
	5 m	LV434198

D Modbus cable

E Ethernet cable

F FDM121: Front Display Module TRV00121

G FDM128: Front Display Module LV434128

H Smartlink Modbus Smartlink SI B A9XMSB11

I Acti9

J ULP line terminators TRV00880

K I/O (Input/Output) application module LV434063

L IFE: Ethernet interface

M External 24 V DC power supply module

N IFM: Modbus-SL interface

O Com'X 210

P ULP cable

Q NSX cord

R HeatTag

S PowerTag Link

LV434001 or LV434002

LV434000

0.3 m	TRV00803
0.6 m	TRV00806
1 m	TRV00810
2 m	TRV00820
3 m	TRV00830
5 m	TRV00850
0.35 m	LV434200
1.3 m	LV434201
3 m	LV434202

Ethernet

Modbus

ULP

24 V DC

Communication

Overview of Functions

Four Functional Levels

The ComPacT can be integrated into a Modbus communication environment. There are four possible functional levels that can be combined.

	Switch-Disconnectors	Circuit Breaker
Status indications		
ON/OFF (O/F)	●	S A E P
Spring charged CH	●	S A E P
Ready to close	●	S A E P
Fault-trip SDE	●	S A E P
Connected/disconnected/test position	●	S A E P
CE/CD/CT (I/O application module only)		S A E P
Controls		
MX open release	●	S A E P
Closing release	●	S A E P
Measurements		
Instantaneous measurement information	●	A E P
Averaged measurement information	●	E P
Maximeter/minimeter	●	A E P
Energy metering	●	E P
Demand for current and power	●	E P
Power quality	●	
Operating assistance		
Protection and alarm settings		A E P
Histories		A E P
Time stamped event tables		A E P
Maintenance indicators		A E P

Modbus principle

The Modbus RS 485 (RTU protocol) system is an open bus on which communicating Modbus devices (ComPacT NS with Modbus COM, PowerLogic PM700, PM800, Sepam, Vigilohm, ComPacT NSX, etc.) are installed. All types of PLCs and microcomputers may be connected to the bus.

Addresses

The Modbus communication parameters (address, baud rate, parity) are entered using the keypad on the MicroLogic A, E, P. For a switch-disconnector, it is necessary to use the EcoStruxure Asset Advisor or RSU (Remote Setting Utility) MicroLogic utility.

Number of devices

The maximum number of devices that may be connected to the Modbus bus depends on the type of device (ComPacT with Modbus COM, PowerLogic, Sepam, Vigilohm, ComPacT NSX, etc.), the baud rate (19200 is recommended), the volume of data exchanged and the desired response time. The RS 485 physical layer offers up to 32 connection points on the bus (1 master, 31 slaves).

A fixed device requires only one connection point (communication module on the device).

A withdrawable device uses two connection points (communication modules on the device and on the chassis).

The number is limited to 31 fixed devices or 15 withdrawable devices.

Length of bus

The maximum recommended length for the Modbus bus is 1200 meters.

Bus power source

A 24 V DC power supply is required (less than 20 % ripple, insulation class II).

Ethernet principle

Ethernet is a data link and physical layer protocol defined by IEEE 802.10 and 100 Mbps specifications that connects computer or other Ethernet devices. Ethernet is an asynchronous Carrier Sense Multiple Access with Collision detection (referred as CSMA/CD) protocol. Carrier Sense means that the hosts can detect whether the medium (coaxial cable) is idle or busy. Multiple Access means that multiple hosts can be connected to the common medium. Collision Detection means a host detects whether its transmission has collided with the transmission of another host (or hosts). IFE Ethernet interface can be connected to a PC or a laptop over Ethernet. The maximum length of Ethernet cable is 100 meters. IFE Ethernet interface + gateway provides a Modbus TCP/IP gateway over Ethernet to enable Modbus TCP communication from a Modbus TCP master to any Modbus slave devices connected to it. The maximum active Modbus TCP client connection is twelve. IFE Ethernet interface has an embedded web server (web page). The Modbus RS 485 (RTU protocol) system is an open bus on which communicating Modbus devices (ComPacT NS with Modbus COM, Power Meter PM700, PM800, Sepam, Vigilohm, ComPacT NSX, etc.) are installed. All types of PLCs and microcomputers may be connected to the bus.



Basic: MicroLogic without measurement.

A: MicroLogic with ammeter

E: MicroLogic "Energy"

P: MicroLogic "Power"


Note: See the description of the MicroLogic control units for further details on protection and alarms, measurements, waveform capture, histories, logs and maintenance indicators.

Communication

COM Option in ComPacT

A

All the ComPacT devices can be fitted with the communication function thanks to the COM option. ComPacT uses the Ethernet or Modbus communications protocol for full compatibility with the supervision management systems. Eco COM is limited to the transmission of metering data and status. It is not used to communicate controls.



BCM ULP



I/O application module

For fixed devices, the COM option is made up of:

- A BCM ULP module, installed behind the MicroLogic control unit and supplied with its set of sensors (OF, SDE, PF and CH micro switches) its kit for connection to communicating voltage releases and its COM terminal block (inputs E1 to E6)
- IFM, this module required for connection to the network, contains the Modbus address (1 to 99) declared by the user via the two dials in front. It automatically adapts (baud rate, parity) to the Modbus network in which it is installed.

Or

- IFE, the Ethernet interface for LV circuit breaker enables an intelligent modular unit (IMU), for example a ComPacT NS circuit breaker to be connected to an Ethernet network. Each circuit breaker has its own IFE and a corresponding IP address.

For withdrawable devices, the COM option is made up of:

- A BCM ULP module, installed behind the MicroLogic control unit and supplied with its set of sensors (OF, SDE, PF and CH micro switches) its kit for connection to communicating voltage releases and its COM terminal block (inputs E1 to E6).
- IFM, this module required for connection to the network, contains the Modbus address (1 to 99) declared by the user via the two dials in front. It automatically adapts (baud rate, parity) to the Modbus network in which it is installed.

Or

- IFE, the Ethernet interface for LV circuit breaker enables an intelligent modular unit (IMU), for example a ComPacT NS circuit breaker to be connected to an Ethernet network. Each circuit breaker has its own IFE and a corresponding IP address.
- I/O (Input/Output) application module for LV breaker, the I/O application module is delivered with withdrawable devices ordered with the COM option, for cradle management. It must be installed on a DIN rail near the device, and connected to the ULP system and to the position contacts (CD, CT, CE) that transmit the position of the device in the cradle.

BCM ULP Module

This module is independent of the control unit. It receives and transmits information on the communication network. An infra-red link transmits data between the control unit and the communication module.

Consumption: 30 mA, 24 V.

XF and MX1 Communicating Voltage Releases

The XF and MX1 communicating voltage releases are equipped for connection to the "device" communication module.


The remote-tripping function (MX2 or MN) are independent of the communication option. They are not equipped for connection to the "device" communication module.

Functions and Characteristics

Communication

Communication Architecture

A



Functions and Characteristics

IFE Ethernet Interface


A



IFE interface, ref.: LV434001



IFE interface + gateway, ref.: LV434002



IFE Interface, IFE Interface + Gateway Description

Introduction

The IFE interface and IFE interface + gateway enable LV circuit breakers as MasterPact, ComPact NSX or PowerPact to be connected to an Ethernet network.

IFE Interface: Ref. LV434001

Provides an Ethernet access to a single LV circuit breaker.

Function

Interface - one circuit breaker is connected to the IFE interface via its ULP port.

IFE Interface + Gateway: Ref. LV434002

Provides an Ethernet access to one or several LV circuit breakers.

Functions

- Interface - one circuit breaker is connected to the IFE interface via its ULP port.
- Gateway: several circuit breakers on a Modbus network are connected via The IFE interface + gateway master Modbus port.

IFE Interface, IFE Interface + Gateway Features

- Dual 10/100 Mbps Ethernet port for simple daisy chain connection.
- Device profile web service for discovery of the IFE interface, IFE interface + gateway on the LAN.
- ULP compliant for localization of the IFE interface in the switchboard.
- Ethernet interface for ComPact, MasterPact and PowerPact circuit breakers.
- Gateway for Modbus-SL connected devices (IFE interface + gateway only).
- Embedded set-up web pages.
- Embedded monitoring web pages.
- Embedded control web pages.
- Built-in e-mail alarm notification.

Mounting

The IFE interface, IFE interface + gateway are DIN rail mounting devices. A stacking accessory enables the user to connect several IFMs (ULP to Modbus interfaces) to an IFE interface + gateway without additional wiring.

24 V DC power supply

The IFE interface, IFE interface + gateway must always be supplied with 24 V DC. The IFMs stacked to an IFE interface + gateway are supplied by the IFE interface + gateway, thus it is not necessary to supply them separately. It is recommended to use an UL listed and recognized limited voltage/limited current or a class 2 power supply with a 24 V DC, 3 A maximum.

IFE Interface, IFE Interface + Gateway Firmware Update

The firmware can be updated using:

- FTP
- EcoStruxure Power Commission software.

Required circuit breaker communication modules

The connection to IFE interface or IFE interface + gateway requires a communication module embedded into the circuit breaker:

- ComPact NS: BCM ULP communication module.
- Withdrawable ComPact NS: BCM ULP and its respective I/O (Input/Output) application module. All connection configurations for ComPact NS require the breaker ULP cord. The insulated NSX cord is mandatory for system voltages greater than 480 V AC. When the second ULP RJ45 connector is not used, close it with a ULP terminator (TRV00880).

Network communication interface

Characteristic		Value
Type of interface module	Modbus RS485	Modbus RTU, RS485 serial connection
		Modbus TCP/IP Ethernet
Transmission	Ethernet	Transfer rate: 9,600...19,200 Baud
		Medium Double shielded twisted pair Impedance 120 Ω
Structure	Type	Modbus, Ethernet
	Method	Master/Slave
Device type	Modbus	Master
	Ethernet	Server
Turnaround time	Modbus	10 ms
	Ethernet	1 ms
Maximum length of cable	Modbus	1000 m
	Ethernet	100 m
Type of bus connector	Modbus	4-pin connector
	Ethernet	RJ45 (Shielded)

General Characteristics

Environmental characteristics

Conforming to standards	UL 508, UL 60950, IEC 60950, 60947-6-2
Certification	cULUs, GOST, FCC, CE
Ambient temperature	-20 to +70 °C (-4 to +158 °F)
Relative humidity	5–85 %
Level of pollution	Level 3
Flame resistance	ULV0

Mechanical characteristics

Shock resistance	1000 m/s ²
Resistance to sinusoidal vibrations	-5 Hz < f < 8.4 Hz

Electrical characteristics

Resistance to electromagnetic discharge	Conforming to IEC/EN 61000-4-3
Immunity to radiated fields	10 V/m
Immunity to surges	Conforming to IEC/EN 61000-4-5
Consumption	120 mA at 24 V input

Physical characteristics

Dimensions	72 x 105 x 71 mm (2.83 x 4.13 x 2.79 in.)
Mounting	DIN rail
Weight	182.5 g (0.41 lb)
Degree of protection of the installed IO	<ul style="list-style-type: none"> On the front panel (wall mounted enclosure): IP4x Connectors: IP2x Other parts: IP3x
Connections	Screw type terminal blocks

Technical characteristics - 24 V DC power supply

Power supply type	Regulated switch type
Rated power	72 W
Input voltage	100–120 V AC for single phase
	200–500 V AC phase-to-phase
PFC filter	With IEC 61000-3-2
Output voltage	24 V DC
Power supply out current	3 A

Note: It is recommended to use an UL listed/UL listed recognized limited voltage/Limited current or a class 2 power supply with a 24 V DC, 3 A maximum.

IFE Web Page Description

Monitoring web page

Real time data 67	○
Device logging	○

Control web page

Single device control	○
-----------------------	---

Diagnostics web page


Statistics	○
Device information	○
IMU information	○
Read device registers	○
Communication check	○

Maintenance web page

Maintenance log	○
Maintenance counters	○

Setup web page

Device localization/name	○
Ethernet configuration (dual port)	○
IP configuration	○
Modbus TCP/IP filtering	○
Serial port	○
Date and time	○
E-mail server configuration	○
Alarms to be e-mailed	○
Device list	○
Device logging	○
Device log export	○
SNMP parameters	○
Documentation links	○
Preferences	○
Advanced services control	○
User accounts	○
Web page access	○



- A** Ethernet 1 and Ethernet 2 communication port.
- B** 24 V DC power supply terminal block
- C** Ethernet communication LEDs:
yellow: 10 Mb
green: 100 Mb
- D** Module status LED:
steady off: no power
steady green: device operational
steady red: major fault
flashing green: standby
flashing red: minor fault
flashing green/red: self-test
- E** Network status LED:
steady off: no power/no valid IP address
steady green: connected, valid IP address
steady orange: default IP address
steady red: duplicated IP address
flashing green/red: self-test
- F** Sealable transparent cover
- G** QR code to product information.
- H** ULP status LED
- I** Test button (with cover closed).
- J** Locking pad
- K** Modbus traffic status LED (LV434002 only)
- L** Device name label
- M** ULP ports

IFM Modbus Communication Interface

A



PB119111.eps

IFM Modbus communication interface
Ref.: LV434000

Function

IFM - Modbus communication interface - is required for connecting MasterPact or ComPact NS and NSX to Modbus network whenever the circuit breaker has an ULP port (Universal Logic Plug). The port is available on BCM ULP for MasterPact range and BSCM module for ComPact range.

Note: IFM is defined as an IMU (Intelligent Modular Unit) in the ULP connection System documentation.

Once connected to IFM, the circuit breaker is considered as a slave by the Modbus master. Its electrical values, alarm status, open/close signals can be monitored or controlled by a Programmable Logic Controller or any other system.

Characteristics

ULP Port

2 RJ45 sockets, internal parallel wiring.

- Connection of a single circuit breaker (eventually via its I/O application module).
- An ULP line terminator or FDM121 display unit must be connected to the second RJ45 ULP socket.

The RJ45 sockets deliver a 24 V DC supply fed from the Modbus socket. Built-in test function, for checking the correct connection to the circuit breaker and FDM121 display unit.

Modbus Slave Port

- Modbus SL RJ45 port - RJ45 connector ensures fast and reliable wiring.
- Lateral socket, for Din-rail stackable connector.

Both top and lateral sockets are internally parallel wired.

- Multiple IFM can be stacked, thus sharing a common power supply and Modbus line without individual wiring.


- On the front face:

- Modbus address setting (1 to 99): 2 coded rotary switches
- Modbus locking pad: enables or disable the circuit breaker remote control And modification of IFM parameters.

- Self adjusting communication format (Baud rate, parity).

24 V DC Power Supply

- Screw clamp terminal block
 - High electrical insulation between Modbus and 24 V DC connectors + separated lines ensure improved communication robustness.



DB424558.eps

- A** Modbus SL RJ45 port.
- B** 0-24 V DC power supply
- C** Modbus address switches
- D** Modbus traffic LED
- E** Modbus locking pad

- F** ULP activity LED
- G** Test button
- H** Mechanical lock
- I** ULP RJ45 connectors
- J** Stacking accessory connection

IFM Modbus Communication Interface

Technical Characteristics

IFM Modbus Communication Interface


Dimensions	18 x 73 x 90 mm
Maximum number of stacked IFM	12
Degree of protection of the installed module	Part projecting beyond the escutcheon IP4x
Other module parts	IP3x
Connectors	IP2x
Operating temperature	-25...+70 °C
Power supply voltage	24 V DC -20 %/+10 % (19.2...26.4 V DC)
Consumption	Typical 21 mA/24 V DC at 20 °C
	Maximum 30 mA/19.2 V DC at 60 °C

Certification


CE	IEC/EN 60947-1
UL	UL 508 - Industrial Control Equipment
CSA	No. 142-M1987 - Process Control Equipment
	■ CAN/CSA C22.2 No. 0-M91 - General requirements - Canadian Electrical Code Part
	■ CAN/CSA C22.2 No. 14-05 - Industrial Control Equipment

Recommended IFM Installation

Stacking IFM





Stacking accessories



Up to 12 stacked IFM


Stacking an IFE Interface + Gateway with IFM



Connection of the IFE to a Fixed or Withdrawable ComPacT NS


A

Connect the IFE to a fixed ComPacT NS circuit breaker using the breaker ULP cord



- A** IFE Ethernet interface for LV circuit breaker
- B** Breaker ULP cord
- C** Fixed terminal block
- D** BCM ULP communication module
- E** Fixed electrically operated circuit breaker

Connect the IFE to a withdrawable ComPacT NS circuit breaker using the breaker ULP cord



- A** IFE Ethernet interface for LV circuit breaker
- B** ULP cable
- C** Breaker ULP cord
- D** Circuit breaker disconnected position contact (CD)
- E** Circuit breaker cradle
- F** Breaker Communication Module with ULP port (BCM ULP)
- G** Withdrawable circuit breaker
- H** Withdrawable terminal block
- I** Circuit breaker connected position contact (CE)
- J** Circuit breaker test position contact (CT)
- K** I/O (Input/Output) application module for LV circuit breaker

Connection of the IFM to a Fixed or Withdrawable ComPacT NS

Modbus Interface Module IFM

Functions

This module, required for connection to the network, contains the Modbus address (1 to 99) declared by the user via the two dials in front. It automatically adapts (baud rate, parity) to the Modbus network in which it is installed.


It is equipped with a lock-out switch to enable or disable operations involving writing to MicroLogic, i.e. reset, counter reset, setting modifications, device opening and closing commands, etc.

There is a built-in test function to check the connections of the Modbus interface module with the MicroLogic and FDM121 display unit.


Mounting

The module is mounted on a DIN rail. A number of modules may be clipped one next to the other. For this, a stacking accessory is available for fast clip-connection of both the Modbus link and the 24 V DC supply.

The Modbus interface module supplies 24 V DC to the corresponding MicroLogic, FDM121 display and BSCM module. Module consumption is 60 mA/24 V DC.




Mounting with stacking accessory



- A** Five-point Modbus and 24 V DC connector
- B** Two Modbus address dials (1 to 99)
- C** Modbus traffic LED
- D** Communication disabling lock out
- E** Test LED
- F** Test button
- G** Two connectors for RJ45 cable


A

Connect the IFM to a fixed ComPacT NS circuit breaker using the breaker ULP cord



- A** IFM Ethernet interface for LV circuit breaker
- B** Breaker ULP cord
- C** Fixed terminal block
- D** BCM ULP communication module
- E** Fixed electrically operated circuit breaker

Connect the IFM to a withdrawable ComPacT NS circuit breaker using the breaker ULP cord






- A** IFM Ethernet interface for LV circuit breaker
- B** ULP cable
- C** Breaker ULP cord
- D** Circuit breaker disconnected position contact (CD)
- E** Circuit breaker cradle
- F** BCM ULP communication module
- G** Withdrawable circuit breaker
- H** Withdrawable terminal block
- I** Circuit breaker connected position contact (CE)
- J** Circuit breaker test position contact (CT)
- K** I/O (Input/Output) application module for LV circuit breaker

A



I/O application module



I/O Application Module Description

Description

The I/O (Input/Output) application module for LV breaker is part of an ULP system with built-in functionalities and applications to enhance the application needs. The ULP system architecture can be built without any restrictions using the wide range of circuit breakers.

The I/O application module is compliant with the ULP system specifications. Two I/O application module can be connected in the same ULP network.

The ranges of LV circuit breakers enhanced by the I/O application module are:

- MasterPact
- ComPacT NS1600b-3200
- ComPacT NS630b-1600
- ComPacT NSX100-630 A.

I/O (Input/Output) application module for LV breaker resources

The I/O application module module resources are:

- 6 digital inputs that are self powered for either NO and NC dry contact or pulse counter
- 3 digital outputs that are bistable relay (5 A maximum)
- 1 analog input for Pt100 temperature sensor.

Pre-defined applications

Pre-defined application adds new functions to the IMU in a simple way:

- Selection by the application rotary switch on the I/O application module, defining the application with pre-defined input/output assignment and wiring diagram.
- No additional setting with the EcoStruxure Power Commission software required.

The resources not assigned to the pre-defined application are free for additional user-defined applications:

- Cradle management
- Breaker operation
- Light and load control
- Custom.

User-defined applications

User-defined applications are processed by the I/O application module in addition to the pre-defined application selected.

The user-defined applications are available depending on:

- The pre-defined application selected
- The I/O application module resources (inputs and outputs) not used by the application.

The resources required by user-defined applications are assigned using the EcoStruxure Power Commission software:

- Protection
- Control
- Energy management
- Monitoring.

Mounting

The I/O application module is a DIN rail mounting device.

Application rotary switch

The application rotary switch enables the selection of the pre-defined application.

It has 9 positions and each position is assigned to a pre-defined application.

The factory set position of the switch is pre-defined application 1.

Setting locking pad

The setting locking pad on the front panel of the I/O application module enables the setting of the I/O application module by the EcoStruxure Power Commission software.

General Characteristics

Environmental characteristics

Conforming to standards	UL 508, UL 60950, IED 60950, 60947-6-2
Certification	cUIUs, GOST, FCC, CE
Ambient temperature	-20 to +70 °C (-4 to +158 °F)
Relative humidity	5–85 %
Level of pollution	Level 3
Flame resistance	ULV0

Mechanical characteristics

Shock resistance	1000 m/s ²
Resistance to sinusoidal vibrations	-5 Hz < f < 8.4 Hz

Electrical characteristics

Resistance to electromagnetic discharge	Conforming to IEC/EN 61000-4-3
Immunity to radiated fields	10 V/m
Immunity to surges	Conforming to IEC/EN 61000-4-5
Consumption	165 mA

Physical characteristics

Dimensions	71.7 x 116 x 70.6 mm (2.83 x 4.56 x 2.78 in.)
Mounting	DIN rail
Weight	229.5 g (0.51 lb)
Degree of protection of the installed I/O application module	On the front panel (wall mounted enclosure): IP4x IO parts: IP3x Connectors: IP2x
Connections	Screw type terminal blocks

Technical characteristics - 24 V DC power supply

Power supply type	Regulated switch type
Rated power	72 W
Input voltage	100–120 V AC for single phase 200–500 V AC phase-to-phase
PFC filter	With IEC 61000-3-2
Output voltage	24 V DC
Power supply out current	3 A

Note: it is recommended to use an UL listed/UL listed recognized limited voltage/Limited current or a class 2 power supply with a 24 V DC, 3 A maximum.

Digital inputs

Digital input type	Self powered digital input with current limitations as per IEC 61131-2 type 2 standards (7 mA)
Input limit values at state 1 (close)	19.8–25.2 V DC, 6.1–8.8 mA
Input limit values at state 0 (open)	0–19.8 V DC, 0 mA
Maximum cable length	10 m (33 ft)

Note: for a length greater than 10 m (33 ft) and up to 300 m (1,000 ft), it is mandatory to use a shielded twisted cable. The shield cable is connected to the I/O functional ground of the I/O application module.


Digital outputs

Digital output type	Bistable relay
Rated load	5 A at 250 V AC
Rated carry current	5 A
Maximum switching voltage	380 V AC, 125 V DC
Maximum switch current	5 A
Maximum switching power	1250 VA, 150 W
Minimum permissible load	10 mA at 5 V DC
Contact resistance	30 mΩ
Maximum operating frequency	18000 operations/hr (Mechanical) 1800 operations/hr (Electrical)
Digital output relay protection by an external fuse	External fuse of 5 A or less
Maximum cable length	10 m (33 ft)

Analog inputs

The I/O application module analog input can be connected to a Pt100 temperature sensor

Range	-30 to 200 °C	-22 to 392 °F
Accuracy	±2 °C from -30 to 20 °C ±1 °C from 20 to 140 °C ±2 °C from 140 to 200 °C	±3.6 °F from -22 to 68 °F ±1.8 °F from 68 to 284 °F ±3.6 °F from 284 to 392 °F
Refresh interval	5 s	5 s



- A** 24 V DC power supply terminal block
- B** Digital input terminal block: 6 inputs, 3 commons and 1 shield
- C** 6 input status LEDs
- D** Analog input status LED
- E** 3 output status LEDs
- F** I/O application module identification labels
- G** Sealable transparent cover
- H** Analog input terminal block
- I** Digital output terminal blocks
- J** ULP status LED
- K** Test/reset button (accessible with cover closed)
- L** Setting locking pad
- M** Application rotary switch: 1 to 9
- N** Switch for I/O addressing (I/O 1 or I/O 2)
- O** ULP connectors.

- [1]** 250 V AC OVC 2 according IEC/EN 60947-2 . For OVC 3 and 4 surge arresters are required on the polarizing voltage of the output contacts.

Customer Engineering Tool: EcoStruxure Power Commission Software

A

Key Features

Build

I want to test & deliver a “ready to commission” panel

- Device Discovery
- Switchboard setting & testing
- Communication Test & Reports
- Save my project & reports

Commission

I want to “shorten” my commissioning time

- Device Discovery
- Multi Device Configuration
- Communication Test & Reports
- Save my project & reports


Maintain

I want to ensure “continuity” of services in “safe conditions”

- Settings consistency check
- Firmware upgrade
- Standard Diagnostic data
- Save my project & reports

EcoStruxure Power Commission Experience

Project Lifecycle



Functions and Characteristics

Customer Engineering Tool: EcoStruxure Power Commission Software

A

Operation and Maintenance

- Devices monitoring and control.
- Measurement parameter logs.
- Log reports.
- Download of current devices settings, compare with previous settings saved in EcoStruxure Power Commission.
- Firmware upgrade and compatibility matrix.

Compatibility

Devices

Configuration of below devices through the range of Enerlin'X interfaces devices.


- Circuit breakers: MasterPact MTZ, ComPacT NSX ranges.
- Circuit breakers and control components.

EcoStruxure Power Commission software for PC

- Compatible with Windows 10.

Example of EcoStruxure Power Commission Win

Browsing tabs



Smart Panels architecture

Contextual window, for monitoring, settings...

Key Features

■ Device Discovery

EcoStruxure Power Commission helps the user to discover the communicating devices in a switchboard either through Ethernet or a serial network. Once the devices in the switchboard are discovered, the user can add those devices to the project area.

■ Communication Test

When a user has installed communicating devices in a switchboard, EcoStruxure Power Commission offers the capability to test the communication network. Once a communication test is done, the user can generate a time stamped communication test report.

■ Reports


EcoStruxure Power Commission offers the following reports to the users

■ Firmware Upgrade

EcoStruxure Power Commission offers the compatibility check and firmware upgrade for the following devices.

A

08439150.ai



Motor Rating (KW) 160...750

NS630b to 1600



Breaking	N	50
capacity (kA rms)	H	70
380/415 V	L	150

page A-12

page A-20

MicroLogic 7.0 A provides the same protection functions, plus earth-leakage protection.

All type 2 have been tested under the conditions defined by standards and they are certified ASEFA/LOVAG.

0B439556.eps

P (kW) (400 V, 50 Hz)	0.37	1.1	5.5	18.5		37				110	160	250		560	750
I _r (A)	1.5	2.5	12	40	50	80	100	160	200	220	320	500	800	1000	1350
ComPacT NS630b ... NS1600											MicroLogic 2.0 A / 5.0 A / 6.0 A / 7.0 A				
											MicroLogic 2.0 E / 5.0 E / 6.0 E				

Functions and Characteristics

Earth-Leakage Protection

Overview of Solutions

A

Earth-leakage protection is obtained by:

- Installing a MicroLogic 7.0 A control unit (ComPacT NS630b to 3200).
- Using a VigiPacT relay and separate sensors (all ComPacT circuit breakers).

Circuit Breakers Equipped with a Control Unit Offering Integrated Earth-Leakage Protection and an External Rectangular Sensor

Rated Current (A)

630...1600

ComPacT NS630b to 1000 N/L
NS1250 and 1600 N

1600...3200

ComPacT NS1600b to 3200

C080N3SEFM.pdf



PB104831_ME.eps



C250N3FM.pdf



General circuit breaker characteristics

[page A-12](#)

ComPacT NS630b to 3200 circuit breakers are presented in the "Protection of distribution systems" section.

Associated control units

[page A-22](#)

MicroLogic 7.0 A electronic control units offer earth-leakage protection as standard.

Earth-Leakage Protection Using a VigiPacT Relay

Earth-leakage relay

Separate toroids

Rectangular sensors

PB104835_SE_FI.eps



059476_SE.eps



ComPacT NS Circuit Breaker with a VigiPacT Relay

VigiPacT relays may be used to add external earth-leakage protection to ComPacT NS circuit breakers.

The circuit breakers must be equipped with an MN or MX voltage release.

The VigiPacT relays add special tripping thresholds and time delays for earth-leakage protection.

VigiPacT relays are very useful when faced with major installation constraints (circuit breaker already installed and connected, limited space available, etc.).

VigiPacT relay characteristics

- Sensitivity adjustable from 30 mA to 30 A and time-delay settings (0 to 4.5 seconds)
- Closed toroids up to 630 A (30 to 300 mm in diameter), opened toroids up to 250 A (80 to 120 mm in diameter) or rectangular sensors up to 630 A
- 50/60 Hz distribution systems

Relay types

- Type A: up to 5A (RH10, RH21, RH68, RH86, RH99, RH197, RHUs or RHU, RMH) and RHB
- Type AC: RH10, RH21, RH68, RH86, RH99, RH197, RHUs or RHU, RMH
- Type B: RHB

Options

- Failsafe operation is possible, see relay wiring
- Voltage LED for local indication that voltage is not present.

Compliance with standards



- IEC 60947-2, annex M
- IEC/EN 60755: general requirements for residual-current operated protective devices
- IEC/EN 61000-4-2 to 4-6: immunity tests
- CISPR 11: Industrial, scientific and medical equipment - Radio-frequency disturbance characteristics - Limits and methods of measurement
- UL1053 and CSA22.2 No. 144 for RH10, RH21 and RH99 relays at supply voltages up to and including 220/240 V.

Protection type

VigiPact devices operate on TT, TNS and IT (for protection of persons against direct contact) systems.

The relays are type A, AC and B as defined by standard IEC/EN 60947-2.

Control and Isolation Overview of Solutions



LV Devices



Control and Isolation

Overview of Solutions

A

ComPacT switch-disconnectors are used to control and isolate electrical distribution circuits. In addition to these basic functions, other functions for safety and remote control include:

- Earth-leakage protection
- Auxiliary MN/MX releases
- Remote operation.

ComPacT switch-disconnectors may be interlocked with another ComPacT switch-disconnector or circuit breaker to constitute a source-changeover system.

C160SNAFM.psd



ComPacT NS1600NA manual switch-disconnector

PB100359.apa



ComPacT NS1600NA electrical switch-disconnector

Control and Disconnection

ComPacT NS630bNA to 1600NA Switch-Disconnectors

Installation standards require upstream protection.

C160S3NAFM.psd



ComPacT NS1600NA manual switch-disconnector

PB106359_1.eps



ComPacT NS1600NA electrical switch-disconnector

ComPacT Switch-Disconnectors

Number of poles

Control	manual	toggle
		direct or extended rotary handle

electric

Connections	fixed	front connection
		rear connection
	withdrawable (on chassis)	front connection
		rear connection

Electrical Characteristics as per IEC/EN 60947-3

Conventional thermal current (A)	I_{th}	40 °C ^[1]
Rated insulation voltage (V)	U_i	
Rated impulse withstand voltage (kV)	U_{imp}	
Rated operational voltage (V)	U_e	AC 50/60 Hz
Rated operational current	I_e	AC 50/60 Hz
		220/240 V
		380/415 V
		440/480 V
		500/525 V
		660/690 V

Short-circuit making capacity	I_{cm}	(kA peak)
Short-time withstand current	I_{cw}	(kA rms)
		0.5 s
		1 s

Suitability for isolation

Durability (C-O cycles)	mechanical			
	electrical	AC	440 V	AC23A/In

Positive contact indication

Pollution degree

Protection

Add-on earth-leakage protection combination with VigiPacT relay

Additional Indication and Control Auxiliaries

Indication contacts

Voltage releases	MX shunt release
	MN undervoltage release

Remote Communication by Bus

Device status indications (communicating auxiliary contacts)

Device remote operation (communicating motor mechanism)

Installation

Accessories	terminal extensions and spreaders	
	terminal shields and interphase barriers	
	escutcheons	
Dimensions (mm)	fixed	3P
W x H x D		4P
Weight (kg)	fixed	3P
		4P

Source-Changeover System (See Section "on Source-Changeover Systems")

Manual source-changeover systems, remote-operated and automatic

^[1] Derating for ambient temperature above 40 °C according to manufacturer's derating table.

Control and Disconnection

ComPacT NS630bNA to 1600NA Switch-Disconnectors

A

NS630bNA	NS800NA	NS1000NA	NS1250NA	NS1600NA
3, 4	3, 4	3, 4	3, 4	3, 4
630	800	1000	1250	1600
1000	1000	1000	1000	1000
8	8	8	8	8
690	690	690	690	690
AC23A	AC23A	AC23A	AC23A	AC23A
630	800	1000	1250	1600
630	800	1000	1250	1600
630	800	1000	1250	1600
630	800	1000	1250	1600
630	800	1000	1250	1600
52	52	52	52	52
25	25	25	25	25
19.2	19.2	19.2	19.2	19.2
10000	10000	10000	10000	10000
2000	2000	2000	2000	1000
3	3	3	3	3
327 x 210 x 147				
327 x 280 x 147				
14				
18				

Control and Disconnection

ComPacT NS1600bNA to 3200NA Switch-Disconnectors

A

Installation standards require upstream protection. However, ComPacT NS1600b to 3200NA switch-disconnectors are self-protected for all currents higher than 130 kA peak.

C2503SPM.ppt



ComPacT NS1600bNA

ComPacT Switch-Disconnectors

Number of poles

Control	manual	toggle
		direct or extended rotary handle

	electric	
Connections	fixed	front connection
		rear connection
	withdrawable (on chassis)	front connection
		rear connection

Electrical Characteristics as per IEC 60947-3 and EN 60947-3

Conventional thermal current (A)	I_{th}	40 °C ^[1]
Rated insulation voltage (V)	U_i	
Rated impulse withstand voltage (kV)	U_{imp}	
Rated operational voltage (V)	U_e	AC 50/60 Hz
Rated operational current	I_e	AC 50/60 Hz
		220/240 V
		380/415 V
		440/480 V
		500/525 V
		660/690 V

Short-circuit making capacity	I_{cm}	(kA peak)	
Short-time withstand current	I_{cw}	(kA rms)	3 s
Integrated instantaneous protection (kA peak ±10 %)			

Suitability for isolation

Durability (C-O cycles)	mechanical			
	electrical	AC	440 V	AC23A/In

Positive contact indication

Pollution degree

Protection

Add-on earth-leakage protection	combination with VigiPacT relay
---------------------------------	---------------------------------

Additional Indication and Control Auxiliaries

Indication contacts

Voltage releases	MX shunt release
	MN undervoltage release

Installation

Accessories	escutcheons
Dimensions (mm)	fixed
W x H x D	3P
Weight (kg)	4P
	3P
	4P

Source-Changeover System

(See Section "on Source-Changeover Systems")






















Manual source-changeover systems, remote-operated and automatic

^[1] For higher temperatures, check derating tables.

Control and Disconnection

ComPacT NS1600bNA to 3200NA Switch-Disconnectors

A

NS1600bNA	NS2000NA	NS2500NA	NS3200NA
3, 4	3, 4	3, 4	3, 4
			
-	-	-	-
-	-	-	-
			
-	-	-	-
-	-	-	-
-	-	-	-
1600	2000	2500	3200
800	800	800	800
8	8	8	8
690	690	690	690
AC23A	AC23A	AC23A	AC23A
1600	2000	2500	3200
1600	2000	2500	3200
1600	2000	2500	3200
1600	2000	2500	3200
1600	2000	2500	3200
135	135	135	135
32	32	32	32
130	130	130	130
			
6000	6000	6000	6000
1000	1000	1000	1000
			
3	3	3	3
			
			
			
			
			
350 x 420 x 160			
350 x 535 x 160			
23			
36			
-			

Source-Changeover Systems

Presentation

A

PB191613-50.eps



65537-117.eps



PI098532-104.eps



Some installations use two supply sources to counter the temporary loss of the main supply.

A source-changeover system is required to switch between two sources, so that power availability is secured.

The replacement source can be a generator set or another network.

Manual Source-Changeover System or MTSE (Manual Transfer Switching Equipment)

The simplest way to switch the load. It is controlled manually by an operator. The time required to switch from the S1 source to S2 source is variable.

System

2 or 3 mechanically interlocked circuit breakers or 2 switch-disconnectors.

Applications

Small commercial buildings and small and medium industrial activities where the need for continuity of service is significant but not a priority.

Automatic Source-Changeover System or ATSE (Automatic Transfer Switching Equipment)

An automatic controller may be added to a remote operated source-changeover system. It is possible to automatically control source transfer according to programmed (dedicated controllers) or programmable (PLC) operating modes. These solutions ensure optimum energy management.

The time required to switch from the S1 source to S2 source is fixed.

System

2 or 3 circuit breakers linked by an electrical interlocking system. A mechanical interlocking system protects also against incorrect manual operations, with an automatic control system (dedicated controllers).

Applications

Large infrastructures, industry, critical buildings & process where the continuity of service is a priority.

Remote Source-Changeover System or RTSE (Remote Transfer Switching Equipment)

In this case, no direct human intervention is required. The time required to switch from the S1 source to S2 source is fixed.

System

2 or 3 circuit breakers linked by an electrical interlocking system. A mechanical interlocking system protects also against incorrect manual operations. In this case is necessary to add a PLC controller not dedicated for source-changeover application.

Applications

Industry & Infrastructure where continuity of service requirements are meaningful but not a priority.

Source-Changeover Systems

Manual Source-Changeover Systems

A

A manual source-changeover system can be installed on two to three manually-operated circuit breakers or switch-disconnectors. Interlocking is mechanical. Interlocks prevent connection to both sources at the same time, even momentarily.

Interlocking of a Number of Devices Using Keylocks (Captive Keys)

Interlocking uses two identical keylocks with a single key. This solution enables interlocking between two devices that are physically distant or that have significantly different characteristics, for example between a low and a medium-voltage device, or between ComPacT NS circuit breakers and switch-disconnectors.

A system of wall-mounted units with captive keys makes possible a large number of combinations between many devices.

Combinations of Normal and Replacement devices

All ComPacT NS630b to 1600 circuit breakers and switch-disconnectors with rotary handles or motor mechanisms can be interlocked.

Interlocking of Two Devices with Rotary Handles

The rotary handles are padlocked with the devices in the OFF position.

The mechanism inhibits the two devices being closed at the same time, but does allow for both to be open (OFF) at the same time.

Combinations of "Normal" and "Replacement" devices

All ComPacT NS630b to 1600 circuit breakers and switch-disconnectors with rotary handles can be interlocked.

Interlocking of a ComPacT NS630b with a ComPacT NS630b to 1600 is not possible.

Interlocking of Two ComPacT NS630b to 1600 Devices Using Connecting Rods

The two devices must be mounted one above the other (either 2 fixed or 2 withdrawable devices).

Installation

This function requires:

- An adaptation fixture on the right side of each circuit breaker or switch-disconnector
- A set of connecting rods with no-slip adjustments.

The adaptation fixtures, connecting rods and circuit breakers or switch-disconnectors are supplied separately, ready for assembly by the customer. The maximum vertical distance between the fixing planes is 900 mm.

Possible combinations of "S1" and "S2" source circuit breakers

Combinaison are possible between between ComPacT NS devices and between ComPacT NS devices with MasterPact MTZ1 devices.

Interlocking of Two ComPacT NS630b to 1600 Devices Using Cables

For cable interlocking, the circuit breakers may be mounted one above the other or side-by-side.

The interlocked devices may be fixed or withdrawable, three-pole or four-pole, and have different ratings and sizes.

Installation

This function requires:

- An adaptation fixture on the right side of each device
- A set of cables with no-slip adjustments.


The maximum distance between the fixing planes (vertical or horizontal) is 2000 mm.




Interlocking with keylocks



Interlocking of two devices with rotary handles



Interlocking with connecting rods



Interlocking with cables

Possible Combinations of "S1" and "S2" Source Circuit Breakers

Source "S1"	Source "S2"			
	NS630b to NS1600	NT06 to NT16	MTZ1/ MTZ2/MTZ3	NW40b to NW63
NS630b to NS1600	●	●	●	Contact Schneider local support

Functions and Characteristics

Electrical Interlocking

IVE Unit

A

Electrical interlocking is used with a mechanical interlocking system. The relays controlling the closing command to the "S1" and "S2" circuit breakers must be mechanically and/or electrically interlocked to prevent them from giving simultaneous closing commands.

Electrical interlocking is carried out by an electrical control device. For ComPacT NS630b to NS1600, this function can be implemented in one of two ways:

- Using the IVE unit
- By an electrician based on the diagrams in accordance with the chapter "Electric diagrams" source-changeover system.

Characteristics of the IVE Unit

- External connection terminal block:
 - Inputs: circuit breaker control signals
 - Outputs: status of the SDE contacts on the "S1" and "S2" source circuit breakers.
- 2 connectors for the two "S1" and "S2" source circuit breakers:
 - Inputs:
 - status of the OF contacts on each circuit breaker (ON or OFF)
 - status of the SDE contacts on the "S1" and "S2" source circuit breakers
 - Outputs: power supply for operating mechanisms.
- Control voltage:
 - 24 to 250 V DC
 - 48 to 415 V 50/60 Hz - 440 V 60 Hz.

The IVE unit control voltage must be same as that of the circuit breaker operating mechanisms.



IVE unit

For ComPacT NS630b to NS1600, each circuit breaker must be equipped with:

- A motor mechanism
- An available OF contact
- A CE connected-position contact (carriage switch) on withdrawable circuit breakers
- An SDE contact.

Standard Configuration for ComPacT NS

Types of mechanical interlocking	Possible combinations	Typical electrical diagrams	Diagram no.
2 Devices			
	QN	QR	ComPacT NS630b to 1600:
	0	0	■ Electrical interlocking with lockout after fault:
	0	1	□ Permanent replacement source (with IVE) 51201183 [1]
	0	1	□ With emergency off By shunt release MX 51201184 [1] □ With emergency off by undervoltage release MN 51201185 [1]

[1] See catalog "Source changeover systems", ref. LVPED211022EN.

Functions and Characteristics


Electrical Interlocking

Remote-Operated Systems

A

Source-Changeover System with a Controller

In this case, changeovers between the "Normal" and "Replacement" sources under predefined conditions are initiated by a Schneider Electric controller.




Control plate


Controller

Switching between sources can be automated by adding:

- A** ACP control plate
- B** BA or UA controller, or an electrical system provided by the installer for NS630b to 1600. Electrical system example: part no. 51156904 and 51156904 in the source-changeover system catalog



Interlocking by rods



Interlocking by cables

> TransferPact Source Changeover Catalog



LVPED216028EN

Source-Changeover Systems

Associated Controllers

A

By combining a remote-operated source-changeover system with an integrated BA or UA automatic controller, it is possible to automatically control source transfer according to user-selected sequences. These controllers can be used on source-changeover systems comprising 2 circuit breakers. For source-changeover systems comprising 3 circuit breakers, the automatic control diagram must be prepared by the installer as a complement to diagrams provided in the "electrical diagrams" section of this catalog.



BA controller



UA controller

- [1] For example, 220 V single-phase or 220 V three-phase.
 [2] The controller is powered by the ACP control plate. The same voltage must be used for the ACP plate, the IVE unit and the operating mechanisms. If this voltage is the same as the source voltage, then the "Normal" and "Replacement" sources can be used directly for the power supply. If not, an isolation transformer must be used.













Controller		BA	UA
4-position switch			
Compatible circuit breaker		All ComPacT NS circuit breaker	
Automatic operation		●	●
Forced operation on "Normal" source		●	●
Forced operation on "Replacement" source		●	●
Stop (both Normal and Replacement sources OFF)		●	●
Automatic operation			
Monitoring of the "Normal" source and automatic transfer		●	●
Generator set startup control			●
Delayed shutdown (adjustable) of engine generator set			●
Load shedding and reconnection of non-priority circuits			●
Transfer to the "Replacement" source if one of the phases of the "Normal" phase is absent			●
Test			
By opening the P25M circuit breaker supplying the controller		●	
By pressing the test button on the front of the controller			●
Indications			
Circuit breaker status indication on the front of the controller: on, off, fault trip		●	●
Automatic mode indication contact		●	●
Other functions			
Selection of type of "Normal" source (single-phase or three-phase) [1]			●
Voluntary transfer to "Replacement" source (e.g. energy-management commands)		●	●
During peak-tariff periods (energy-management commands) forced operation on "Normal" source if "Replacement" source not operational			●
Additional control contact (not in controller). Transfer to "Replacement" source only if contact closed (e.g. used to test the frequency of UR)		●	●
Setting of maximum startup time for the replacement source			●
Power supply			
Control voltages [2]	110 V	●	●
	220 to 240 V 50/60 Hz	●	●
	380 to 415 V 50/60 Hz	●	●
	440 V 60 Hz	●	●
Operating thresholds			
Undervoltage	0.35 Un ≤ voltage ≤ 0.7 Un	●	●
Phase loss	0.5 Un ≤ voltage ≤ 0.7 Un		●
Voltage presence	voltage ≥ 0.85 Un	●	●

Functions and Characteristics

Source-Changeover Systems

Associated Controllers


A

Controller		BA	UA				
IP degree of protection (EN 60529) and IK degree of protection against external mechanical imPacts (EN 50102)							
Front	IP40						
Side	IP30						
Connectors	IP20						
Front	IK07						
Characteristics of output contacts (dry, volt-free contacts)							
Rated thermal current (A)	8						
Minimum load	10 mA at 12 V						
Output contacts:							
Position of the Auto/Stop switch							
Load shedding and reconnection order							
Generator set start order							
		AC		DC			
Utilization category (IEC 60947-5-1)		AC12	AC13	AC14	AC15	DC12	DC13
Operational current (A)	24 V	8	7	5	6	8	2
	48 V	8	7	5	5	2	-
	110 V	8	6	4	4	0.6	-
	220/240 V	8	6	4	3	-	-
	250 V	-	-	-	-	0.4	-
	380/415 V	5	-	-	-	-	-
	440 V	4	-	-	-	-	-
	660/690 V	-	-	-	-	-	-

Electrical and Mechanical Accessories

ComPacT NS630b to 1600 (Fixed Version)

DB439119.ai



- A** **A1** Terminal extension for cables with lugs
- A2** Vertical connection adapter
- A3** Spreader
- B** Interphase barriers
- C** **C1** Spreader
- C2** Rear connectors
- D** **D1** Sealable terminal shield
- D2** Connection kit for connectors

- E** **E1** Auxiliary contact
- E2** Voltage release
- E3** BCM ULP Communication module
- F** Escutcheon
- G** **G1** I/O (Input/Output) application module for LV circuit breaker
- G2** IFE Ethernet interface for LV circuit breaker
- G3** IFM Ethernet interface for LV circuit breaker
- G4** FDM121: Front Display Module
- G5** FDM128: Front Display Module


- H** **H1** Connection kit for connectors
- H2** Sealable terminal shield
- I** **I1** Extended rotary handle
- I2** Direct rotary handle

Electrical and Mechanical Accessories

ComPacT NS630b to 1600 (Withdrawable Version)

D9-439152-01

A



- A**
 - A1** Terminal extension for cables with lugs
 - A2** Vertical connection adapter
 - A3** Spreader
- B** Interphase barriers
- C**
 - C1** Spreader
 - C2** Rear connectors
- D**
 - D1** I/O (Input/Output) application module for LV circuit breaker
 - D2** IFE Ethernet interface for LV circuit breaker
 - D3** IFM Ethernet interface for LV circuit breaker
 - D4** FDM121: Front Display Module
 - D5** FDM128: Front Display Module
- E**
 - E1** Auxiliary contact
 - E2** Voltage release
 - E3** Communications module
- F**
 - F1** Extended rotary handle
 - F2** Direct rotary handle
 - F3** Transparent cover
- G** Escutcheon

Electrical and Mechanical Accessories

ComPacT NS630b to 1600

The withdrawable configuration makes it possible to:

- Extract and/or rapidly replace the circuit breaker without having to touch connections;
- Allow for the addition of future circuits at a later date.

C080N3E.FM.pad



Manually operated fixed ComPacT NS800

PB10481_ME_1.eps





Electrically operated fixed ComPacT NS1600


Installation

Fixed Configuration

ComPacT NS630b to 1600 circuit breakers may be installed vertically, horizontally or flat on their back.





Mounting on a backplate




Mounting on rails

Withdrawable Configuration


ComPacT NS630b to 1600 circuit breakers should be installed vertically only.




Mounting on a backplate



Rear mounting on rails



Device on mounting plate



Device on rails

C080N130_SE_ME_1.eps



Electrically operated withdrawable ComPacT NS800H


Electrical and Mechanical Accessories

ComPacT NS630b to 1600

A

The device may be in one of four positions on the chassis:

- Connected position. The power circuits and auxiliary contacts are all connected
- Test position. The power circuits are disconnected. The auxiliary contacts are still connected and the device can be operated electrically
- Disconnected position. The power circuits and auxiliary contacts are all disconnected, however the device is still mounted on the chassis. It can be operated manually (ON, OFF, "push to trip").
- Removed position. All circuits are disconnected. The device simply rests on the chassis rails and can be removed.



The multifunctional chassis for ComPacT NS630b to 1600 devices is particularly suited for incoming circuit breakers. Features include:

- Device connection and disconnection through a door, using a crank that can be stored in the chassis
- Three positions (connected, test and disconnected) that are indicated:
 - Locally by a position indicator
 - Remotely by carriage switches (3 for the connected position, 2 for the disconnected position and 1 for the test position)
- Circuit breaker ON/OFF commands through a switchboard front panel.


Locking

There are extensive locking possibilities:

- Chassis locking in connected, disconnected and test positions using three padlocks and two keylocks, on the switchboard front panel
- Door interlock (inhibits door opening with breaker in connected position)
- Racking interlock (inhibits racking with door open)
- Locking in each of the connected, disconnected and test positions during device connection or disconnection. Continuation to the next position requires pressing a release button to free the crank.

Other safety function

Mismatch protection ensures that a circuit breaker is installed only in a chassis with compatible characteristics.



- A** Mismatch protection
- B** Door interlock
- C** Racking interlock
- D** Keylock locking
- E** Padlock locking
- F** Position indicator
- G** Chassis front plate (accessible with cubicle door closed)
- H** Crank entry
- I** Reset button
- J** Crank storage


Electrical and Mechanical Accessories

ComPacT NS630b to 1600

Types of Connection


Fixed Device

Front connections (N, L)



Connection by:


bars



bare cables (except L)




cables with lugs(except L)




Rear connections (N, L, LB)

Horizontal:



Vertical:




Connection by:

bars



cables with lugs
(except L, LB)





Simply turn a horizontal rear connector 90° to make it a vertical connector.

Combination of front and rear connections (N, L)

Connection by:



bars



bare cables (except L)




cables with lugs(except L)



Withdrawable Device

Front connections




Connection by:


bars



cables with lugs



Rear connections




Connection by:

bars











cables with lugs



To ensure performance and isolation, depending on the type of circuit breaker (N, H, L, LB) and type of connection, certain isolation accessories are mandatory.

Connections Accessories

Type of Accessories		For ComPacT NS630b to NS1600			
		Fixed:		Withdrawable:	
		Front connection	Rear connection	Front connection	Rear connection
Vertical-connection adapters		N, H	-	N, H, L, LB	-
Set of bare-cable connectors and terminal shields for ratings ≤ 1250 A		N, H	-	-	-
Cable lug adapters		N, H	N, H, L, LB	N, H, L, LB	N, H, L, LB
Interphase barriers		N, H, L, LB	N, H, L, LB	-	N, H, L, LB
Spreaders		N, H	N, H	N, H, L, LB	N, H, L, LB
Connection shield		N, H, L	-	-	-
Safety shutters with locking by padlocks (IP20)		-	-	N, H, L, LB (standard)	N, H, L, LB (standard)
Arc chute screen		N, H, L	-	-	-

[4]

[1] Spreaders, vertical connection adapters and cable lugs adapters are not compatible with voltages ≥ 500 V.



[2] Mandatory for voltages ≥ 500 V unless using the bare-cable connector + terminal shield kit.

[3] Mandatory for fixed devices with L and LB performance levels, whatever the voltage.

[4] Mandatory for fixed front-connection versions with vertical connection adapters oriented towards the front.

Electrical and Mechanical Accessories







ComPacT NS630b to 1600



Front Connection of Fixed Devices



Bars

Fixed, front-connection ComPacT NS630b to 1600 devices are equipped with terminals comprising captive screws for direct connection of bars. Other connection possibilities for bars include vertical-connection adapters for edgewise bars and spreaders to increase the pole pitch to 95 mm. If the vertical connection adapters are front oriented, then it is mandatory to install the arc chute screen in order to comply with the safety clearances.



Bare Cables

Special sets of connectors and terminal shields may be used to connect up to four 240 mm² copper or aluminium cables for each phase. Bare cable connection is possible for ratings up to and including 1250 A.



4-cable connectors.


Cables with Lugs

Cable lug adapters are combined with the vertical-connection adapters.




One to four cables with crimped lugs ($\leq 300 \text{ mm}^2$) may be connected.

To ensure adequate mechanical strength, the cable lug adapters must be secured together via spacers.

If the cable lug adapters are installed over the top of the arc chute chambers, then it is mandatory to install the arc chute screen in order to comply with the safety clearances.



Cable lug adapters



Electrical and Mechanical Accessories


ComPacT NS630b to 1600

Rear Connection of Fixed Devices




Bars

Fixed, rear-connection ComPacT NS630b to 1600 devices equipped with horizontal or vertical connectors may be directly connected to flat or edgewise bars, depending on the position of the connectors.

Spreaders are available to increase the pole pitch to 95 mm.




Spreaders







Cables with Lugs

Cable lug adapters enable connection of one to four cables with crimped lugs ($\leq 300 \text{ mm}^2$).

To ensure stability, spacers must be positioned between the terminal extensions.




Cable lug adapters



A

Electrical and Mechanical Accessories


ComPacT NS630b to 1600




Front Connection of Withdrawable Devices

Bars




Withdrawable, front-connection ComPacT NS630b to 1600 devices are suitable for direct connection of bars. Other connection possibilities for bars include vertical-connection adapters for edgewise bars and spreaders to increase the pole pitch to 95 mm.



Vertical-connection adapters




Spreaders





Cables with Lugs

Cable lug adapters enable connection of one to four cables with crimped lugs ($\leq 300 \text{ mm}^2$).

To ensure stability, spacers must be positioned between the terminal extensions.



Cable lug adapters



Electrical and Mechanical Accessories


ComPacT NS630b to 1600

Rear Connection of Withdrawable Devices




Bars

Withdrawable, rear-connection ComPacT NS630b to 1600 devices equipped with horizontal or vertical connectors may be directly connected to flat or edge-wise bars, depending on the position of the connectors.

Spreaders are available to increase the pole pitch to 95 mm.




Spreaders






Cables with Lugs

Cable lug adapters enable connection of one to four cables with crimped lugs ($\leq 300 \text{ mm}^2$).

To ensure stability, spacers must be positioned between the terminal extensions.



Cable lug adapters



Electrical and Mechanical Accessories

ComPacT NS630b to 1600




ComPacT NS equipped with connection shield

Insulation of Live Parts

Connection Shield


Mounted on fixed, front-connection devices, this shield insulates power-connection points, particularly when cables with lugs are used




Connection shield

Interphase Barriers


These barriers are flexible insulated partitions used to reinforce isolation of connection points in installations with busbars, whether insulated or not. Barriers are installed vertically between front or rear connection terminals. They are mandatory for voltages ≥ 500 V for both fixed and withdrawable products and for L and LB types, whatever the voltage.



Interphase barriers for fixed device, front connection



Interphase barriers for fixed device, rear connection




Interphase barriers for withdrawable device, rear connection

Safety Shutters (Standard)

Mounted on the chassis, the safety shutters automatically block access to the disconnecting contact cluster when the device is in the disconnected or test positions (degree of protection IP20). When the device is removed from its chassis, no live parts are accessible.

The shutters can be padlocked (padlock not supplied) to:

- Prevent connection of the device
- Lock the shutters in the closed position.



Safety shutters


Electrical and Mechanical Accessories

ComPacT NS630b to 1600

Connection of Electrical Auxiliaries

Fixed Devices



Connections are made directly to the auxiliaries once the front has been removed. Wires exit the circuit breaker through a knock-out in the top.




Withdrawable Devices

Auxiliary circuits are connected to terminal blocks located in the top part of the chassis.


The auxiliary terminal block is made up of a fixed and moving part. The two parts are in contact when the device is in the test and connected positions.



Manually operated device



Electrically operated device



Withdrawable device

A

Electrical and Mechanical Accessories

ComPacT NS630b to 1600

All the auxiliary contacts opposite are also available in "low-level" versions capable of switching very low loads (e.g. for the control of PLCs or electronic circuits).




Screwless type: OF, SD and SDE changeover contacts



Screw type: OF, SD and SDE changeover contacts



Wireless type: OF, SD and SDE changeover contacts



Carriage switches for connected (CE), disconnected (CD) and test (CT) positions

Indication Contacts

Contacts Installed in the Device

Changeover contacts are used to remote circuit breaker status information and can thus be used for indications, electrical locking, relaying, etc. They comply with the IEC 60947-5-1 international recommendation.

Functions

- **OF (ON/OFF)** - indicates the position of the main circuit breaker contacts
- **SD (trip indication)** - indicates that the circuit breaker has tripped due to:
 - An overload
 - A short-circuit
 - An earth-leakage fault.
 - Operation of a voltage release
 - Operation of the "push to trip" button
 - Disconnection when the device is ON.

Returns to de-energized state when the circuit breaker is reset.

- **SDE (fault indication)** - indicates that the circuit breaker has tripped due to:
 - An overload
 - A short-circuit
 - An earth-leakage fault.

Returns to de-energized state when the circuit breaker is reset.

- **CAF/CAO (early-make or early-break function)** - indicates the position of the rotary handle. Used in particular for advanced opening of safety trip devices (early break) or to energize a control device prior to circuit breaker closing (early make).

Installation

- **OF, SD and SDE functions** - a single type of contact provides all these different indication functions, depending on where it is inserted in the device. The contacts clip into slots behind the front cover of the circuit breaker
- **CAF/CAO function** - the contact fits into the rotary-handle unit (direct or extended).

Electrical Characteristics of the OF/SD/SDE/CAF/CAO Auxiliary Contacts

Contacts	Standard contact with spring terminals					Low-level contact with screw terminals			
Types of contacts	OF, SD, SDE, SDV					OF, SD, SDE, SDV			
Rated thermal current (A)	5					5			
Minimum load	100 mA at 24 V DC					1 mA at 4 V DC			
Utilization cat. (IEC 60947-5-1)	AC12	AC15	DC12	DC13	DC14	AC12	AC15	DC12	DC14
Operational current (A)	5	5	5	2.5	1	5	3	5	1
48 V AC/DC	5	5	2.5	1.2	0.2	5	3	2.5	0.2
110 V AC/DC	5	5	0.6	0.35	0.05	5	2.5	0.6	0.05
220/240 V AC	5	4	-	-	-	5	2	-	-
250 V DC	-	-	0.3	0.03	0.03	5	-	0.3	0.03
380/440 V AC	5	2	-	-	-	5	1.5	-	-
480 V AC	5	1.5	-	-	-	5	1	-	-
660/690 V AC	5	0.1	-	-	-	-	-	-	-

Connected, Disconnected, Test Position Carriage Switches

A single type of changeover contact can be mounted optionally on the chassis to indicate, depending on the slot where it is installed:

- The connected (CE) position
- The disconnected (CD) position. This position is indicated when the required clearance for isolation of the power and auxiliary circuits is reached
- The test (CT) position. In this position, the power circuits are disconnected and the auxiliary circuits are connected.

Installation

- Contacts for the connected (CE), disconnected (CD) and test (CT) positions clip into the upper front section of the chassis.

Electrical Characteristics of the CE/CD/CT Auxiliary Contacts

Contacts	Standard				Low level			
Rated thermal current (A)	8				5			
Minimum load	100 mA at 24 V				2 mA at 15 V			
Utilization cat. (IEC 60947-5-1)	AC12	AC15	DC12	DC14	AC12	AC15	DC12	DC14
Operational current (A)	8	6	2.5	1	5	3	5	1
24 V	8	6	2.5	0.2	5	3	2.5	0.2
48 V	8	5	0.8	0.05	5	2.5	0.8	0.05
110 V	8	4	-	-	5	2	-	-
220/240 V	8	4	-	-	5	2	-	-
250 V	-	-	0.3	0.03	5	-	0.3	0.03
380/440 V	8	3	-	-	5	1.5	-	-
660/690 V	6	0.1	-	-	-	-	-	-

Electrical and Mechanical Accessories

ComPacT NS630b to 1600

A

Rotary Handles

There are two types of rotary handle:

- Direct rotary handle
- Extended rotary handle.

There are two models:

- Standard with a black handle
- VDE with a red handle and yellow front for machine-tool control.

Direct Rotary Handle

Degree of protection IP40, IK07.

The direct rotary handle maintains:

- Visibility of and access to trip unit settings
- Suitability for isolation
- Indication of the three positions O (OFF), I (ON) and tripped
- Access to the "push to trip" button
- Circuit breaker locking capability in the OFF position by one to three padlocks, shackle diameter 5 to 8 mm (not supplied).

It replaces the circuit breaker front cover.

Accessories transform the standard direct rotary handle for the following situations:

- A higher degree of protection (IP43, IK07)
- Machine-tool control, complying with CNOMO E03.81.501, IP54, IK07.

Extended Rotary Handle

Degree of protection IP55, IK07.

This handle makes it possible to operate circuit breakers installed at the back of switchboards, from the switchboard front.

It maintains:

- Suitability for isolation
- Indication of the three positions O (OFF), I (ON) and tripped
- Access to trip unit settings, when the switchboard door is open
- Circuit breaker locking capability in the OFF position by one to three padlocks, shackle diameter 5 to 8 mm (not supplied).

The door cannot be opened if the circuit breaker is ON or locked.

The extended rotary handle is made up of:

- A unit that replaces the front cover of the circuit breaker (secured by screws)
- An assembly (handle and front plate) on the door that is always secured in the same position, whether the circuit breaker is installed vertically or horizontally
- An extension shaft that must be adjusted to the distance. The min/max distance between the back of circuit breaker and door is 218/605 mm.



ComPacT NS with a direct rotary handle



ComPacT NS with an extended rotary handle

Electrical and Mechanical Accessories

ComPacT NS630b to 1600

Manually operated circuit breakers may be equipped with an MX shunt release, an MN undervoltage release or a delayed undervoltage release (MN + delay unit).

Electrically operated circuit breakers are equipped as standard with a remote-operating mechanism to remotely open or close the circuit breaker. An MX shunt release or an MN undervoltage release (instantaneous or delayed) may be added.

Remote Tripping


This function opens the circuit breaker via an electrical order. It is made up of:

- A shunt release (2nd MX)
- Or an undervoltage release MN
- Or a delayed undervoltage release MN + delay unit.

These releases (2nd MX or MN) cannot be operated by the communication bus.

The delay unit, installed outside the circuit breaker, may be disabled by an emergency OFF button to obtain instantaneous opening of the circuit breaker.

Wiring diagram for the remote-tripping function

Voltage Releases 2nd MX

When energized, the 2nd MX voltage release instantaneously opens the circuit breaker. A continuous supply of power to the 2nd MX locks the circuit breaker in the OFF position. The MX release instantaneously opens the circuit breaker when energized, the minimum duration of the pulse operating order must be 200 ms.

The MX release locks the circuit breaker in OFF position if the order is maintained (except for MX "communicating" releases).

Characteristics

Power supply	V AC 50/60 Hz	24 - 48 - 100/130 - 200/250 - 277 - 380/480
	V DC	12 - 24/30 - 48/60 - 100/130 - 200/250
Operating threshold		0.7 to 1.1 Un
Permanent locking function		0.85 to 1.1 Un
Consumption (VA or W)		pick-up: 200 (200 ms) hold: 4.5
Circuit breaker response time at Un		50 ms ±10

Instantaneous Voltage Releases MN

The MN release instantaneously opens the circuit breaker when its supply voltage drops to a value between 35 % and 70 % of its rated voltage. If there is no supply on the release, it is impossible to close the circuit breaker, either manually or electrically. Any attempt to close the circuit breaker has no effect on the main contacts. Circuit breaker closing is enabled again when the supply voltage of the release returns to 85 % of its rated value.

Characteristics

Power supply	V AC 50/60 Hz	24 - 48 - 100/130 - 200/250 - 380/480
	V DC	24/30 - 48/60 - 100/130 - 200/250
Operating threshold	opening	0.35 to 0.7 Un
	closing	0.85 Un
Consumption (VA or W)		pick-up: 200 (200 ms) hold: 4.5
MN consumption with delay unit (VA or W)		pick-up: 400 (200 ms) hold: 4.5
Circuit breaker response time at Un		90 ms ±5

MN Delay Units

To eliminate circuit breaker nuisance tripping during short voltage dips, operation of the MN release can be delayed. This function is achieved by adding an external delay unit in the MN voltage-release circuit. Two versions are available, adjustable and non-adjustable.

Characteristics


Power supply	non-adjustable	100/130 - 200/250
V AC 50-60 Hz / DC	adjustable	48/60 - 100/130 - 200/250 - 380/480
Operating threshold	opening	0.35 to 0.7 Un
	closing	0.85 Un
Consumption of delay unit alone (VA or W)	pick-up: 200 (200 ms)	hold: 4.5
Circuit breaker response time at Un	non-adjustable	0.25 s
	adjustable	0.5 s - 1 s - 1.5 s - 3 s



Fixed ComPacT NS800



Fixed ComPacT NS1600



MX voltage release

Electrical and Mechanical Accessories

ComPacT NS630b to 1600

A

Electrically operated circuit breakers are equipped as standard with a motor mechanism module. Two solutions are available for electrical operation:

- Point-to-point solution
- Bus solution with the COM communication option.

Electrically Operated Circuit Breaker

The motor mechanism module is used to remotely open and close the circuit breaker. It is made up of a spring-charging motor equipped with an opening release and a closing release.

An electrical operation function is generally combined with:

- Device ON/OFF indication OF
- "fault-trip" indication SDE.

Motor mechanism module

Power supply	V AC 50/60 Hz	48/60 - 100/130 - 200/240 - 277 - 380/415
	V DC	24/30 - 48/60 - 100/125 - 200/250
Operating threshold		0.85 to 1.1 U_n
Consumption (VA or W)		180
Motor overcurrent		2 to 3 I_n for 0.1 second
Charging time		maximum 4 seconds
Operating frequency		maximum 3 cycles per minute

Electrical closing order

The release remotely closes the circuit breaker if the spring mechanism is charged. Release electrical characteristics are identical to those of an MX release (see above), the operating threshold is from 0.85 to 1.1 U_n and the circuit breaker response time at U_n is 60 ms \pm 10.

The ComPacT NS electrical operation function can be used to implement a synchro-coupling system.

Electrical opening order


The release instantaneously opens the circuit breaker when energized. The supply can be impulse-type or maintained.

Release electrical characteristics are identical to those of an MX release (see above).




Electrically operated ComPacT NS circuit breaker.

Wiring diagram of a point-to-point electrical operation solution



Wiring diagram of a bus-type electrical operation solution



In the event of simultaneous opening and closing orders, the mechanism discharges without any movement of the main contacts.

In the event of maintained opening and closing orders, the standard electrical operation solution provides an anti-pumping function by blocking the main contacts in open position.

Electrical and Mechanical Accessories


ComPacT NS630b to 1600



Toggle locked by removable padlocking device.



Rotary handle locked by a keylock.



Access to pushbuttons protected by transparent cover.

Pushbutton locking using a padlock.



OFF position locking using padlocks.



OFF position locking using a keylock and padlocks.


Locking on Manually Operated Devices

Locking in the OFF position ensures isolation as per IEC 60947-2. Padlocking systems can receive up to three padlocks with shackle diameters ranging from 5 to 8 mm (padlocks not supplied).

Control device	Function	Means	Required accessories
Toggle	lock in		
	■ OFF position	padlock	removable device
	■ OFF or ON position	padlock	fixed device
Direct rotary handle	lock in		
	■ OFF position	padlock	
	■ OFF or ON position	keylock	locking device + keylock
CNOMO direct rotary lock in handle	■ OFF position	padlock	
Extended rotary handle	lock in OFF position, door opening prevented	padlock	
		keylock	keylock

Locking in ON position does not prevent the device from tripping in the event of a fault or remote tripping order.

Locking on Electrically Operated Devices



- A** reset of mechanical trip indicator
- B** OFF pushbutton
- C** OFF position locking
- D** ON pushbutton
- E** springs charged indication
- F** pushbutton locking
- G** contact position indication
- H** operation counter

Pushbutton Locking VBP

The transparent cover blocks access to the pushbuttons used to open and close the device.

It is possible to independently lock the opening OFF button and the closing ON button.

The pushbuttons may be locked using either:

- Padlocks (not supplied), 5 to 8 mm
- Lead seal
- Two screws.

Device Locking in the OFF Position VCPO by Padlocks, VSPO by Keylocks

The circuit breaker is locked in the OFF position by physically maintaining the opening pushbutton pressed down:

- Using padlocks in standard (one to three padlocks, not supplied)
- Using a keylock (supplied).

Keys may be removed only when locking is effective (Profalux or Ronis type locks).

The keylocks are available in any of the following configurations:

- One keylock
- One keylock mounted on the device + one identical keylock supplied separately for interlocking with another device.


A locking kit (without lock) is available for installation of a keylock (Ronis, Profalux, Kirk or Castell).

Electrical and Mechanical Accessories

ComPacT NS630b to 1600

Chassis Locking

DB128071.eps



- A** mismatch protection
- B** door interlock
- C** racking interlock
- D** keylock locking
- E** padlock locking
- F** position indicator
- G** chassis front plate (accessible with cubicle door closed)
- H** crank entry
- I** reset button
- J** crank storage

"Disconnected" Position Locking by Padlocks (Standard) or Keylocks (VSPD Option)

Mounted on the chassis and accessible with the door closed, these devices lock the circuit breaker in the disconnected position in two manners:

- Using padlocks (standard), up to three padlocks (not supplied)
- Using keylocks (optional), one or two different keylocks are available.

Profalux and Ronis keylocks are available in different options:

- One keylock
- One keylock mounted on the device + one identical keylock supplied separately, using the same key, for interlocking with another device
- One (or two) keylocks mounted on the device + one (or two) identical keylocks supplied separately, for interlocking with another device.

A locking kit (without locks) is available for installation of one or two keylocks (Ronis, Profalux, Kirk or Castell).

"Connected", "Disconnected" and "Test" Position Locking

The connected, disconnected and test positions are shown by an indicator and are mechanically indexed.

The racking crank blocks when the exact position is obtained.

A release button is used to free it.

As standard, the circuit breaker can be locked only in "disconnected position". On request, the locking system may be modified to lock the circuit breaker in any of the three positions: "connected", "disconnected" or "test".

Door Interlock Catch VPEC

Mounted on the right or left-hand side of the chassis, this device inhibits opening of the cubicle door when the circuit breaker is in connected or test position. If the breaker is put in the connected position with the door open, the door may be closed without having to disconnect the circuit breaker.

Racking Interlock VPOC

This device prevents insertion of the crank when the cubicle door is open (device cannot be connected).

Mismatch Protection VDC

Mismatch protection ensures that a circuit breaker is installed only in a chassis with compatible characteristics. It is made up of two parts (one on the chassis and one on the circuit breaker) offering twenty different combinations that the user may select.



"Disconnected" position locking by padlocks.



"Disconnected" position locking by keylocks.



Door interlock.



Racking interlock.



Mismatch protection.

Electrical and Mechanical Accessories


ComPacT NS630b to 1600

PB10474C32.eps



Auxiliary terminal shield.

PB104382A32.eps



Operation counter.

DB128144.eps




Escutcheon.

DB128145.eps



Transparent cover.

DB128146.eps



Blanking plate.

Other Accessories

Auxiliary Terminal Shield (CB)

Optional equipment mounted on the chassis, the shield prevents access to the terminal block of the electrical auxiliaries.

Operation Counter (CDM)

The operation counter sums the number of operating cycles and is visible on the front panel. This option is mandatory for Source-changeover systems and only compatible with electrically operated devices.

Escutcheon (CDP)

Optional equipment mounted on the door of the cubicle, the escutcheon increases the degree of protection to IP40. It is available in fixed and withdrawable versions.

Transparent Cover (CCP) for Escutcheon

Optional equipment mounted on the escutcheon, the cover is hinged and secured by a screw. It increases the degree of protection to IP54 and the degree of protection against mechanical impacts to IK10. It may be used for withdrawable devices only.

Blanking Plate (OP) for Escutcheon


Used with the escutcheon, this option closes off the door cutout of a cubicle not yet equipped with a device. It may be used with the escutcheon for both fixed and withdrawable devices.

Electrical and Mechanical Accessories

ComPacT NS1600b to 3200 (Fixed Version)

D9-439/04, all

A



- A** Vertical-connection adapters
- B** Interphase barriers
- C** **C1** Auxiliary contact
C2 Voltage release
C3 Communications module
- D** Escutcheon

- E** **E1** I/O (Input/Output) application module for LV circuit breaker
E2 IFE Ethernet interface for LV circuit breaker
E3 IFM Modbus interface for LV circuit breaker
E4 FDM121: Front Display Module
E5 FDM128: Front Display Module

Electrical and Mechanical Accessories

ComPacT NS1600b to 3200

C250NFM.eps





Fixed ComPacT NS

Installation

Fixed Circuit Breakers

ComPacT NS1600b to 3200 circuit breakers should be installed vertically only.




Mounting on rails


Connection

Front Connection

NS1600 to 2500




NS3200






Bars

Bars may be directly connected to the terminals of ComPacT NS1600b to 3200 circuit breakers.

NS1600b to 2500



NS1600b to 2500 with connection for vertical-connection adapters or NS3200



Electrical and Mechanical Accessories

ComPacT NS1600b to 3200

All the auxiliary contacts opposite are also available in "low-level" versions capable of switching very low loads (e.g. for the control of PLCs or electronic circuits).

A

Indication Contacts

Contacts Installed in the Device

Changeover contacts are used to remote circuit breaker status information and can thus be used for indications, electrical locking, relaying, etc. They comply with the IEC 60947-5-1 international recommendation.

Functions

- OF (ON/OFF) - indicates the position of the main circuit breaker contacts
- SD (trip indication) - indicates that the circuit breaker has tripped due to:
 - an overload
 - a short-circuit
 - an earth-leakage fault
 - operation of a voltage release
 - operation of the "push to trip" button
- Returns to de-energized state when the circuit breaker is reset.
- SDE (fault indication) - indicates that the circuit breaker has tripped due to:
 - an overload
 - a short-circuit
 - an earth-leakage fault.

Returns to de-energized state when the circuit breaker is reset.

Installation

- OF, SD and SDE functions - a single type of contact provides all these different indication functions, depending on the position where it is inserted in the device. The contacts clip into slots behind the front cover of the circuit breaker.

Electrical characteristics of the OF/SD/SDE auxiliary contacts

Contacts		Standard contact with spring terminals				Low-level contact with screw terminals			
Rated thermal current (A)		5				5			
Minimum load		100 mA at 24 V				1 mA at 4 V			
Utilization cat. (IEC 60947-5-1)		AC12	AC15	DC12	DC14	AC12	AC15	DC12	DC14
Operational current (A)	24 V	5	5	5	1	5	3	5	1
	48 V	5	5	2.5	0.2	5	3	2.5	0.2
	110 V	5	5	0.6	0.05	5	2.5	0.6	0.05
	220/240 V	5	4	-	-	5	2	-	-
	250 V	-	-	0.3	0.03	5	-	0.3	0.03
	380/440 V	5	2	-	-	5	1.5	-	-
	480 V	5	1.5	-	-	5	1	-	-
660/690 V		5	0.1	-	-	-	-	-	-



Screwless type: OF, SD and SDE changeover contacts



Screw type: OF, SD and SDE changeover contacts




Wireless type: OF, SD and SDE changeover contacts

Electrical and Mechanical Accessories

ComPacT NS1600b to 3200

ComPacT NS1600b to 3200 circuit breakers may be equipped with an MX shunt release, an MN undervoltage release or a delayed undervoltage release (MNR = MN + delay unit).



Remote Tripping


This function opens the circuit breaker via an electrical order. It is made up of:

- a shunt release 2nd MX
- or an undervoltage release MN
- or a delayed undervoltage release MNR = MN + delay unit.

These releases (2nd MX or MN) cannot be operated by the communication bus.

The delay unit, installed outside the circuit breaker, may be disabled by an emergency OFF button to obtain instantaneous opening of the circuit breaker.

Wiring diagram for the remote-tripping function

Voltage Releases 2nd MX

When energized, the 2nd MX voltage release instantaneously opens the circuit breaker. A continuous supply of power to the 2nd MX locks the circuit breaker in the OFF position.

Characteristics

Power supply V AC 50/60 Hz	24 - 48 - 100/130 - 200/250 - 277 - 380/480
V DC	12 - 24/30 - 48/60 - 100/130 - 200/250
Operating threshold	0.7 to 1.1 Un
Permanent locking function	0.85 to 1.1 Un
Consumption (VA or W)	pick-up: 200 (80 ms) hold: 4.5
Circuit breaker response time at Un	50 ms ± 10

Instantaneous Voltage Releases MN

The MN release instantaneously opens the circuit breaker when its supply voltage drops to a value between 35 % and 70 % of its rated voltage. If there is no supply on the release, it is impossible to close the circuit breaker, either manually or electrically. Any attempt to close the circuit breaker has no effect on the main contacts. Circuit breaker closing is enabled again when the supply voltage of the release returns to 85 % of its rated value.

Characteristics

Power supply V AC 50/60 Hz	24 - 48 - 100/130 - 200/250 - 380/480
V DC	24/30 - 48/60 - 100/130 - 200/250
Operating opening threshold	0.35 to 0.7 Un
closing	0.85 Un
Consumption (VA or W)	pick-up: 200 (200 ms) hold: 4.5
MN consumption with delay unit (VA or W)	pick-up: 400 (200 ms) hold: 4.5
Circuit breaker response time at Un	90 ms ± 5

MN Delay Units

To eliminate circuit breaker nuisance tripping during short voltage dips, operation of the MN release can be delayed. This function is achieved by adding an external delay unit in the MN voltage-release circuit. Two versions are available, adjustable and non-adjustable.

Characteristics

Power supply V AC 50-60 Hz / DC	non-adjustable	100/130 - 200/250
	adjustable	48/60 - 100/130 - 200/250 - 380/480
Operating opening threshold	opening	0.35 to 0.7 Un
	closing	0.85 Un
Consumption of delay unit alone (VA or W)	pick-up: 200 (200 ms)	hold: 4.5
Circuit breaker response time at Un	non-adjustable	0.25 s
	adjustable	0.5 s - 0.9 s - 1.5 s - 3 s

Electrical and Mechanical Accessories

ComPacT NS1600b to 3200

A

Device Locking

Locking in the OFF position ensures isolation as per IEC 60947-2. Padlocking systems can receive up to three padlocks with shackle diameters ranging from 5 to 8 mm (padlocks not supplied).

Control device	Function	Means	Required accessories
Toggle	lock in OFF position	padlock	removable device
	lock in OFF or ON position	padlock	fixed device

Interphase Barriers

These barriers are flexible insulated partitions used to reinforce isolation of connection points in installations with busbars, whether insulated or not. Barriers are installed vertically between front connection terminals.

Escutcheon CDP


Optional equipment mounted on the door of the cubicle, the escutcheon increases the degree of protection to IP40.




ComPacT NS with toggle locked using a fixed device and padlocks



ComPacT NS with toggle locked using a removable device and padlocks



Interphase barriers



Escutcheon

Indication and Measurement Accessories

PowerLogic™ PowerTag Energy Rope 200 A to 2000 A

As per standard IEC 61557-12 PMD-II/DD/K70/1, PowerLogic™ PowerTag Energy Rope can be installed easily on busbars and cables without having to disconnect the conductors, thanks to its flexible and openable current sensors. PowerLogic™ PowerTag Energy Rope is suitable for 3P or 3P+N networks. Its removable spring connector, used for voltage picking, facilitates its installation.

The module can be mounted on a DIN rail or maintained with brackets where needed in a panel.



PowerTag Energy Rope



> PowerTag Energy Rope

Main Characteristics

PowerTag Energy Rope measures the following values in accordance with the IEC 61557-12 standard PMD-II/DD/K70/1:

Energy (4 quadrants):

- Active energy (kWh): total and partial, delivered and received.
- Active energy per phase (kWh): total and partial, delivered and received.
- Reactive energy (kVARh): total and partial, delivered and received.
- Reactive energy per phase (kVARh): total and partial, delivered and received.
- Apparent energy (kVAh): total and partial.
- Apparent energy per phase (kVAh): total and partial.

Real-time measurement values:

- Voltages (V): phase-to-phase (U12, U23, U31) and phase-to-neutral (V1N, V2N, V3N).
- Currents (A): per phase (I1, I2, I3), calculated neutral current when connected (IN).
- Power:
- Active power (W): total and per phase.
- Reactive power (VAR): total and per phase.
- Apparent power (VA): total and per phase.
- Frequency (Hz).
- Power factor: total and per phase.

Voltage loss alarms:

- PowerTag Energy Rope sensor sends a “voltage loss” alarm and the current-per-phase value before being de-energized.
- At “voltage loss”, PowerTag Energy Rope adds an overload alarm if the current is higher than the rated current of the associated protective device.

Note: Functions listed above depends on Concentrator/Gateway.

Indication and Measurement Accessories

PowerLogic™ PowerTag Energy Rope 200 A to 2000 A

Technical Specifications


Main characteristics (as per IEC 61557-12)				
Rated voltage	Un	Phase-to-neutral	100...277 VAC ± 20 %	
		Phase-to-phase	173...480 VAC ± 20 %	
Frequency			50/60 Hz	
Maximum current	I _{max}		200 A / 600 A / 1000 A / 2000 A	
Maximum operating current			1.2 x I _{max}	
Saturation current			2 x I _{max}	
Maximum consumption			3 VA	
Starting current	I _{st}		120 mA / 400 mA / 600 mA / 1.2 A	
Basic current	I _b		30 A / 100 A / 150 A / 300 A	
Additional characteristic				
Operating temperature			-25 °C to +70 °C	
Maximum primary conductor temperature			105 °C ^[2]	
Storage temperature			-40 °C to +85 °C	
Overvoltage category		As per IEC 61010-1	Cat. IV	
Measuring category		As per IEC 61010-2-030	Cat. IV	
Pollution degree			3	
Altitude			Up to 2000 m without derating ^[1]	
Degree of protection device			IP20 (IP40 front face)	
			IK05	
Radio-frequency communication				
ISM band 2.4 GHz			2.4 GHz to 2.4835 GHz	
Channels		As per IEEE 802.15.4	11 to 26	
Isotropic Radiated Power		Equivalent (EIRP)	0 dBm	
Maximum transmission time			< 5 ms	
Channel occupancy		For 1 device	messages sent every 5 seconds	
Characteristics of measuring functions				
Function	Symbol	Performance category as per IEC 61557-12 (PMD-II/DD/K70/1)		Measuring range (200 A / 600 A / 1000 A / 2000 A)
		Class	Measuring range (200 A / 600 A / 1000 A / 2000 A)	
Total active power (Active power per phase)	P	1	3 to 200 A / 10 to 600 A / 15 to 1000 A / 30 to 2000 A	29 W (10 W) to 240 kW / 96 W (32 W) to 720 kW / 144 W (48 W) to 1200 kW / 288 W (96 W) to 2400 kW
Total reactive power (Reactive power per phase)	Q _A	2		36 VAR (12 VAR) to 240 kVAR / 120 VAR (40 VAR) to 720 kVAR / 180 VAR (60 VAR) to 1200 kVAR / 360 VAR (120 VAR) to 2400 kVAR
Total apparent power (Apparent power per phase)	S _A	2		46 VA (15 VA) to 240 kVA / 154 VA (51 VA) to 720 kVA / 231 VA (77 VA) to 1200 kVA / 461 VA (154 VA) to 2400 kVA
Active Energy: per phase, total, partial, delivered and received	E _a	1		0 to 281.109 kWh
Reactive energy: per phase, total, partial, delivered and received	E _{rA}	2		0 to 281.109 kVARh
Apparent energy: per phase, total, partial	E _{apA}	2		0 to 281.109 kVAh
Frequency	f	0.5	50 / 60 Hz ± 2 %	45 to 65 Hz
Phase current	I	1	6 to 200 A / 20 to 600 A / 30 to 1000 A / 60 to 2000 A	120 mA to 400 A / 400 mA to 1200 A / 600 mA to 2000 A / 1.2 A to 4000 A
Neutral current	I _{NC}	2		
Voltages (Line to Line)	U	0.5	Un ± 20 %	138 to 576 VAC
Power factor (per phase, total)	P _{FA}	1	From 0.5 inductive to 0.8 capacitive	-1 to 1

[1] Above 2000 m, please consult us.

[2] For higher value, please consult us.

PowerTag Energy Rope 200 A to 2000 A

Dimensions



PowerTag Energy Rope 200 A to 2000 A

Commercial Reference Numbers

Commercial reference number	Type	Description
A9MEM1592	R1000 3P/3P+N	PowerTag Energy Rope 1000 A 3P / 3P+N
A9MEM1593	R2000 3P/3P+N	PowerTag Energy Rope 2000 A 3P / 3P+N



Installation Recommendations

Operating Conditions..... B-2

Installation in Switchboards

Power Supply and Weights B-3

Safety Clearances and Minimum Distances B-4

Door Interlock for ComPacT NS630b to 1600..... B-6

Control Wiring..... B-7

Temperature Derating

ComPacT NS Circuit Breakers Equipped with Electronic Trip Units or Switch-Disconnectors..... B-8

Power Dissipation/Resistance

ComPacT NS Circuit Breakers Equipped with Electronic Trip Units or Switch-Disconnectors..... B-9

Other Chapters

Functions and Characteristics A-1

Dimensions and Connection C-1

Electrical Diagrams..... D-1


Additional Characteristics..... E-1

Catalog Numbers F-1

Installation Recommendations Operating Conditions

ComPacT circuit breakers have been tested for operation in industrial atmospheres. It is recommended that the equipment be cooled or heated to the proper operating temperature and kept free of excessive vibration and dust.

B



DB439131.ai

Altitude Derating


Altitude does not significantly affect circuit-breaker characteristics up to 2000 m. Above this altitude, it is necessary to take into account the decrease in the dielectric strength and cooling capacity of air.

The following table gives the corrections to be applied for altitudes above 2000 metres. The breaking capacities remain unchanged.

ComPacT NS630b to 3200

Altitude (m)	2000	3000	4000	5000
Impulse withstand voltage U_{imp} (kV)	8	7.1	6.4	5.6
Rated insulation voltage (U_i)	800	710	635	560
Maximum rated operational voltage 50/60 Hz U_e (V)	690	690	635	560
Rated current 40 °C	$1 \times I_n$	$0.99 \times I_n$	$0.96 \times I_n$	$0.94 \times I_n$

Intermediate values may be obtained by interpolation.



DB439132.ai


Vibrations

ComPacT NS devices resist electromagnetic or mechanical vibrations.

Tests are carried out in compliance with standard IEC 60068-2-6 for the levels required by merchant-marine inspection organizations (Bureau Veritas, Lloyd's, etc.):

- 2 → 13.2 Hz: amplitude ± 1 mm
- 13.2 → 100 Hz: constant acceleration 0.7 g.

Excessive vibration may cause tripping, breaks in connections or damage to mechanical parts.



DB439133.ai

Electromagnetic Disturbances

ComPacT NS devices are protected against:

- Overvoltages caused by devices that generate electromagnetic disturbances
- Overvoltages caused by an atmospheric disturbances or by a distribution-system outage (e.g. failure of a lighting system)
- Devices emitting radio waves (radios, walkie-talkies, radar, etc.)
- Electrostatic discharges produced by users.

ComPacT NS devices have successfully passed the electromagnetic-compatibility tests (EMC) defined by the following international standards:

- IEC 60947-2, appendix F
- IEC 60947-2, appendix B (trip units with residual earth-leakage function).

The above tests ensure that:

- No nuisance tripping occurs
- Tripping times are respected.

Installation Recommendations

Installation in Switchboards

Power Supply and Weights


Power Supply

ComPacT NS circuit breakers can be supplied from either the top or the bottom without any reduction in performance. This capability facilitates connection when installed in a switchboard.

Weights

		Circuit breaker	Chassis
NS630b to 1600 manual operation	3P	14	14
	4P	18	18
NS630b to 1600 electrical operation	3P	14	16
	4P	18	21
NS1600b to 3200	3P	24	-
	4P	36	-

The table above presents the weights (in kg) of the circuit breakers and the main accessories, which must be summed to obtain the total weight of complete configurations.



DB439134.eps

B

Installation in Switchboards

Safety Clearances and Minimum Distances

General Rules


When installing a circuit breaker, minimum distances (safety clearances) must be maintained between the device and panels, bars and other protection devices installed nearby. These distances, which depend on the ultimate breaking capacity, are defined by tests carried out in accordance with standard IEC 60947-2.

If installation conformity is not checked by type tests, it is also necessary to:


- Use insulated bars for circuit-breaker connections
- Block off the busbars using insulating screens.

ComPacT NS630b to 1600 (Fixed Devices)

Front connections



Rear connections




Insulated parts	Metal parts	Live parts
A 0	120	C 180
B 0	10	D 60

Installation Recommendations

Installation in Switchboards

Safety Clearances and Minimum Distances


ComPacT NS630b to 1600 (Withdrawable Devices)



Insulated parts	Metal parts	Live parts
A 0	0	D 30
B 10	10	E 60
C 0	0	F 30

[F] Datum, position of device mouting hole.

ComPacT NS1600b to 3200




Insulated parts	Metal parts	Live parts
A 50	170	C 230
B 0	10	D 60

Door Interlock for ComPacT NS630b to 1600

Mounted on the left or right-hand side of the chassis, this locking device prevents opening of the door if the circuit breaker is in the connected or test positions. If the circuit breaker was connected with the door open, the door may be closed without having to disconnect the circuit breaker.

B




Dimensions (mm)

Type	(1)	(2)
NS630b to 1600 (3P)	135	168
NS630b to 1600 (4P)	205	168


Device in Connected or Test Positions

Door locked



Device in Disconnected Position

Door not locked



Note: The door interlock may be mounted on either the left or right-hand side of the chassis.

F Datum

Wiring of Voltage Releases

During pick-up, the power consumed is approximately 150 to 200 VA. For low control voltages (12, 24, 48 V), maximum cable lengths are imposed by the voltage and the cross-sectional area of cables.

Recommended Maximum Cable Lengths (Meter)							
		12 V		24 V		48 V	
		2.5 mm ²	1.5 mm ²	2.5 mm ²	1.5 mm ²	2.5 mm ²	1.5 mm ²
MN	U source 100 %	–	–	58	35	280	165
	U source 85 %	–	–	16	10	75	45
MX-XF	U source 100 %	21	12	115	70	550	330
	U source 85 %	10	6	75	44	350	210

Note: the indicated length is that of each of the two wires.

24 V DC Power-Supply Module

External 24 V DC power-supply module for MicroLogic (F1-, F2+)

- It is recommended to use the AD power supply due to its low stray primary-secondary capacitance. Good operation of the MicroLogic Trip Unit in noisy environment is not guaranteed with other power supplies.
- The dedicated AD power supplies shall be used only for the MicroLogic trip units. If the COM option is used, a second dedicated power supply shall be used.
- The consumption of a MicroLogic Trip Unit is approximately 100mA.
- For MicroLogics control units alone, a number of 10 devices can be connected to the same AD power supply. Add other AD power supply for more than 10 MicroLogics.
- If the installation is shared between several panels, one AD power supply shall be added for each panel.
- AD power supply dedicated to MicroLogics trip units shall not be connected to earth. (F1-, F2+).

External 24 V DC power supply for Communication bus

- A dedicated 24 V DC power supply shall be used for the communication devices.
- Do not connect the positive terminal (E1) to earth.
- The negative terminal (E2) can be connected to earth.
- A number of communication modules (BCM, IFE, IFM, I/O, FDM...) can be connected to the same 24 V DC power supply. Refer below the devices consumption table to avoid exceeding the maximum current delivered by the 24 V DC power supply.

ULP module consumption

The table below lists the ULP module consumption.

Module	Typical Consumption (24 V DC at 20 °C/68 °F)	Maximum Consumption (19.2 V DC at 60 °C/140 °F)
BCM ULP for MasterPact and ComPacT NS	40 mA	65 mA
MicroLogic 5 or 6 trip unit for ComPacT NSX circuit breakers	30 mA	55 mA
BSCM for ComPacT NSX circuit breakers	9 mA	15 mA
2-wire RS 485 isolated repeater	15 mA	19 mA
FDM121 display for LV circuit breaker	21 mA	30 mA
IFM Modbus-SL interface for LV circuit breaker	21 mA	30 mA
IFE Ethernet interface for LV circuit breaker	120 mA	3 A (with gateway)
I/O input/output interface module for LV circuit breaker	165 mA	420 mA
Maintenance module	0 mA (the maintenance module has its own power supply)	0 mA (the maintenance module has its own power supply)

Installation recommendation

- The 24 V DC wires (output of the 24 V DC power supply) shall be twist together.
- The 24 V DC wires (output of the 24 V DC power supply) must cross all power cables perpendicularly.
- The technical characteristics of the external 24 V DC power-supply module for MicroLogic control units are indicated on [page A-30](#).

Note: Wiring of ZSI: it is recommended to use twisted shielded cable. The shield must be connected to earth at both ends.

Temperature Derating

ComPacT NS Circuit Breakers Equipped with Electronic Trip Units or Switch-Disconnectors

ComPacT circuit breakers have been tested for operation in industrial atmospheres.

It is recommended that the equipment be cooled or heated to the proper operating temperature and kept free of excessive vibration and dust.

ComPacT NS630b to NS1600 ^[1]

The table below indicates the maximum rated-current value for each type of connection, depending on the ambient temperature. For mixed connections, use the same derating values as for horizontal connections.

Version Connection temp. Ti ^[2]	Fixed device													
	Front or horizontal rear							Vertical rear						
	40	45	50	55	60	65	70	40	45	50	55	60	65	70
NS630b N/L	630	630	630	630	630	630	630	630	630	630	630	630	630	630
NS800 N/L	800	800	800	800	800	800	800	800	800	800	800	800	800	800
NS1000 N/L	1000	1000	1000	1000	1000	1000	1000	1000	1000	1000	1000	1000	1000	1000
NS1250 N	1250	1250	1250	1250	1250	1240	1090	1250	1250	1250	1250	1250	1250	1180
NS1600 N	1600	1600	1560	1510	1470	1420	1360	1600	1600	1600	1600	1600	1510	1460

Version Connection temp. Ti ^[2]	Withdrawable device													
	Front or horizontal rear							Vertical rear						
	40	45	50	55	60	65	70	40	45	50	55	60	65	70
NS630b N/L	630	630	630	630	630	630	630	630	630	630	630	630	630	630
NS800 N/L	800	800	800	800	800	800	800	800	800	800	800	800	800	800
NS1000 N/L	1000	1000	1000	1000	1000	1000	920	1000	1000	1000	1000	1000	1000	990
NS1250 N	1250	1250	1250	1250	1250	1170	1000	1250	1250	1250	1250	1250	1250	1090
NS1600 N	1600	1600	1520	1480	1430	1330	1160	1600	1600	1600	1560	1510	1420	1250

ComPacT NS1600b to 3200

Version Connection temp. Ti ^[2]	Fixed device													
	Front or horizontal rear							Vertical rear						
	40	45	50	55	60	65	70	40	45	50	55	60	65	70
NS1600b N	1600	1600	1600	1600	1500	1450	1400	1600	1600	1600	1600	1600	1550	1500
NS2000 N	2000	2000	2000	2000	1900	1800	1700	2000	2000	2000	2000	2000	1900	1800
NS2500 N	2500	2500	2500	2500	2500	2500	2500	2500	2500	2500	2500	2500	2500	2500
NS3200 N	-	-	-	-	-	-	-	3200	3200	3200	3180	3080	2970	2860

^[1] For a circuit breaker mounted in horizontal position, the derating to be applied is equivalent to that of a front or horizontal rear connected circuit breaker.

^[2] Ti: temperature around the circuit breaker and its connections.

Power Dissipation/Resistance

ComPacT NS Circuit Breakers Equipped with Electronic Trip Units or Switch-Disconnectors

The values indicated in the tables opposite are typical values.

Power dissipated per pole (P/pole) in Watts (W)

The value indicated in the table is the power dissipated at I_N , 50/60 Hz, for a three-pole or four-pole circuit breaker (these values can be higher than the power calculated on the basis of the pole resistance). Measurement and calculation of the dissipated power are carried out in compliance with the recommendations of Annex G of standard IEC 60947-2.

Resistance per pole (R/pole) in milliohms (mΩ)

The value of the resistance per pole is provided as a general indication for a new device.

The value of the contact resistance must be determined on the basis of the measured voltage drop, in accordance with the manufacturer's test procedure (expert card ABT no. FE 05e).

Note: this measurement is not sufficient to determine the quality of the contacts, i.e. the capacity of the circuit breaker to carry its rated current.

ComPacT NS630b to 1600

Version	Fixed device					
	N		L		LB	
	R/pole	P/pole	R/pole	P/pole	R/pole	P/pole
NS630b	0.026	10	0.039	15	0.056	15
NS800	0.026	15	0.039	20	0.056	20
NS1000	0.026	22	0.039	34		
NS1250	0.026	44				
NS1600	0.026	74				

Version	Withdrawable device					
	N		L		LB	
	R/pole	P/pole	R/pole	P/pole	R/pole	P/pole
NS630b	0.038	19	0.072	34	0.086	34
NS800	0.038	30	0.072	40	0.086	40
NS1000	0.038	50	0.072	77		
NS1250	0.036	84				
NS1600	0.036	154				

ComPacT NS1600b to 3200

Version	Fixed device	
	N	
	R/pole	P/pole
NS1600b	0.019	84
NS2000	0.013	84
NS2500	0.008	100
NS3200	0.008	227



Dimensions and Connection

ComPacT NS630b to 1600 (Fixed Version)

Dimensions	C-2
Mounting	C-3
Front-Panel Cutouts.....	C-4
Rotary Handle	C-5

ComPacT NS630b to 1600 (Withdrawable Version)

Dimensions, Mounting and Cutouts	C-6
Rotary Handle	C-7

ComPacT NS1600b to 3200 (Fixed Version)

Dimensions	C-8
------------------	-----

ComPacT NS630b to 3200

External Modules	C-9
------------------------	-----

FDM121 Switchboard Display

C-13

FDM128 Switchboard Display

C-14

Accessories NS630b to 3200

C-15

ComPacT NS630b to 1600 (Fixed Version)

Bars.....	C-16
Cables with Lugs and Bare Cables.....	C-19

ComPacT NS630b to 1600 (Withdrawable Versions)

Bars.....	C-20
Cables with Lugs	C-22

ComPacT NS1600b to 3200 (Fixed Version).....

C-23

Power Connections for ComPacT NS630b to 1600

Recommended Drilling Dimensions.....	C-24
--------------------------------------	------

Power Connections for ComPacT NS1600b to 3200

Recommended Drilling Dimensions.....	C-25
--------------------------------------	------

Power Connections for ComPacT NS630b to 3200

Sizing of Bars	C-28
----------------------	------

Other Chapters



Functions and Characteristics	A-1
Installation Recommendations.....	B-1
Electrical Diagrams.....	D-1
Additional Characteristics.....	E-1
Catalog Numbers	F-1

ComPacT NS630b to 1600 (Fixed Version)

Dimensions



Manual control

Front Connection (N, L)





[1] Terminal shields are optional.

Rear Connection (N, L, LB)



Electrical control

Front and Rear Connection (N, L, LB)



[F]: Datum.


Note: Dimensions for front and rear connection on electrically operated devices are identical to those for manually operated devices.

ComPacT NS630b to 1600 (Fixed Version)


Mounting

Front connection

On Backplate




On Rails




Rear connection

On Backplate



On Rails



Note: Mounting parameters for electrically operated devices are identical to those for manually operated devices.


X and **Y** are the symmetry planes for a 3-pole device

Z is the back plane of the device.

ComPacT NS630b to 1600 (Fixed Version)




Front-Panel Cutouts

Toggle control




F: Datum.
 [1] Without escutcheon.
 [2] With escutcheon.

Door Cutout




Electrical control



F: Datum.
 [1] Without escutcheon.
 [2] With escutcheon.


Door Cutout A



ComPacT NS630b to 1600 (Fixed Version) Rotary Handle


Direct rotary handle

Dimensions




Door Cutout


A



B



D




[1] Without escutcheon.


[2] With escutcheon.

Extended rotary handle

Dimensions



Door Cutout



[F]: Datum.


Note: X and Y are the symmetry planes for a 3-pole device Z is the back plane of the device.

ComPacT NS630b to 1600 (Withdrawable Version)


Dimensions, Mounting and Cutouts

Dimensions


Manual Control



Electrical Control





[1] Withdrawable position




Mounting

Bottom Mounting on Base Plate or Rails




Vertical on Uprights or Backplate




Cutouts

Door Cutout



Rear Panel Cutout



[1] Without escutcheon.

[2] With escutcheon.


[F]: Datum.

Note: X and Y are the symmetry planes for a 3-pole device.


ComPacT NS630b to 1600 (Withdrawable Version) Rotary Handle

Direct rotary handle

Dimensions




Door Cutout




Extended rotary handle

Dimensions



Door Cutout




Note: X and Y are the symmetry planes for a 3-pole device.

ComPacT NS1600b to 3200 (Fixed Version)


Dimensions

Dimensions




Door cutout (A, B, C)


A




B



C



Mounting on rails



F: Datum.

[1] Without escutcheon.

[2] With escutcheon.

C-8

Life Is On

Schneider
Electric


Note: X and Y are the symmetry planes for a 3-pole device.

Dimensions and Connection


ComPacT NS630b to 3200

External Modules


Control-wire connections to terminal block



External power-supply module (AD)




Battery module (BAT)



Chassis communication module



Modbus





ComPacT NS630b to 3200

External Modules



I/O (Input/Output) application module





IFM - Modbus-SL interface



IFE - Ethernet interface



Com'X 210/510




Dimensions and Connection

ComPacT NS630b to 3200


External Modules

External sensor for neutral

400/1600 A (NS630b to 1600)




1000/4000 A (NS1600b to 3200)




Installation

400/1600 (NS630b to NS1600)



1000/4000 A (NS1600b to NS3200)





ComPacT NS630b to 3200

External Modules

Rectangular sensor for earth leakage protection (Vigi)



280 X 115 mm Window

DB128232 eps



470 X 160 mm Window

DB128234 eps




Busbars	I ≤ 1600 A	I ≤ 3200 A
Window (mm)	280 x 115	470 x 160
Weight (kg)	14	18

Busbars path

280 X 115 mm Window


Busbars Spaced 70 mm Center-to-Center

DB128236 eps



2 bars 50 x 10

DB128238 eps




2 bars 100 x 5

470 X 160 mm Window


Busbars Spaced 115 mm Center-to-Center

DB128237 eps



4 bars 100 x 5

DB128239 eps





4 bars 125 x 5

Dimensions and Connection




FDM121 Switchboard Display

Dimensions






Mounting


Through Panel



On Panel



Connector (optional).




Dimensions and Connection

FDM128 Switchboard Display


www.se.com

Dimensions




Mounting

On Panel



Escutcheon


NS630b to NS1600 (Fixed Control)



NS630b to NS1600 (Withdrawable Control)







NS1600b to NS3200 (Fixed Control)







ComPacT NS630b to 1600 (Fixed Version) Bars

Horizontal rear connection







Vertical rear connection



View A detail.

Front connection






View A detail.

F: Datum.




Note: Recommended connection screws: **M10** class 8.8. Tightening torque: **50 Nm** with contact washer.

ComPacT NS630b to 1600 (Fixed Version) Bars

Front connection with spreaders




Rear connection with spreaders




Spreader Detail

Middle left or middle right spreader for 4P




View A detail.


Middle spreader for 3P



Left or right spreader for 4P



Left or right spreader for 3P







F: Datum.

Note: **X** and **Y** are the symmetry planes for a 3-pole device.

ComPacT NS630b to 1600 (Fixed Version) Bars

Front connection with vertical-connection adapters



View A detail.

F: Datum.

[1] two mounting possibilities for vertical-connection adapters (pitch 21 mm).


Note: Recommended connection screws: **M10** class 8.8.

Tightening torque: **50 Nm** with contact washer.


ComPacT NS630b to 1600 (Fixed Version)

Cables with Lugs and Bare Cables


Front connection with vertical-connection adapters and cable-lug adapters



Lugs






Fixed circuit breaker with 4-cable bare-cable connectors (240 mm²)






ComPacT NS630b to 1600 (Withdrawable Versions) Bars




Horizontal rear connection



Vertical rear connection



Front connection




[F]: Datum.

Note: Recommended connection screws: **M10** class 8.8. Tightening torque: **50 Nm** with contact washer.


ComPacT NS630b to 1600 (Withdrawable Versions) Bars

Front connection with spreaders



Spreader detail


Middle left or middle right spreader for 4P




View A detail.

[F]: Datum.


Middle spreader for 3P



Left or right spreader for 4P




Left or right spreader for 3P




ComPacT NS630b to 1600 (Withdrawable Versions) Cables with Lugs

Front connection with vertical-connection adapters and cable-lug adapters



Lugs



F: Datum.

Note: **X** and **Y** are the symmetry planes for a 3-pole device.




Recommended connection screws: **M10** class 8.8.

Tightening torque: **50 Nm** with contact washer.

Dimensions and Connection




ComPacT NS1600b to 3200 (Fixed Version)

Front connection (NS1600b to 2500)






View A detail.

Front connection with vertical-connection adapters (NS1600b to 2500)



View A detail.

Front connection (NS3200)



View A detail.


F: Datum.

Note: Recommended connection screws: **M10** class 8.8. Tightening torque: **50 Nm** with contact washer.




Power Connections for ComPacT NS630b to 1600

Recommended Drilling Dimensions


Rear connection




Rear connection with spreaders




Middle left or middle right spreader for 4P




Middle spreader for 3P









Left or right spreader for 4P




Left or right spreader for 3P






Vertical rear connection




Front connection





Front connection with vertical-connection adapter



Top terminal




Bottom terminal




Power Connections for ComPacT NS1600b to 3200

Recommended Drilling Dimensions


Front connection (NS1600b to 2500)



Front connection with vertical-connection adapter (NS1600b to 2500)



Front connection (NS3200)




C


Power Connections for ComPacT NS630b to 3200

C

DB4391 135.eps



DB4391 139.eps



Conductor Materials and Electrodynamic Stresses

ComPacT circuit breakers can be connected indifferently with bare-copper, tinned-copper and tinned-aluminium conductors (flexible or rigid bars, cables). In the event of a short-circuit, thermal and electrodynamic stresses will be exerted on the conductors. They must therefore be correctly sized and maintained in place using supports.

Electrical connection points on all types of devices (switch-disconnectors, contactors, circuit breakers, etc.) should not be used for mechanical support. Any partition between upstream and downstream connections of the device must be made of non-magnetic material.

Ties for Flexible Bars and Cables


The table below indicates the maximum distance between ties depending on the prospective short-circuit current.

The maximum distance between ties attached to the switchboard frame is 400 mm.


Type of tie	"Panduit" ties			"Sarel" ties				
	Width: 4.5 mm			Width: 9 mm				
	Maximum load: 22 kg			Maximum load: 90 kg				
	Color: white			Color: black				
Maximum distance between ties (mm)	200	100	50	350	200	100	70	50 (double ties)
Short-circuit current (kA rms)	10	15	20	20	27	35	45	100

Note: For cables $\geq 50 \text{ mm}^2$, use 9 mm-wide ties.

DB4391 136.eps



DB4391 137.eps



Connection of Bars

Bars must be adjusted to ensure correct positioning on the terminals before bolting (B). Bars must rest on a support firmly attached to the switchboard frame, such that the circuit breaker terminals do not bear any weight (C).


Electrodynamic forces

The first spacer between bars must be positioned within a maximum distance (see table below) of the connection point to the circuit breaker. This distance is calculated to resist the electrodynamic stresses exerted between the bars of each phase during a short-circuit.


Maximum distance A between the circuit breaker connection and the first spacer between bars, depending on the short-circuit current

I _{sc} (kA)	30	50	65	80	100	150
Distance (mm)	350	300	250	150	150	150

DB4391 139.eps



DB4391 140.eps



Power Connections for ComPacT NS630b to 3200

Connections


The quality of bar connections depends, among other things, on the tightening torques used for the nuts and bolts. Over-tightening may have the same consequences as under-tightening.

The correct tightening torques for the connection of bars to the circuit breaker terminals are indicated in the table below.

The values below are for copper bars (Cu ETP-NFA51-100) and steel nuts and bolts (class 8.8).

The same values apply to AGS-T52 quality aluminium bars (French standard NFA 02-104 and American National Standard H-35-1).

Examples of bar connections




Tightening torque for bars


Rated diameter (mm)	Drilling (mm) diameter	Tightening torque (Nm) with flat or grower washers	Tightening torque (Nm) with contact or split washers
10	11	37.5	50

Bar Drilling

Examples



Insulation Distance




Dimensions (mm)

Utilization voltage	X minimum
$U_i \leq 600 \text{ V}$	8 mm
$U_i \leq 1000 \text{ V}$	14 mm


Bar Bending

Bars must be bent according to the table below. A tighter bend may cause cracks.



Dimensions (mm)

e	Radius r Minimum	Recommended
5	5	7.5
10	15	18 to 20



- 1 Terminal screws, factory tightened to 13 Nm
- 2 Circuit breaker terminal
- 3 Bars
- 4 Bolt
- 5 Washer
- 6 Nut

C

Power Connections for ComPacT NS630b to 3200


Sizing of Bars

The following tables are based on the following assumptions:

- Maximum permissible temperature of bars is 100 °C
- Ti: temperature around the circuit breaker and its connections
- Busbars made of copper and not painted.

Note: The values presented in the tables are the result of trials and theoretical calculations on the basis of the assumptions mentioned above. These tables are provided to help design connections, however, the actual values must be confirmed by tests on the installation.

Front or Horizontal Rear Connections



ComPacT	Maximum service current	Ti: 40 °C				Ti: 50 °C				Ti: 60 °C			
		Nb of bars	5 mm thick	Nb of bars	10 mm thick	Nb of bars	5 mm thick	Nb of bars	10 mm thick	Nb of bars	5 mm thick	Nb of bars	10 mm thick
NS630b	400	2	30 x 5	1	30 x 10	2	30 x 5	1	30 x 10	2	30 x 5	1	30 x 10
NS630b	630	2	40 x 5	1	40 x 10	2	40 x 5	1	40 x 10	2	40 x 5	1	40 x 10
NS800	800	2	50 x 5	1	50 x 10	2	50 x 5	1	50 x 10	2	50 x 5	1	63 x 10
NS1000	1000	3	50 x 5	1	63 x 10	3	50 x 5	2	50 x 10	3	63 x 5	2	50 x 10
NS1250	1250	3	50 x 5	2	40 x 10	3	50 x 5	2	50 x 10	3	63 x 5	2	50 x 10
NS1600/1600b	1400	2	80 x 5	2	40 x 10	2	80 x 5	2	50 x 10	3	80 x 5	2	63 x 10
NS1600/1600b	1600	3	80 x 5	2	63 x 10	3	80 x 5	2	63 x 10	3	80 x 5	3	50 x 10
NS2000	1800	3	80 x 5	2	63 x 10	3	80 x 5	2	63 x 10	3	100 x 5	2	80 x 10
NS2000	2000	3	100 x 5	2	80 x 10	3	100 x 5	2	80 x 10	3	100 x 5	3	63 x 10
NS2500	2200	3	100 x 5	2	80 x 10	3	100 x 5	2	80 x 10	4	80 x 5	2	100 x 10
NS2500	2500	4	100 x 5	2	100 x 10	4	100 x 5	2	100 x 10	4	100 x 5	3	80 x 10
NS3200	2800	4	100 x 5	3	80 x 10	4	100 x 5	3	80 x 10	5	100 x 5	3	100 x 10
NS3200	3000	5	100 x 5	3	80 x 10	6	100 x 5	3	100 x 10	8	100 x 5	4	80 x 10
NS3200	3200	6	100 x 5	3	100 x 10	8	100 x 5	3	100 x 10			4	100 x 10


Note: With ComPacT NS630b to NS1600, it is recommended to use 50 mm wideness bars (see "Recommended busbars drilling").

Power Connections for ComPacT NS630b to 3200

Sizing of Bars

Vertical rear connections

DB123371.eps



ComPacT	Maximum service current	Ti: 40 °C				Ti: 50 °C				Ti: 60 °C			
		Nb of bars	5 mm thick	Nb of bars	10 mm thick	Nb of bars	5 mm thick	Nb of bars	10 mm thick	Nb of bars	5 mm thick	Nb of bars	10 mm thick
NS630b	400	2	30 x 5	1	30 x 10	2	30 x 5	1	30 x 10	2	30 x 5	1	30 x 10
NS630b	630	2	40 x 5	1	40 x 10	2	40 x 5	1	40 x 10	2	40 x 5	1	40 x 10
NS800	800	2	50 x 5	1	50 x 10	2	50 x 5	1	50 x 10	2	50 x 5	1	50 x 10
NS1000	1000	2	50 x 5	1	50 x 10	2	50 x 5	1	50 x 10	2	63 x 5	1	63 x 10
NS1250	1250	2	63 x 5	1	63 x 10	3	50 x 5	2	40 x 10	3	50 x 5	2	40 x 10
NS1600	1400	2	80 x 5	1	80 x 10	2	80 x 5	2	50 x 10	3	63 x 5	2	50 x 10
NS1600	1600	3	63 x 5	2	50 x 10	3	63 x 5	2	50 x 10	3	80 x 5	2	63 x 10
NS2000	2000	3	100 x 5	2	63 x 10	3	100 x 5	2	63 x 10	3	100 x 5	2	80 x 10
NS2500	2500	4	100 x 5	2	80 x 10	4	100 x 5	2	80 x 10	4	100 x 5	3	80 x 10
NS3200	3200	6	100 x 5	3	100 x 10	6	100 x 5	3	100 x 10			4	100 x 10

C



Electrical Diagrams

ComPacT NS630b to 1600
Fixed Circuit Breakers..... D-2
Withdrawable Circuit Breakers D-4

ComPacT NS1600b to 3200
Fixed Circuit Breakers..... D-6

ComPacT NS630b to 3200
Earth-Fault and Earth-Leakage Protection
Neutral Protection Zone Selective Interlocking D-8
Communication..... D-10

Fixed, Electrically Operated ComPacT NS630b to 3200
Connection to the Communication Interface Module..... D-11
Connection to the I/O Application Module and Communication
Interface Module..... D-12

ComPacT NS630b to 3200
24 V DC External Power Supply AD Module..... D-13




Other Chapters
Functions and Characteristics A-1
Installation Recommendations..... B-1
Dimensions and Connection C-1
Additional Characteristics..... E-1
Catalog Numbers F-1

Electrical diagrams

ComPacT NS630b to 1600

Fixed Circuit Breakers

The diagram is shown with circuits de-energized, all devices open, connected and charged and relays in the normal position.



Basic	A	E	P	Control unit
<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	E1-E6 communication
	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	Z1-Z5 zone selective interlocking: Z1 = ZSI OUT SOURCE Z2 = ZSI OUT ; Z3 = ZSI IN SOURCE Z4 = ZSI IN ST (short time) Z5 = ZSI IN GF (earth fault)
	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	M1 = Vigi module input (MicroLogic 7)
	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	T1, T2, T3, T4 = external neutral;
	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	M2, M3 = Vigi module input (MicroLogic 7)
	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	F2+, F1- external 24 V DC power supply
	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	VN external voltage connector (must be connected to the neutral with a 3P circuit breaker)


E: energy
A: digital ammeter.
P: A + power meter + additional protection.

Remote operation

M : undervoltage release
or
MX: shunt release

Motor-mechanism module ^[1]
A4: electrical opening order
A2: electrical closing order
B4, A1: power supply for control devices and gear motor

[1] Spring-charging motor 440/480 V AC (380 V motor + additional resistor)




Electrical diagrams


ComPacT NS630b to 1600

Fixed Circuit Breakers

Indication contacts



Terminal-block marking (manual operation)



Indication contacts

OF3/OF2/OF1: indication contacts


SDE: fault-trip indication contact (short-circuit, overload, earth fault)

SD: trip indication contact (manual operation)

CAF2/CAF1: early-make contact (rotary handle)

CAO2/CAO1: early-break contact (rotary handle)

Terminal-block marking (electrical operation)



Electrical diagrams

ComPacT NS630b to 1600


Withdrawable Circuit Breakers

The diagram is shown with circuits de-energized, all devices open, connected and charged and relays in the normal position.

Power


Control unit

Remote operation



Terminal-block marking

Control unit						
Com	UC1	UC2	UC3	CAF2		
o o	o o	o o	o o	o o		
E5 E6	Z5 M1	M2 M3	F2+	544		
o o	o o	o o	o o	o o		
E3 E4	Z3 Z4	T3 T4	VN	542		
o o	o o	o o	o o	o o		
E1 E2	Z1 Z2	T1 T2	F1 -	541		



Remote operation			
MN / MX	MT2	MT1	
o o / o o	o o	o o	
D2 C2	A4	A2	
		o o	
		B4	
o o / o o		o o	
D1 C1		A1	

Basic	A	E	P	Control unit
<input checked="" type="radio"/>	<input checked="" type="radio"/>	<input checked="" type="radio"/>	<input checked="" type="radio"/>	Com: E1-E6 communication
<input checked="" type="radio"/>	<input checked="" type="radio"/>	<input checked="" type="radio"/>	<input checked="" type="radio"/>	UC1: Z1-Z5 zone selective interlocking: Z1 = ZSI OUT SOURCE Z2 = ZSI OUT; Z3 ZSI IN SOURCE Z4 = ZSI IN ST (short time) Z5 = ZSI IN GF (earth fault)
<input checked="" type="radio"/>	<input checked="" type="radio"/>	<input checked="" type="radio"/>	<input checked="" type="radio"/>	M1 = Vigi module input (MicroLogic 7)
<input checked="" type="radio"/>	<input checked="" type="radio"/>	<input checked="" type="radio"/>	<input checked="" type="radio"/>	UC2: T1, T2, T3, T4 = external neutral; M2, M3 = Vigi module input (MicroLogic 7)
<input checked="" type="radio"/>	<input checked="" type="radio"/>	<input checked="" type="radio"/>	<input checked="" type="radio"/>	UC3: F2+, F1- external 24 V DC power supply VN external voltage connector (must be connected to the neutral with a 3P circuit breaker)

Remote operation	
MN: undervoltage release or MX: shunt release	
Motor-mechanism module	
MT2: A4: electrical opening order	
MT1: A2: electrical closing order B4, A1: power supply for control devices and gear motor (MCH)	


A: digital ammeter.
E: energy.
P: A + power meter + additional protection.

Electrical diagrams


ComPacT NS630b to 1600

Withdrawable Circuit Breakers

Indication contacts



Carriage switches



Indication contacts

CAF2	CAF1	SDE	SD	CAO2	CAO1	OF3	OF2	OF1
544	534	84	94	524	514	34	24	14
542	532	82	92	522	512	32	22	12
541	531	81	91	521	511	31	21	11

Carriage switches

CD2	CD1	CE3	CE2	CE1	CT1
824	814	334	324	314	914
822	812	332	322	312	912
821	811	331	321	311	911

Indication contacts

OF3/OF2/OF1: indication contacts

SDE: fault-trip indication contact (short-circuit, overload, earth fault)

SD: trip indication contact (manual operation)

CAF2/CAF1: early-make contact (rotary handle)

CAO2/CAO1: early-break contact (rotary handle)

Carriage switches

CD2: disconnected

CD1: position

CE3: connected

CE2: position

CE1

CT1: test position

Legend


Connected (only one wire per connection point)

Life Is On

Schneider
Electric

Fixed Circuit Breakers

The diagram is shown with circuits de-energized, all devices open, connected and charged and relays in the normal position.



MN: undervoltage release
or
MX: shunt release


A: digital ammeter.

Electrical diagrams


ComPacT NS1600b to 3200

Fixed Circuit Breakers

Indication contacts



Terminal-block marking



Indication contacts

OF3/OF2/OF1: ON/OFF indication contacts

SDE: fault-trip indication contact (short-circuit, overload, earth fault)

SD: trip indication contact

ComPacT NS630b to 3200

Earth-Fault and Earth-Leakage Protection

Neutral Protection Zone Selective Interlocking

External sensor (CT) for residual earth-fault protection

Connection of current-transformer secondary circuit for external neutralComPacT equipped with a MicroLogic 6 A/E/P ^[1]:

- Shielded cable with 2 twisted pairs
- T1 twisted with T2
- Maximum length 4 meters
- Cable cross-sectional area 0.4 to 1.5 mm²
- Recommended cable: Belden 9552 or equivalent.

For proper wiring of neutral CT, refer to instruction Bulletin 48041-082-03 shipped with it.


Do not remove MicroLogic factory-installed jumper between T1 and T2 unless neutral CT is connected.

If supply is via the top, follow the schematics.

If supply is via the bottom, control wiring is identical; for the power wiring, H1 is connected to the source side, H2 to the load side.

For four-pole versions, for residual earth-fault protection, the current transformer for the external neutral is not necessary.

Connection for signal VN is required only for power measurements (3 Ø, 4 wires, 4CTs).


^[1] Only for NS630b to 1600.

External transformer for source ground return (SGR) earth-fault protection

Connection of the secondary circuitComPacT equipped with a MicroLogic 6 A/E/P ^[1]:

unshielded cable with 1 twisted pair

- Maximum length 150 metres
- Cable cross-sectional area 0.4 to 1.5 mm²
- Recommended cable: Belden 9409 or equivalent.

^[1] Only for NS630b to 1600.

ComPacT NS630b to 3200


Earth-Fault and Earth-Leakage Protection

Neutral Protection Zone Selective Interlocking

Earth-leakage protection

Connection of the rectangular-sensor secondary circuit

ComPacT equipped with a MicroLogic 7 A/P:
use the cable shipped with the rectangular sensor.



Neutral protection

- Three pole circuit breaker:
 - Neutral protection is impossible with MicroLogic A,E
 - With MicroLogic P, an external neutral transformer is necessary; the connection diagram is the same as for residual earth-fault protection.
- Four pole circuit breaker:
 - ComPacT equipped with MicroLogic A,E,P
 - The current transformer for external neutral is not necessary.

Zone selective interlocking

Zone-selective interlocking is used to reduce the electrodynamic forces exerted on the installation by shortening the time required to clear faults, while maintaining time selectivity between the various devices.

A pilot wire interconnects a number of circuit breakers equipped with MicroLogic A/E/P control units, as illustrated in the diagram above.

The control unit detecting a fault sends a signal upstream and checks for a signal arriving from downstream. If there is a signal from downstream, the circuit breaker remains closed for the full duration of its tripping delay. If there is no signal from downstream, the circuit breaker opens immediately, regardless of the tripping-delay setting.

Fault 1


Only circuit breaker A detects the fault. Because it receives no signal from downstream, it immediately opens in spite of its tripping delay set to 0.3.

Fault 2

Circuit breakers A and B detect the fault. Circuit breaker A receives a signal from B and remains closed for the full duration of its tripping delay set to 0.3. Circuit breaker B does not receive a signal from downstream and opens immediately, in spite of its tripping delay set to 0.2.

Wiring


- Maximum impedance: 2.7 Ω /300 m.
- Capacity of connectors: 0.4 to 2.5 mm².
- Wires: single or multicore.
- Maximum length: 3000 m.
- Limits to device interconnection:
 - The common ZSI - OUT (Z1) and the output ZSI - OUT (Z2) can be connected to a maximum of 10 upstream device
 - A maximum of 100 downstream devices may be connected to the common ZSI - IN (Z3) and to an input ZSI - IN CR (Z4) or GF (Z5).



ComPacT NS630b to 3200

Communication

Connection of circuit breakers to the Modbus communication network




[1] Modbus termination is mandatory, see ULP system user guide TRV99101.

Fixed, Electrically Operated ComPacT NS630b to 3200

Connection to the Communication Interface Module


DB432548.eps



Withdrawable ComPacT NS630b to 3200

Connection to the I/O Application Module and Communication Interface Module

DE432548 eps



ComPacT NS630b to 3200

24 V DC External Power Supply AD Module

- With MicroLogic, it is recommended to connect 24 V DC external power supply (AD module) to the MicroLogic control unit (F1- F2+) in order
 - To keep available the display and the energy metering, even if Current < 20 % In.
 - To use the display even if the circuit breaker is open or not supplied (for the exact conditions of use, see the “electrical diagrams” part of this catalog)
 - To display fault currents after tripping
 - To modify settings when the circuit breaker is open (OFF position).
- The same 24 V DC external power supply can be used for the micrologic control unit and the communication devices (IFE, IFM, I/O, FDM).
- The 24 V DC external power supply (AD module) for the MicroLogic control unit (F1- F2+) is not required for basic protections LSIG.
- The 24 V DC external power supply for the BCM ULP communication module (E1-E2) is required. The same 24 V DC external power supply can be used for the communication devices (IFE, IFM, I/O, FDM).
- If the 24 V DC external power supply (AD module) is used to supply MicroLogic control unit, this power supply shall be used only for supplying MicroLogic control unit and M2C.
- The dedicated AD power supply shall be used only for the MicroLogic trip unit. If the COM option is used, a second dedicated 24 V DC external power supply shall be used.

Note: Case of using the 24 V DC external power supply (AD module), maximum cable length between 24 V DC (G1, G2) and the control unit (F1-, F2+) must not exceed 10 meters. The internal voltage taps are connected to the bottom side of the circuit breaker.

An external voltage taps are possible using the PTE option:

- With this option, the internal voltage taps are disconnected and the voltage taps are connected to terminals VN, V1, V2, V3.
- The PTE option is required for voltages less than 220 V and greater than 690 V (in which case a voltage transformer is compulsory). For three-pole devices, the system is supplied with terminal VN connected only to the control unit.
- When the PTE option is implemented, the voltage measurement input must be protected against short-circuits. Installed as close as possible to the busbars, this protection function is ensured by a P25M circuit breaker (1 A rating) with an auxiliary contact (cat. no. 21104 and 21117).
- This voltage measurement input is reserved exclusively for the control unit and must not ever be used to supply other circuits outside the switchboard.

Connection


The maximum length for each conductor supplying power to the trip unit module is 10 m.

Do not ground F2+, F1-, or power supply output:

- The positive terminal (F2+) on the trip unit must not be connected to earth ground
- The negative terminal (F1-) on the trip unit must not be connected to earth ground
- The output terminals (- and +) of the 24 V DC power supply must not be grounded.

Reduce electromagnetic interference:

- The input and output wires of the 24 V DC power supply must be physically separated as much as possible
- The 24 V DC wires (output of the 24 V DC power supply) shall be twisted together
- The 24 V DC wires (output of the 24 V DC power supply) must cross all power cables perpendicularly
- Power supply conductors must be cut to length. Do not loop excess conductor.



DB432611 eps

D



Additional Characteristics

Tripping Curves

ComPacT NS630b to 3200 E-2

Current-Limiting Curves E-3

E

Other Chapters


Functions and Characteristics	A-1
Installation Recommendations.....	B-1
Dimensions and Connection	C-1
Electrical Diagrams	D-1
Catalog Numbers	F-1

Tripping Curves


ComPacT NS630b to 3200

MicroLogic Electronic Control Units


MicroLogic 2.0



MicroLogic 5.0, 6.0, 7.0



Earth-Fault Protection (MicroLogic 6.0)



[1]

$I_g = I_n \times \dots$	A	B	C	D	E	F	G	H	J
$I_n < 400 A$	0.3	0.3	0.4	0.5	0.6	0.7	0.8	0.9	1
$400 A \leq I_n \leq 1200 A$	0.2	0.3	0.4	0.5	0.6	0.7	0.8	0.9	1
$I_n > 1200 A$	500	640	720	800	880	960	1040	1120	1200

The limiting capacity of a circuit breaker is its aptitude to limit short-circuit currents.

Ics = 100 % Icu

The exceptional limiting capacity of the ComPacT NS range greatly reduces the forces created by fault currents in devices.

The result is a major increase in breaking performance. In particular, the service breaking capacity Ics is equal to 100 % of Icu for limiter circuit breaker.

The Ics value, defined by IEC standard 60947-2, is guaranteed by tests comprising the following operations:

- Break three times consecutively a fault current equal to 100 % of Icu
- Check that the device continues to function normally:
 - It conducts the rated current without abnormal temperature rise
 - Protection functions perform within the limits specified by the standard
 - Suitability for isolation is not impaired.

Longer Service Life of Electrical Installations

Current-limiting circuit breakers greatly reduce the negative effects of short-circuits on installations.

Thermal effects

Less temperature rise in conductors, therefore longer service life for cables.

Mechanical effects

Reduced electrodynamic forces, therefore less risk of electrical contacts or busbars being deformed or broken.

Electromagnetic effects

Less disturbances for measuring devices located near electrical circuits.

Economy by Means of Cascading

Cascading is a technique directly derived from current limiting. Circuit breakers with breaking capacities less than the prospective short-circuit current may be installed downstream of a limiting circuit breaker. The breaking capacity is reinforced by the limiting capacity of the upstream device.

It follows that substantial savings can be made on downstream equipment and enclosures.

Current-Limiting Curves


The current-limiting capacity of a circuit breaker is expressed by two curves which are a function of the prospective short-circuit current (the current which would flow if no protection devices were installed):

- The actual peak current (limited current),
- Thermal stress (A^2s), i.e. the energy dissipated by the short-circuit in a conductor with a resistance of 1Ω .

Example

What is the real value of a 200 kA rms prospective short-circuit (i.e. 440 kA peak) limited by an NS630bLB upstream ?

Answer: 70 kA peak (see next page).



The exceptional limiting capacity of the ComPacT NS range is due to the rotating double-break technique (very rapid natural repulsion of contacts and the appearance of two arc voltages in-series with a very steep wave front).

Additional Characteristics


Current-Limiting Curves

www.se.com

Current-Limiting Curves


Voltage 400/440 V AC ⁽¹⁾

Limited short-circuit current (kA peak)



Voltage 660/690 V AC


Limited short-circuit current (kA peak)



Thermal-Stress Curves


Voltage 400/440 V AC ^[1]

Limited energy



Voltage 660/690 V AC

Limited energy




^[1] Valid for 480 V Nema.

Catalog Numbers and Order Forms

NS630b to NS1600 Fixed Manually Operated	
Complete Device	F-2
Device Based on Separate Components.....	F-4
NS630b to NS1600 Fixed Electrically Operated	
Device Based on Separate Components.....	F-5
NS630b to NS1600 Manually Operated Withdrawable Devices	
Device Based on Separate Components.....	F-6
NS630b to NS1600 Electrically Operated Withdrawable Devices	
Device Based on Separate Components.....	F-7
Accessories for NS630b to NS1600 Fixed Devices....	
Accessories for NS630b to NS1600 Withdrawable Devices	
	F-9
Accessories for NS630b to NS1600 Fixed and Withdrawable Devices	
Mechanical Interlocking.....	F-12
Communication Option for NS630b to NS1600 Fixed and Withdrawable Devices.....	
	F-13
NS1600b to NS3200 Fixed, Front-Connected, Manually Operated Device	
	F-15
Accessories for NS1600b to NS3200	
	F-16
Spare Parts: NS630b to NS1600 Fixed Circuit Breaker	
Connection.....	F-18
Electrical Auxiliaries and Installation Accessories	F-19
MicroLogic Control Unit, External Sensor	F-20
Locking and Accessories	F-21
Spare Parts: NS630b to NS1600 Fixed and Withdrawable Circuit Breaker	
Mechanical Interlocking for Source Changeover	F-22
Spare Parts: NS630b to NS1600 Withdrawable Circuit Breaker	
Connection.....	F-23
Electrical Auxiliaries	F-24
Installation Accessories	F-25
MicroLogic Control Unit, External Sensor	F-26
Locking and Accessories	F-27
Chassis Locking and Accessories Mechanical Interlocking for Source Changeover	F-28
Spare Parts: Communication Bus Accessories, Monitoring and Control, Ethernet Gateway	
	F-29
Spare Parts: ComPacT NS1600b to 3200	
Connection, Locking and Installation Accessories	F-30
MicroLogic Control Unit, External Sensor	F-31
Order Form: ComPacT NS630b to NS3200	
Circuit Breakers and Switch-Disconnectors	F-32

NS630b to NS1600 Fixed Manually Operated Complete Device

Front-Connected Circuit Breaker with MicroLogic 2.0 Control Unit



ComPacT NS type N

Icu = 50 kA at 220/415 V

	3P	4P
NS630b	C063N320FM	C063N420FM
NS800	C080N320FM	C080N420FM
NS1000	C100N320FM	C100N420FM
NS1250	C125N320FM	C125N420FM
NS1600	C160N320FM	C160N420FM

ComPacT NS type H

Icu = 70 kA at 220/415 V


	3P	4P
NS630b	C063H320FM	C063H420FM
NS800	C080H320FM	C080H420FM
NS1000	C100H320FM	C100H420FM
NS1250	C125H320FM	C125H420FM
NS1600	C160H320FM	C160H420FM

ComPacT NS type L

Icu = 150 kA at 220/415 V

	3P	4P
NS630b	C063L320FM	C063L420FM
NS800	C080L320FM	C080L420FM
NS1000	C100L320FM	C100L420FM

Front-Connected Circuit Breaker with MicroLogic 5.0 Control Unit



ComPacT NS type N

Icu = 50 kA at 220/415 V

	3P	4P
NS630b	C063N350FM	C063N450FM
NS800	C080N350FM	C080N450FM
NS1000	C100N350FM	C100N450FM
NS1250	C125N350FM	C125N450FM
NS1600	C160N350FM	C160N450FM

ComPacT NS type H

Icu = 70 kA at 220/415 V


	3P	4P
NS630b	C063H350FM	C063H450FM
NS800	C080H350FM	C080H450FM
NS1000	C100H350FM	C100H450FM
NS1250	C125H350FM	C125H450FM
NS1600	C160H350FM	C160H450FM

ComPacT NS type L

Icu = 150 kA at 220/415 V

	3P	4P
NS630b	C063L350FM	C063L450FM
NS800	C080L350FM	C080L450FM
NS1000	C100L350FM	C100L450FM

Front-Connected Circuit Breaker with MicroLogic 6.0 Control Unit



ComPacT NS type N

Icu = 50 kA at 220/415 V

	3P	4P
NS630b	C063N360FM	C063N460FM
NS800	C080N360FM	C080N460FM
NS1000	C100N360FM	C100N460FM
NS1250	C125N360FM	C125N460FM
NS1600	C160N360FM	C160N460FM


ComPacT NS type H

Icu = 70 kA at 220/415 V

	3P	4P
NS630b	C063H360FM	C063H460FM
NS800	C080H360FM	C080H460FM
NS1000	C100H360FM	C100H460FM
NS1250	C125H360FM	C125H460FM
NS1600	C160H360FM	C160H460FM


NS630b to NS1600 Fixed Manually Operated Complete Device

Front-Connected Circuit Breaker with MicroLogic 2.0 A Control Unit




ComPacT NS type N			
Icu = 50 kA at 220/415 V	3P		4P
NS630b	C063N32AFM		C063N42AFM
NS800	C080N32AFM		C080N42AFM
NS1000	C100N32AFM		C100N42AFM
NS1250	C125N32AFM		C125N42AFM
NS1600	C160N32AFM		C160N42AFM
ComPacT NS type H			
Icu = 70 kA at 220/415 V	3P		4P
NS630b	C063H32AFM		C063H42AFM
NS800	C080H32AFM		C080H42AFM
NS1000	C100H32AFM		C100H42AFM
NS1250	C125H32AFM		C125H42AFM
NS1600	C160H32AFM		C160H42AFM
ComPacT NS type L			
Icu = 150 kA at 220/415 V	3P		4P
NS630b	C063L32AFM		C063L42AFM
NS800	C080L32AFM		C080L42AFM
NS1000	C100L32AFM		C100L42AFM

Front-Connected Circuit Breaker with MicroLogic 5.0 A Control Unit




ComPacT NS type N			
Icu = 50 kA at 220/415 V	3P		4P
NS630b	C063N35AFM		C063N45AFM
NS800	C080N35AFM		C080N45AFM
NS1000	C100N35AFM		C100N45AFM
NS1250	C125N35AFM		C125N45AFM
NS1600	C160N35AFM		C160N45AFM
ComPacT NS type H			
Icu = 70 kA at 220/415 V	3P		4P
NS630b	C063H35AFM		C063H45AFM
NS800	C080H35AFM		C080H45AFM
NS1000	C100H35AFM		C100H45AFM
NS1250	C125H35AFM		C125H45AFM
NS1600	C160H35AFM		C160H45AFM
ComPacT NS type L			
Icu = 150 kA at 220/415 V	3P		4P
NS630b	C063L35AFM		C063L45AFM
NS800	C080L35AFM		C080L45AFM
NS1000	C100L35AFM		C100L45AFM

Fixed Front Connected MicroLogic 2.0 E




ComPacT NS type N			
	3P		4P
NS630b	C063N32EFM		C063N42EFM
NS800	C080N32EFM		C080N42EFM
NS1000	C100N32EFM		C100N42EFM
NS1250	C125N32EFM		C125N42EFM
NS1600	C160N32EFM		C160N42EFM
ComPacT NS type H			
	3P		4P
NS630b	C063H32EFM		C063H42EFM
NS800	C080H32EFM		C080H42EFM
NS1000	C100H32EFM		C100H42EFM
NS1250	C125H32EFM		C125H42EFM
NS1600	C160H32EFM		C160H42EFM

Fixed Front Connected MicroLogic 5.0 E



ComPacT NS type N			
	3P		4P
NS630b	C063N35EFM		C063N45EFM
NS800	C080N35EFM		C080N45EFM
NS1000	C100N35EFM		C100N45EFM
NS1250	C125N35EFM		C125N45EFM
NS1600	C160N35EFM		C160N45EFM
ComPacT NS type H			
	3P		4P
NS630b	C063H35EFM		C063H45EFM
NS800	C080H35EFM		C080H45EFM
NS1000	C100H35EFM		C100H45EFM
NS1250	C125H35EFM		C125H45EFM
NS1600	C160H35EFM		C160H45EFM

Front-Connected Switch-Disconnecter



	3P		4P
NS630b	C063S3NAFM		C063S4NAFM
NS800	C080S3NAFM		C080S4NAFM
NS1000	C100S3NAFM		C100S4NAFM
NS1250	C125S3NAFM		C125S4NAFM
NS1600	C160S3NAFM		C160S4NAFM


Note: select in addition the connection accessories, device accessories and auxiliaries, control-unit accessories and communications option, as required.

NS630b to NS1600 Fixed Manually Operated Device Based on Separate Components

Basic Circuit Breaker

A ComPacT fixed manually operated circuit breaker is composed of 4 catalog references corresponding to:

- The basic circuit breaker
- A control unit
- The top connection
- The bottom connection.



ComPacT NS type N		
Icu = 50 kA at 220/415 V	3P	4P
NS630b	C063N3FM	C063N4FM
NS800	C080N3FM	C080N4FM
NS1000	C100N3FM	C100N4FM
NS1250	C125N3FM	C125N4FM
NS1600	C160N3FM	C160N4FM

ComPacT NS type H		
Icu = 70 kA at 220/415 V	3P	4P
NS630b	C063H3FM	C063H4FM
NS800	C080H3FM	C080H4FM
NS1000	C100H3FM	C100H4FM
NS1250	C125H3FM	C125H4FM
NS1600	C160H3FM	C160H4FM

ComPacT NS type L		
Icu = 150 kA at 220/415 V	3P	4P
NS630b	C063L3FM	C063L4FM
NS800	C080L3FM	C080L4FM
NS1000	C100L3FM	C100L4FM

ComPacT NS type LB		
Icu = 200 kA at 400/415 V	3P	4P
NS630b	C063B3FM	C063B4FM
NS800	C080B3FM	C080B4FM

MicroLogic control units Without "measurement"		
MicroLogic 2.0	basic protection	3P/4P C20FM
MicroLogic 5.0	selective protection	C50FM
MicroLogic 6.0	selective + earth-fault protection	C60FM

"ammeter" A

MicroLogic 2.0 A	basic protection	3P/4P C2AFM
MicroLogic 5.0 A	selective protection	C5AFM
MicroLogic 6.0 A	selective + earth-fault protection	C6AFM
MicroLogic 7.0 A	selective + earth-leakage protection	C7AFM

"energy" E ^[1]


MicroLogic 2.0 E	basic protection	3P/4P C2EFM
MicroLogic 5.0 E	selective protection	C5EFM
MicroLogic 6.0 E	selective + earth-fault protection	C6EFM

"power meter" P ^[1]

MicroLogic 5.0 P	selective protection	3P/4P C5PFM
MicroLogic 6.0 P	selective + earth-fault protection	C6PFM
MicroLogic 7.0 P	selective + earth-leakage protection	C7PFM


[1] In case of an installation 3P + Neutral, please add ENVT device ref. 65317 (see page F-13).

Basic Switch-Disconnecter



ComPacT NS type NA		
NS630b	3P C063S3FM	4P C063S4FM
NS800	C080S3FM	C080S4FM
NS1000	C100S3FM	C100S4FM
NS1250	C125S3FM	C125S4FM
NS1600	C160S3FM	C160S4FM

Connections for Circuit Breakers and Switch-Disconnectors



Front connection		
630-1000 A - NA/N/H	Top	3P 33598
	Bottom	33599
1250 A - NA/N/H	Top	33600
630-1000 A - L	Bottom	33601
1600 A - NA/N/H	Top	33602
	Bottom	33603
33608		33609
33610		33611
33612		33613
Rear connection		
Vertical NA/N/H/L/LB	Top	3P 33604
	Bottom	33605
Horizontal	Top	33606
NA/N/H/L/LB	Bottom	33607
33614		33615
33616		33617

Note: to order a complete device, order:


- a basic circuit breaker and a MicroLogic control unit, or a basic switch disconnector.
- connections.
- accessories (for the device, the connection, the control unit) and communication option as required.

NS630b to NS1600 Fixed Electrically Operated Device Based on Separate Components

Basic Circuit Breaker

A ComPacT fixed electrically operated circuit breaker is composed of 5 catalog references corresponding to:

- The basic circuit breaker
- A control unit
- The top connection
- The bottom connection
- The motor mechanism module.



Note: the characteristics of the motor mechanism module for electrical operation are specified separately by selecting a part number from the table at the bottom of this page.

[1] In case of an installation 3P + Neutral, please add ENVT device ref. 65317 (see page F-13).

ComPacT NS type N

Icu = 50 kA at 220/415 V	3P	4P
NS630b	33270	33274
NS800	33280	33284
NS1000	33290	33294
NS1250	33300	33304
NS1600	33310	33314

ComPacT NS type H

Icu = 70 kA at 220/415 V	3P	4P
NS630b	33271	33275
NS800	33281	33285
NS1000	33291	33295
NS1250	33301	33305
NS1600	33311	33315

ComPacT NS type L

Icu = 150 kA at 220/415V	3P	4P
NS630b	33272	33276
NS800	33282	33286
NS1000	33292	33296

MicroLogic control units

Without "measurement"

		3P/4P
MicroLogic 2.0	basic protection	33504
MicroLogic 5.0	selective protection	33511
MicroLogic 6.0	selective + earth-fault protection	33515

"ammeter" A

		3P/4P
MicroLogic 2.0 A	basic protection	33505
MicroLogic 5.0 A	selective protection	33512
MicroLogic 6.0 A	selective + earth-fault protection	33513
MicroLogic 7.0 A	selective + earth-leakage protection	33514


"energy" E [1]

		3P/4P
MicroLogic 2.0 E	basic protection	33535
MicroLogic 5.0 E	selective protection	33537
MicroLogic 6.0 E	selective + earth-fault protection	33539

"power meter" P [1]

		3P/4P
MicroLogic 5.0 P	selective protection	65290
MicroLogic 6.0 P	selective + earth-fault protection	65291
MicroLogic 7.0 P	selective + earth-leakage protection	65292

Basic Switch-Disconnecter




ComPacT NS type NA

	3P	4P
NS630b	33440	33441
NS800	33442	33443
NS1000	33444	33445
NS1250	33446	33447
NS1600	33448	33449

Note: the characteristics of the motor mechanism module for electrical operation are specified separately by selecting a part number from the table at the bottom of this page.

Connections for Circuit Breakers and Switch-Disconnectors



Front connection

		3P	4P
630-1000 A - NA/N/H	Top	33598	33608
	Bottom	33599	33609
1250 A - NA/N/H	Top	33600	33610
630-1000 A - L	Bottom	33601	33611
1600 A - NA/N/H	Top	33602	33612
	Bottom	33603	33613

Rear connection

		3P	4P
Vertical NA/N/H/L	Top	33604	33614
	Bottom	33605	33615
Horizontal	Top	33606	33616
NA/N/H/L	Bottom	33607	33617

Motor Mechanism Module



AC 50/60 Hz

	Standard	Communicating		Standard	Communicating
48 V	33691 [2]	33698 [2]	24/30 V	33690 [2]	33697 [2]
100/130 V	33687 [2]	33694 [2]	48/60 V	33691 [2]	33698 [2]
220/240 V	33688 [2]	33695 [2]	100/130 V	33692 [2]	33699 [2]
277 V	33686	-	-	-	-
380/415 V	33689 [2]	33696 [2]	200/250 V	33693 [2]	33700 [2]

Note: to order a complete device, order:

- a basic circuit breaker and a MicroLogic control unit, or a basic switch disconnector. ■ connections. ■ accessories (for the device, the connection, the control unit) and communication option as required.


[2] Consult us.

NS630b to NS1600 Manually Operated Withdrawable Devices Device Based on Separate Components

Basic Circuit Breaker

A ComPacT withdrawable manually operated circuit breaker is composed of 5 catalog references corresponding to:

- The basic circuit breaker
- The chassis
- A control unit
- The top connection
- The bottom connection.



ComPacT NS type N		
Icu = 50 kA at 220/415 V	3P	4P
NS630b	C063N3WM	C063N4WM
NS800	C080N3WM	C080N4WM
NS1000	C100N3WM	C100N4WM
NS1250	C125N3WM	C125N4WM
NS1600	C160N3WM	C160N4WM

ComPacT NS type H		
Icu = 70 kA at 220/415 V	3P	4P
NS630b	C063H3WM	C063H4WM
NS800	C080H3WM	C080H4WM
NS1000	C100H3WM	C100H4WM
NS1250	C125H3WM	C125H4WM
NS1600	C160H3WM	C160H4WM

ComPacT NS type L		
Icu = 150 kA at 220/415 V	3P	4P
NS630b	C063L3WM	C063L4WM
NS800	C080L3WM	C080L4WM
NS1000	C100L3WM	C100L4WM

ComPacT NS type LB		
Icu = 200 kA at 400/415 V	3P	4P
NS630b	C063B3WM	C063B4WM
NS800	C080B3WM	C080B4WM

MicroLogic control units Without "measurement"

MicroLogic 2.0	basic protection	3P/4P
MicroLogic 5.0	selective protection	C20WM
MicroLogic 6.0	selective + earth-fault protection	C50WM
"ammeter" A		C60WM


MicroLogic 2.0 A	basic protection	3P/4P
MicroLogic 5.0 A	selective protection	C2AWM
MicroLogic 6.0 A	selective + earth-fault protection	C5AWM
MicroLogic 7.0 A	selective + earth-leakage protection	C6AWM
"energy" E ^[1]		C7AWM

MicroLogic 2.0 E	basic protection	3P/4P
MicroLogic 5.0 E	selective protection	C2EWM
MicroLogic 6.0 E	selective + earth-fault protection	C5EWM
"power meter" P ^[1]		C6EWM

MicroLogic 5.0 P	selective protection	3P/4P
MicroLogic 6.0 P	selective + earth-fault protection	C5PWM
MicroLogic 7.0 P	selective + earth-leakage protection	C6PWM
		C7PWM



[1] In case of an installation 3P + Neutral, please add ENVT device ref. 65316 (see page F-13).

Basic Switch-Disconnecter



ComPacT NS type NA		
NS630b	3P	4P
NS800	C063S3WM	C063S4WM
NS1000	C080S3WM	C080S4WM
NS1250	C100S3WM	C100S4WM
NS1600	C125S3WM	C125S4WM
	C160S3WM	C160S4WM

Basic Chassis and Connections



Chassis		
630-1250 A - NA/N/H	3P	4P
1600 A - NA/N/H	33722	33725
630/800 A - LB	33723	33726
630-1000 A - L		
+ connection		
	3P	4P
Front connection		
Top NA/N/H/L/LB	33727	33733
Bottom NA/N/H/L/LB	33728	33734
Rear connection		
Vertical NA/N/H/L/LB	Top	33729
	Bottom	33730
Horizontal	Top	33731
NA/N/H/L/LB	Bottom	33732
		33735
		33736
		33737
		33738

Note: to order a complete device, order:


- a basic circuit breaker and a MicroLogic control unit, or a basic switch disconnector. ■ chassis and connections. ■ accessories (for the device, the connection, the control unit) and communication option as required.

NS630b to NS1600 Electrically Operated Withdrawable Devices Device Based on Separate Components

Basic Circuit Breaker

A ComPacT withdrawable electrically operated circuit breaker is composed of 6 catalog references corresponding to:

- The basic circuit breaker
- The chassis
- A control unit
- The top connection
- The bottom connection
- The motor mechanism module.



Note: the characteristics of the motor mechanism module for electrical operation are specified separately by selecting a part number from the table at the bottom of this page.

[1] In case of an installation 3P + Neutral, please add ENVT device ref. 65316 (see page F-13).

ComPacT NS type N

Icu = 50 kA at 220/415 V	3P	4P
NS630b	33370	33374
NS800	33380	33384
NS1000	33390	33394
NS1250	33400	33404
NS1600	33410	33414

ComPacT NS type H

Icu = 70 kA at 220/415 V	3P	4P
NS630b	33371	33375
NS800	33381	33385
NS1000	33391	33395
NS1250	33401	33405
NS1600	33411	33415

ComPacT NS type L

Icu = 150 kA at 220/415 V	3P	4P
NS630b	33372	33376
NS800	33382	33386
NS1000	33392	33396

MicroLogic control units

Without "measurement"

		3P/4P
MicroLogic 2.0	basic protection	33504
MicroLogic 5.0	selective protection	33511
MicroLogic 6.0	selective + earth-fault protection	33515

"ammeter" A

		3P/4P
MicroLogic 2.0 A	basic protection	33525
MicroLogic 5.0 A	selective protection	33532
MicroLogic 6.0 A	selective + earth-fault protection	33533
MicroLogic 7.0 A	selective + earth-leakage protection	33534


"energy" E [1]

		3P/4P
MicroLogic 2.0 E	basic protection	33536
MicroLogic 5.0 E	selective protection	33538
MicroLogic 6.0 E	selective + earth-fault protection	33540

"power meter" P [1]

		3P/4P
MicroLogic 5.0 P	selective protection	65293
MicroLogic 6.0 P	selective + earth-fault protection	65294
MicroLogic 7.0 P	selective + earth-leakage protection	65295

Basic Switch-Disconnecter





ComPacT NS type NA

	3P	4P
NS630b	33450	33451
NS800	33452	33453
NS1000	33454	33455
NS1250	33456	33457
NS1600	33458	33459

Note: the characteristics of the motor mechanism module for electrical operation are specified separately by selecting a part number from the table at the bottom of this page.

Chassis and Connections



Chassis

	3P	4P
630-1250 A - NA/N/H	33722	33725
1600 A - NA/N/H	33723	33726


+ connection

	3P	4P
Front connection		
Top NA/N/H/L	33727	33733
Bottom NA/N/H/L	33728	33734

Rear connection

Vertical NA/N/H/L	Top	33729	33735
	Bottom	33730	33736
Horizontal	Top	33731	33737
	Bottom	33732	33738

Motor Mechanism Module



AC 50/60 Hz

	Standard	Communicating	DC	Standard	Communicating
48 V	33831 [2]	33838 [2]	24/30 V	33830 [2]	33837 [2]
100/130 V	33827 [2]	33834 [2]	48/60 V	33831 [2]	33838 [2]
220/240 V	33828 [2]	33835 [2]	100/130 V	33832 [2]	33839 [2]
380/415 V	33829 [2]	33836 [2]	200/250 V	33833 [2]	33840 [2]

Note: to order a complete device, order:

- a basic circuit breaker and a MicroLogic control unit, or a basic switch disconnector.
- chassis and connections.
- accessories (for the device, the connection, the control unit) and communication option as required.









[2] Consult us.

Accessories for NS630b to NS1600 Fixed Devices

Connection Accessories


Front Connection

Rear Connection


Bare-cable connectors + 1 connector shield for 4 cables (240 mm ²) for rating ≤1250 A			
	3P (3 parts)	33640	
	4P (4 parts)	33641	
1 long connection shield			
	3P	33628	
	4P	33629	
Vertical-connection adapters			
	3P (3 parts)	33642	
	4P (4 parts)	33643	
Cable lug adapters			
	3P (3 parts)	33644	33644
	4P (4 parts)	33645	33645
Cable lug kits			
	240 mm ²	3P (6 lug kit)	33013
		4P (8 lug kit)	33014
	300 mm ²	3P (6 lug kit)	33015
		4P (8 lug kit)	33016
Interphase barriers			
	3P/4P top (3 parts)	33646	33648
	3P/4P bottom (3 parts)	33646	33648
Arc chute screen			
	3P	64907	
	4P	33597	
Brackets for mounting on a horizontal surface			
	3P/4P (2 parts)		64908
Spreaders			
	3P	33622	33622
	4P	33623	33623

Electrical Auxiliaries

Indication contacts

		Standard contact with spring terminals	Low-level contact with screw terminals
	OF, ON/OFF indication contacts	33108	33109
	SD, trip indication contact for manually operated devices	33004	33008
	SDE, fault indication contact operated devices	33011	33012
Up to 3 OF, 1 SD and 1 SDE can be connected (the SDE contact is standard for electrically operated devices).			




Indication auxiliary (wireless)

	OF or SD or SDE wireless	LV429454	












Instantaneous voltage releases

	MX	MN	Delay unit	R (non-adjustable)	Rr (adjustable)
12 V DC	33658				
24/30 V DC, 24 V AC	33659	33668			
48/60 V DC, 48 V AC	33660	33669	48/60 V AC/DC		33680
100/130 V AC/DC	33661	33670	100/130 V AC/DC	33684	33681
200/250 V AC/DC	33662	33671	200/250 V AC/DC	33685	33682
277 V AC	33663				
380/480 V AC	33664	33673	380/480 V AC/DC		33683

Installation Accessories

	Escutcheon (small cut-out) for manually operated device with toggle	33717
	Escutcheon for: device with toggle (large cutout), - device with rotary handle, - electrically operated device	33718
ref. 33717	ref. 33718	
Blanking plate		
		33858


Accessories for NS630b to NS1600 Withdrawable Devices

Connection Accessories			Front Connection	Rear Connection		
Vertical-connection adapters						
		3P (3 parts)	33642			
		4P (4 parts)	33643			
Cable lug adapters						
		3P (3 parts)	33644	33644		
		4P (4 parts)	33645	33645		
Cable lug kits						
	240 mm²	3P (6 lug kit)	33013	33013		
		4P (8 lug kit)	33014	33014		
	300 mm²	3P (6 lug kit)	33015	33015		
		4P (8 lug kit)	33016	33016		
Interphase barriers						
		3P/4P (3 parts)		33768		
Spreaders						
		3P (3 parts)	33622	33622		
		4P (4 parts)	33623	33623		
Chassis Accessories						
Auxiliary terminal shield (CB)						
		3P		33763		
		4P		33764		
Safety shutters (VO) as standard						
		3P		33765		
		4P		33766		
Electrical Auxiliaries						
OF ON/OFF indication contacts						
	OF, ON/OFF indication contacts		Standard contact	Low-level contact		
	SD, trip indication contact for manually operated devices		33801	33804		
	SDE, fault indication contact operated devices		33800	33803		
	Up to 3 OF, 1 SD and 1 SDE can be connected (the SDE contact is standard for electrically operated devices)		33799	33802		
Indication auxiliary (wireless)						
	OF or SD or SDE wireless			LV429454		
CE, CD, CT carriage switches						
	Connected position NO/NC contact (up to 3 CE)		Standard contact	Low-level contact		
	Disconnected position NO/NC (up to 2 CD)		33751	33754		
	Test position NO/NC contact (up to 1 CT)		33753	33756		
	Spare parts (up to 3 CE, 1 CT, 2 CD per device)		33752	33755		
			33170	33171		
Instantaneous voltage releases						
		MX	MN	Delay unit	R (non-adjustable)	Rr (adjustable)
	12 V DC	33809				
	24/30 V DC, 24 V AC	33810	33819			
	48/60 V DC, 48 V AC	33811	33820	48/60 V AC/DC		33680
	100/130 V AC/DC	33812	33821	100/130 V AC/DC	33684	33681
	200/250 V AC/DC	33813	33822	200/250 V AC/DC	33685	33682
	277 V AC	33814				
	380/480 V AC	33815	33824	380/480 V AC/DC		33683
Auxiliary terminals for chassis alone						
3 wire terminal (30 parts)					47071	
6 wire terminal (10 parts)					47072	
Jumpers (10 parts)					47900	

Accessories for NS630b to NS1600 Withdrawable Devices

Chassis Locking

Keylocking in disconnected position




By Profalux keylocks

Profalux	1 lock with 1 key + adaptation kit	64909
	2 locks 1 key + adaptation kit	64910
	2 locks 2 different keys + adaptation kit	64911
1 keylock Profalux (without adaptation kit):		
	identical key not identified combination	33173
	identical key identified 215470 combination	33174
	identical key identified 215471 combination	33175

By Ronis keylocks


Ronis	1 lock with 1 key + adaptation kit	64912
	2 locks 1 key + adaptation kit	64913
	2 locks 2 different keys + adaptation kit	64914
1 keylock Ronis (without adaptation kit):		
	identical key not identified combination	33189
	identical key identified EL24135 combination	33190
	identical key identified EL24153 combination	33191
	identical key identified EL24315 combination	33192
Optional disconnected/test/connected position locking		33779
Adaptation kit (without keylock):		
	adaptation kit Profalux	33769
	adaptation kit Ronis	33770
	adaptation kit Castell	33771
	adaptation kit Kirk	33772

Door interlock



Right side of chassis (VPECD)	33786
Left side of chassis (VPECG)	33787

Racking interlock (VPOC)



	33788
--	-------


Mismatch protection (VDC)



	33767
--	-------


Installation Accessories

Escutcheon



	33857
--	-------

Transparent cover for escutcheon



	33859
--	-------

Blanking plate




	33858
--	-------


Accessories for NS630b to NS1600 Fixed and Withdrawable Devices

Locking for Manually Operated Devices

Removable toggle locking system


DB 128448.eps		Locking by 3 padlocks	44936

Fixed toggle locking system


DB 128449.eps		Locking by 3 padlocks	32631

Rotary Handle for Manually Operated Devices


Devices with direct rotary handles

DB 128450.eps		Handle and front	Black handle and black front	33863	
			Red handle and yellow front	33864	
		Conversion accessory	CNOMO	33866	
		Locking by keylocks		Ronis	Profalux
			OFF position	33870	33869
			OFF and ON positions	33872	33871
		Keylock kit (without keylocks)		33868	33868


Mechanical interlocking

DB 128451.eps		For 2 devices with extended rotary handles	33890

Devices with extended rotary handles

DB 128452.eps		Handle and front	Black handle and black front	33878	
			Red handle and yellow front	33879	
			Telescopic (for chassis-mounted devices)	33880	

Control accessories


DB 128453.eps		2 advanced indication contacts (6 A - 240 V)	Fixed	Withdrawable
		Early break	33882	33884
		Early make	33883	33885

Locking and Accessories for Electrically Operated Devices


Pushbutton locking

DB 128454.eps		By transparent cover + padlocks	33897

Locking in OFF position

DB 128455.eps		By padlocks + BPFE support		
		VCPO	47514	
		By Profalux keylocks		
		Profalux	1 lock with 1 key + adaptation kit	33902
			2 locks 1 key + adaptation kit	33904
		1 keylock Profalux (without adaptation kit):		
			identical key not identified combination	33173
			identical key identified 215470 combination	33174
			identical key identified 215471 combination	33175
		By Ronis keylocks + BPFE support		
		Ronis	1 lock with 1 key + adaptation kit	33903
			2 locks 1 key + adaptation kit	33905
		1 keylock Ronis (without adaptation kit):		
			identical key not identified combination	33189
			identical key identified EL24135 combination	33190
			identical key identified EL24153 combination	33191
			identical key identified EL24315 combination	33192
		Adaptation kit (without keylock):		
			adaptation kit Profalux	33898
			adaptation kit Ronis	33899
			adaptation kit Kirk	47517
			adaptation kit Castell	47518

Operation counter CDM


DB 128456.eps		Operation counter CDM	33895

Accessories for NS630b to 1600 Fixed and Withdrawable Devices

Mechanical Interlocking


Mechanical Interlocking for Source Changeover

Interlocking using connecting rods for ComPacT electrically operated devices



Complete assembly with 2 adaptation fixtures + rods	33910
2 ComPacT fixed devices	33913
2 ComPacT withdrawable devices	

Interlocking using cables for ComPacT electrically operated devices




Complete assembly with 2 adaptation fixtures + cables	33911
2 ComPacT fixed devices	33914
2 ComPacT withdrawable devices	33915
1 ComPacT fixed + 1 ComPacT withdrawable device	

Communication Option for NS630b to NS1600 Fixed and Withdrawable Devices

Indication and Measurements Modules

PowerLogic PowerTag Rope



3P/3P+N


1000 A

A9MEM1592


2000 A

A9MEM1593


Communication Options




IFE

Ethernet interface
for LV breaker**LV434001**Ethernet interface
for LV breakers and gateway**LV434002**

IFM Modbus-SL interface module

LV434000

I/O application module

LV434063

For fixed devices

COM (BCM-ULP)

Manually operated**Electrically operated**

Eco COM module (BCM-ULP)

33702**33708****33703****33709**

For withdrawable devices

Breaker + chassis

COM (BCM-ULP)


Manually operated**Electrically operated**

Eco COM module (BCM-ULP)

33842**33848****33714****33713**

Accessories for MicroLogic Control Units

Long-time rating plug (enhanced accuracy by limiting the setting range)



Standard

0.4 to 1 x Ir

C33542

Low setting

0.4 to 0.8 x Ir

C33543

High setting

0.8 to 1 x Ir

C33544

Without long-time protection

OFF

C33545

External Neutral Voltage Tap

For MicroLogic E and P - 3P + Neutral installation

Connection kit to neutral for MicroLogic P on fixed version


65317

Connection kit to neutral for MicroLogic P on withdrawable version

65316

External sensors


External sensor for neutral + earth-fault protection (TCE)



CT rating: 400/1600 A

33576

Rectangular sensor for earth-leakage protection


**Inside dimensions (mm)****Ie (A)**

280 x 115

1600

33573

Source ground return (SGR) earth fault protection




External sensor (SGR)

33579

MDGF summing module

48891

External power supply module (AD)



24/30 V DC

LV454440

48/60 V DC

LV454441

100/125 V DC

LV454442

110/130 V AC

LV454443


200/240 V AC

LV454444

Communication Option for NS630b to NS1600 Fixed and Withdrawable Devices


Test Equipment

Mini test kit		
	Hand held test kit (HHTK)	33594



DB120463.eps

Service Interface Test Kit		
	BTM (Breaker Test Module)	LV485500
	Service interface spare part	LV485510SP
	Service interface AC/DC power	LV485511SP
	Service interface 7 pin cable ACB MCCB TU	LV485512SP
	Service interface ULP cable	LV485514SP
	Service interface USB magnet cable	LV485517SP




DB4395317.ai

NS1600b to NS3200 Fixed, Front-Connected, Manually Operated Device

Circuit Breaker

A ComPacT fixed manually operated circuit breaker is composed of 2 catalog references corresponding to:

- The switch-disconnector
- A control unit.



ComPacT NS type N

Icu = 85/70 kA to 220/415 V

	3P	4P
NS1600b	C16bN3FM	C16bN4FM
NS2000	C200N3FM	C200N4FM
NS2500	C250N3FM	C250N4FM
NS3200	C320N3FM	C320N4FM

ComPacT NS type H

Icu = 125/85 kA to 220/415 V

	3P	4P
NS1600b	C16bH3FM	C16bH4FM
NS2000	C200H3FM	C200H4FM
NS2500	C250H3FM	C250H4FM
NS3200	C320H3FM	C320H4FM

MicroLogic control units

Without "measurement"

		3P/4P
MicroLogic 2.0	basic protection	C20FM
MicroLogic 5.0	selective protection	C50FM
MicroLogic 6.0	selective + earth-fault protection	C60FM


"ammeter" A

		3P/4P
MicroLogic 2.0 A	basic protection	C2AFM
MicroLogic 5.0 A	selective protection	C5AFM
MicroLogic 6.0 A	selective + earth-fault protection	C6AFM
MicroLogic 7.0 A	selective + earth-leakage protection	C7AFM

"energy" E

		3P/4P
MicroLogic 2.0 E	basic protection	C2EFM
MicroLogic 5.0 E	selective protection	C5EFM
MicroLogic 6.0 E	selective + earth-fault protection	C6EFM


Switch-Disconnecter



ComPacT NS type NA

	3P	4P
NS1600b	C16bS3FM	C16bS4FM
NS2000	C200S3FM	C200S4FM
NS2500	C250S3FM	C250S4FM
NS3200	C320S3FM	C320S4FM

Optional Vertical Connection Adaptor




1600/2500 A	3P (3 parts)	33975
	4P (4 parts)	33976

Note: standard for 3200 A.

Electrical Auxiliaries

Indication contacts



OF, ON/OFF indication contacts
SD, trip indication contact for manually operated devices
SDE, fault indication contact operated devices
Up to 3 OF, 1 SD and 1 SDE can be connected


	Standard contact with spring terminals	Low-level contact with screw terminals
OF, ON/OFF indication contacts	33108	33109
SD, trip indication contact for manually operated devices	33004	33008
SDE, fault indication contact operated devices	33011	33012

Indication auxiliary (wireless)



OF or SD or SDE wireless | **LV429454**


Instantaneous voltage releases



	MX	MN	Delay unit	R (non-adjustable)	Rr (adjustable)
12 V DC	33658				
24/30 V DC, 24 V AC	33659	33668			
48/60 V DC, 48 V AC	33660	33669	48/60 V AC/DC		33680
100/130 V AC/DC	33661	33670	100/130 V AC/DC	33684	33681
200/250 V AC/DC	33662	33671	200/250 V AC/DC	33685	33682
277 V AC	33663				
380/480 V AC	33664	33673	380/480 V AC/DC		33683


Locking

Removable toggle locking system



Locking by 3 padlocks | **33996**

Fixed toggle locking system




Locking by 3 padlocks | **32631**

Accessories for NS1600b to NS3200

Indication and Measurements Modules

PowerLogic PowerTag Rope



3P/3P+N


1000 A

A9MEM1592

2000 A

A9MEM1593

Communication Option



IFE

Ethernet interface
for LV breaker

LV434001

Ethernet interface
for LV breakers and gateway

LV434002

IFM Modbus-SL interface module

LV434000

I/O application module

LV434063

COM (BCM-ULP)


33986

Eco COM module (BCM-ULP)

33988

Accessories for MicroLogic Control Units

Long-time rating plug (enhanced accuracy by limiting the setting range)



Standard

0.4 to 1 x Ir

C33542

Low setting

0.4 to 0.8 x Ir

C33543

High setting

0.8 to 1 x Ir

C33544


Without long-time protection

OFF

C33545

External sensors


External sensor for neutral + earth-fault protection (TCE)



CT rating: 1000/4000 A

34036


Rectangular sensor for earth-leakage protection



470 mm x 160 mm

33574

Source ground return (SGR) earth fault protection




External sensor (SGR)

33579

MDGF summing module

48891

External power supply module (AD)



24/30 V DC

LV454440

48/60 V DC

LV454441

100/125 V DC

LV454442

110/130 V AC

LV454443

200/240 V AC

LV454444

Accessories for NS1600b to NS3200

Test Equipment

Mini test kit

DB128463.eps



Hand held test kit (HHTK)

33594

Service Interface Test Kit

DB439317.ai




BTM (Breaker Test Module)

LV485500

Installation Accessories

Escutcheon


DB128444.eps



33929

Front cover

DB439314.ai



ComPacT NS1600b to NS3200 fixed front cover

C35005

Interphase barriers (3 parts)

DB128446.eps




33998

Spare Parts: NS630b to NS1600 Fixed Circuit Breaker

Electrical Auxiliaries and Installation Accessories

Electrical Auxiliaries

Indication contact/1 part



	Standard contact with spring terminals	Low-level contact with screw terminals
OF, ON/OFF indication contacts	29450	33804
SD trip indication contact for manually operated devices	29450	33803
SDE fault indication contact operated devices	29450	33802


Up to 3 OF, 1 SD and 1 SDE can be connected (the SDE contact is standard for electrically operated devices).

Indication auxiliary (wireless)



OF or SD or SDE wireless	LV429454
--------------------------	-----------------

Remote tripping/1 part




	MX	MN	Delay unit	R (non-adjustable)	Rr (adjustable)
12 V DC	33658				
24/30 V DC, 24 V AC	33659	33668			
48/60 V DC, 48 V AC	33660	33669	48/60 V AC/DC		33680
100/130 V AC/DC	33661	33670	100/130 V AC/DC	33684	33681
200/250 V AC/DC	33662	33671	200/250 V AC/DC	33685	33682
277 V AC	33663				
380/480 V AC	33664	33673	380/480 V AC/DC		33683

Installation Accessories/1 Part




Escutcheon (small cut-out) for manually operated device with toggle	33717
---	--------------




Escutcheon for: - device with toggle (large cutout) - device with rotary handle - electrically operated device	33718
---	--------------

Front cover




ComPacT NS630b to NS1600 fixed front cover	C33158
--	---------------

Blanking plate/1 part



Blanking plate	33858
----------------	--------------


Toggle extension/1 part



Toggle extension	46996
------------------	--------------



Toggle extension without LED	C46996
------------------------------	---------------




Additional toggle extension	C33195
-----------------------------	---------------

Spare Parts: NS630b to NS1600 Fixed Circuit Breaker

MicroLogic Control Unit, External Sensor


Replacement Parts for MicroLogic Control Units

Long-time rating plug (limits setting range for higher accuracy)/1 part




Standard	0.4 at 1 x Ir	C33542
Low-setting option	0.4 at 0.8 x Ir	C33543
High-setting option	0.8 at 1 x Ir	C33544
Without long-time protection	off	C33545

Battery + cover




Battery (1 part)		33593
Cover (1 part)	For MicroLogic A, E	C33592
	For MicroLogic P	C47067


Communication Option



IFE	Ethernet interface for LV breaker	LV434001
	Ethernet interface for LV breakers and gateway	LV434002




IFM Modbus-SL interface module		LV434000
--------------------------------	--	----------



I/O application module		LV434063
------------------------	--	----------


External sensors

External sensor for neutral + earth-fault protection (TCE)/1 part




CT rating: 400/1600 A		33576
-----------------------	--	-------

Rectangular sensors




Inside dimensions (mm)	Ie (A)	
280 x 115	1600	33573

Source ground return (SGR) earth-fault protection/1 part



External sensor (SGR)	33579
MDGF summing module	48891

External power supply module (AD)/1 part



24-30 V DC	LV454440
48-60 V DC	LV454441
100-125 V DC	LV454442
110-130 V AC	LV454443
200-240 V AC	LV454444

Service Interface Test Kit



BTM (Breaker Test Module)	LV485500
---------------------------	----------

Spare Parts: NS630b to NS1600 Fixed Circuit Breaker

Locking and Accessories

Locking for Manually Operated Devices

Removable toggle locking system/1 part

DB128446.eps



Locking by 3 padlocks **44936**

Fixed toggle locking system/1 part

DB128449.eps




Locking by 3 padlocks **32631**

Rotary Handle for Manually Operated Devices

Devices with direct rotary handles/1 part


DB128352.eps



Conversion accessory	CNOMO	33866	
Locking by keylocks		Ronis	Profalux
	OFF position	33870	33869
	OFF and ON positions	33872	33871
Keylock kit (without keylocks)		33868	33868

Mechanical interlocking

DB128451.eps




For 2 devices with extended rotary handles **33890**

Locking and Accessories for Electrically Operated Devices

Pushbutton locking/1 part


DB128454.eps



By transparent cover + padlocks **33897**

Locking in OFF position/1 part

DB128455.eps



By padlocks + BPFE support

VCPO **47514**

By Profalux keylocks

Profalux	1 lock with 1 key + adaptation kit	33902
	2 locks 1 key + adaptation kit	33904
1 keylock Profalux (without adaptation kit):		
	identical key not identified combination	33173
	identical key identified 215470 combination	33174
	identical key identified 215471 combination	33175

By Ronis keylocks

Ronis	1 lock with 1 key + adaptation kit	33903
	2 locks 1 key + adaptation kit	33905
1 keylock Ronis (without adaptation kit):		
	identical key not identified combination	33189
	identical key identified EL24135 combination	33190
	identical key identified EL24153 combination	33191
	identical key identified EL24315 combination	33192
Adaptation kit (without keylock):		
	adaptation kit Profalux	33898
	adaptation kit Ronis	33899
	adaptation kit Kirk	47517
	adaptation kit Castell	47518

Operation counter CDM/1 part


DB128456.eps



Operation counter CDM **33895**

Front cover

DB430314.ai



ComPacT NS630b to NS1600 fixed front cover **C33158**


F

Spare Parts: NS630b to NS1600 Fixed and Withdrawable Circuit Breaker

Mechanical Interlocking for Source Changeover


Mechanical Interlocking for Source Changeover

Interlocking using connecting rods for ComPacT electrically operated devices



Complete assembly with 2 adaptation fixtures + rods	
2 ComPacT fixed devices	33910

Interlocking using cables for ComPacT electrically operated devices






Complete assembly with 2 adaptation fixtures + cables	33911
2 ComPacT fixed devices	
1 ComPacT fixed + 1 ComPacT withdrawable device	33915

Spare Parts: NS630b to NS1600






Withdrawable Circuit Breaker

Connection



Connection

 DB128416.eps	Front connection/Replacement kit (6 or 8 parts)		3P	4P
	Top and bottom		33588	33589
 DB128417.eps	 DB40144.eps	Rear connection/Replacement kit (4 or 6 parts)		
		Vertical and horizontal		33586 33587
Vert. mounting. Horiz. mounting.				

Connection Accessories

Vertical connection adapters for front-connected chassis/Replacement kit (3 or 4 parts)				
	3P			33642
	4P			33643
Cable lug adapters for front-connected chassis/Replacement kit (3 or 4 parts)				
	3P			33644
	4P			33645
Interphase barriers for rear-connected chassis/Replacement kit (3 parts)				
	3P/4P			33768
Spreaders for front-connected and rear-connected chassis/Replacement kit (3 or 4 parts)				
	3P			33622
	4P			33623
Cable lug kits/Replacement kit (6 or 8 parts)				
	240 mm ²	3P (6 lug kit)		33013
		4P (8 lug kit)		33014
	300 mm ²	3P (6 lug kit)		33015
		4P (8 lug kit)		33016

Chassis Accessories

Auxiliary terminal shield (CB)/1 part				
DB128434.eps		3P		33763
		4P		33764
Safety shutters (VO)/1 part				
DB401445.eps		3P		33765
		4P		33766

Clusters

1 disconnecting contact cluster for chassis (see table below) (1 part)

64906

Table: number of clusters required for the different chassis models

Chassis rating (A)	ComPacT NS - 3P		ComPacT NS - 4P	
	NA - N	L	NA - N	L
630	12	18	16	24
800	12	18	16	24
1000	12	18	16	24
1250	12		16	
1600	18		24	

Note: the minimum order is 6 parts.

Set of 2 clusters fitters for 2 and 3 clusters

47554


Spare Parts: NS630b to NS1600

Withdrawable Circuit Breaker

Electrical Auxiliaries

Electrical Auxiliaries

SD trip indication contact for manually operated devices/1 part



	Standard contact with spring terminals	Low-level contact with screw terminals
OF, ON/OFF indication contacts	33801	33804
SD trip indication contact for manually operated devices	33800	33803
SDE fault indication contact operated devices	33799	33802

Up to 3 OF, 1 SD and 1 SDE can be connected (the SDE contact is standard for electrically operated devices).

Indication auxiliary (wireless)




OF or SD or SDE wireless	LV429454
--------------------------	-----------------

CE, CD, CT carriage switches/1 part





	Standard contact	Low-level contact
Connected position NO/NC contact (up to 3 CE)	33751	33754
Disconnected position NO/NC (up to 2 CD)	33753	33756
Test position NO/NC contact (up to 1 CT)	33752	33755
Spare parts (up to 3 CE, 1 CT, 2 CD per device)	33170	33171

Instantaneous voltage releases/1 part



	MX	MN	Delay unit	R (non-adjustable)	Rr (adjustable)
12 V DC	33658				
24/30 V DC, 24 V AC	33659	33668			
48/60 V DC, 48 V AC	33660	33669	48/60 V AC/DC		33680
100/130 V AC/DC	33661	33670	100/130 V AC/DC	33684	33681
200/250 V AC/DC	33662	33671	200/250 V AC/DC	33685	33682
277 V AC	33663				
380/480 V AC	33664	33673	380/480 V AC/DC		33683

Auxiliaries terminal for chassis



3 wire terminal block (1 part)	33098
6 wire terminal block (1 part)	33099
Jumpers (10 parts)	47900

3 wires.


6 wires.

Spare Parts: NS630b to NS1600

Withdrawable Circuit Breaker

Installation Accessories

Installation Accessories

 DB128430.eps	Escutcheon/1 part	33857
 DB128445.eps	Transparent cover for escutcheon/1 part	33859
 DB128432.eps	Blanking plate/1 part	33858
 DB439315.ai	Front cover	
	Front cover ComPacT NS630b to NS1600	C33152

Catalog Numbers


Spare Parts: NS630b to NS1600

Withdrawable Circuit Breaker


MicroLogic Control Unit, External Sensor

Replacement Parts for MicroLogic Control Units




Long-time rating plug (limits setting range for higher accuracy)/1 part

	Standard	0.4 at 1 x I _r	C33542
	Low-setting option	0.4 at 0.8 x I _r	C33543
	High-setting option	0.8 at 1 x I _r	C33544
	Without long-time protection	off	C33545

Battery + cover

	Battery (1 part)		33593
	Cover (1 part)	For MicroLogic A, E	C33592
		For MicroLogic P	C47067

Communication Option


	IFE	Ethernet interface for LV breaker	LV434001
		Ethernet interface for LV breakers and gateway	LV434002
	IFM Modbus-SL interface module		LV434000
	I/O application module		LV434063

External sensors

External sensor for neutral + earth-fault protection (TCE)/1 part

	CT rating: 400/1600 A		33576
---	-----------------------	--	-------


Source ground return (SGR) earth-fault protection + Vigi cable/1 part

	External sensor (SGR)		33579
	MDGF summing module		48891

Rectangular sensors

	Inside dimensions (mm)	I _e (A)	
	280 x 115	1600	33573

External power supply module (AD)/1 part

	24-30 V DC		LV454440
	48-60 V DC		LV454441
	100-125 V DC		LV454442
	110-130 V AC		LV454443
	200-240 V AC		LV454444

Service Interface Test Kit

	BTM (Breaker Test Module)		LV485500
---	---------------------------	--	----------


Spare Parts: NS630b to NS1600

Withdrawable Circuit Breaker

Locking and Accessories

Locking for Manually Operated Devices

Removable toggle locking system/1 part


DB 128448 eps		Locking by 3 padlocks	44936

Fixed toggle locking system/1 part

DB 128449 eps		Locking by 3 padlocks	32631

Rotary Handle for Manually Operated Devices

Devices with direct rotary handles/1 part

DB 128352 eps		Conversion accessory	CNOMO	33866	
		Locking by keylocks		Ronis	33869
			OFF position	33870	33871
			OFF and ON positions	33872	33868
		Keylock kit (without keylocks)		33868	

Mechanical interlocking


DB 128451 eps		For 2 devices with extended rotary handles	33890

Locking and Accessories for Electrically Operated Devices

Pushbutton locking/1 part

DB 128454 eps		By transparent cover + padlocks	33897

Locking in OFF position/1 part

DB 128455 eps		By padlocks + BPFE support			
		VCPO			47514
		By Profalux keylocks			
		Profalux	1 lock with 1 key + adaptation kit	33902	
			2 locks 1 key + adaptation kit	33904	
		1 keylock Profalux (without adaptation kit):			
			identical key not identified combination	33173	
			identical key identified 215470 combination	33174	
			identical key identified 215471 combination	33175	
		By Ronis keylocks			
		Ronis	1 lock with 1 key + adaptation kit	33903	
			2 locks 1 key + adaptation kit	33905	
		1 keylock Ronis (without adaptation kit):			
			identical key not identified combination	33189	
			identical key identified EL24135 combination	33190	
			identical key identified EL24153 combination	33191	
			identical key identified EL24315 combination	33192	
		Adaptation kit (without keylock):			
			adaptation kit Profalux	33898	
			adaptation kit Ronis	33899	
			adaptation kit Kirk	47517	
			adaptation kit Castell	47518	

Front cover

DB439316 al		ComPacT NS1600b to 3200 fixed front cover	C35005


Operation counter CDM/1 part

DB 128456 eps		Operation counter CDM/1 part	33895

Spare Parts: NS630b to NS1600 Withdrawable Circuit Breaker Chassis Locking and Accessories Mechanical Interlocking for Source Changeover

Chassis Locking

Keylocking in disconnected position/1 part




By Profalux keylocks

Profalux	1 lock with 1 key + adaptation kit	64909
	2 locks 1 key + adaptation kit	64910
	2 locks 2 different keys + adaptation kit	64911
1 keylock Profalux (without adaptation kit):	identical key not identified combination	33173
	identical key identified 215470 combination	33174
	identical key identified 215471 combination	33175

By Ronis keylocks


Ronis	1 lock with 1 key + adaptation kit	64912
	2 locks 1 key + adaptation kit	64913
	2 locks 2 different keys + adaptation kit	64914
1 keylock Ronis (without adaptation kit):	identical key not identified combination	33189
	identical key identified EL24135 combination	33190
	identical key identified EL24153 combination	33191
	identical key identified EL24315 combination	33192
Adaptation kit (without keylock):	adaptation kit Profalux	33769
	adaptation kit Ronis	33770
	adaptation kit Castell	33771
	adaptation kit Kirk	33772

Door interlock/1 part



Right and left side of chassis (VPECD or VPECG)	33172
---	-------

Racking interlock (VPOC)/1 part



33788


Mismatch protection (VDC)/1 part



33767


Mechanical Interlocking for Source Changeover

Interlocking using connecting rods for ComPacT electrically operated devices



Complete assembly with 2 adaptation fixtures + rods	33913
2 ComPacT withdrawable devices	




Interlocking using cables for ComPacT electrically operated devices



Complete assembly with 2 adaptation fixtures + cables	33914
2 ComPacT fixed devices	33915
1 ComPacT fixed + 1 ComPacT withdrawable device	


Spare Parts: Communication Bus Accessories, Monitoring and Control, Ethernet Gateway

Communication Options

	IFE	Ethernet interface for LV breaker	LV434001
		Ethernet interface for LV breakers and gateway	LV434002
	IFM Modbus-SL interface module		LV434000
	I/O application module		LV434063

Monitoring and Control






ULP display module ^[1]

	Switchboard front display module FDM121	TRV00121
	FDM mounting accessory (diameter 22 mm)	TRV00128

Ethernet display module

	Switchboard front display module FDM128	LV434128
--	---	-----------------

ULP wiring accessories

	Breaker ULP cord L = 0.35 m	LV434195
	Breaker ULP cord L = 1.3 m	LV434196
	Breaker ULP cord L = 3 m	LV434197
	Breaker ULP cord L = 5 m	LV434198
	10 Modbus line terminators	VW3A8306DRC ^[2]
	Connector Modbus adaptor	LV434211
	5 RJ45 connectors female/female	TRV00870
	10 ULP line terminators	TRV00880
	10 RJ45/RJ45 male cord L = 0.3 m	TRV00803
	10 RJ45/RJ45 male cord L = 0.6 m	TRV00806
	5 RJ45/RJ45 male cord L = 1 m	TRV00810
	5 RJ45/RJ45 male cord L = 2 m	TRV00820
	5 RJ45/RJ45 male cord L = 3 m	TRV00830
	1 RJ45/RJ45 male cord L = 5 m	TRV00850


^[1] For measurement display with MicroLogic A, E, P.

^[2] www.se.com.

Spare Parts: ComPacT NS1600b to 3200


Connection, Locking and Installation Accessories

Optional Vertical Connection Adaptor /Replacement Kit (3 or 4 Parts)

DB12623 eps 	1600/2500/3200 A	3P	33975
		4P	33976

Electrical Auxiliaries

Indication contacts (1 part)

DB435416 all 	OF, SD, SDE	Standard contact with spring terminals	33108
		Low-level contact with screw terminals	33109


Note: up to 3 OF, 1 SD and 1 SDE can be connected.

Instantaneous voltage releases (1 part)


	MX	MN	Delay unit	R (non-adjustable)	Rr (adjustable)
12 V DC	33658				
24/30 V DC, 24 V AC	33659	33668			
48/60 V DC, 48 V AC	33660	33669	48/60 V AC/DC		33680
100/130 V AC/DC	33661	33670	100/130 V AC/DC	33684	33681
200/250 V AC/DC	33662	33671	200/250 V AC/DC	33685	33682
277 V AC	33663				
380/480 V AC	33664	33673	380/480 V AC/DC		33683

Locking

Removable toggle locking system/1 part

DB12648 eps 	Locking by 3 padlocks	33996
---	-----------------------	--------------

Fixed toggle locking system/1 part


DB12649 eps 	Locking by 3 padlocks	32631
--	-----------------------	--------------

Installation Accessories


Escutcheon/1 part

DB12644 eps 	33929
--	--------------

Interphase barriers/3 parts

DB12646 eps 	33998
--	--------------

Toggle extension/1 part

DB12638 eps 	NS3200 toggle extension for replacement	33997
--	---	--------------

Front cover

DB435316 all 	ComPacT NS1600b to NS3200 fixed front cover	C35005
---	---	---------------

Spare Parts: ComPacT NS1600b to 3200

MicroLogic Control Unit, External Sensor

Accessories for MicroLogic Control Units

Long-time rating plug (enhanced accuracy by limiting the setting range)/1 part

DB128459.eps




Standard	0.4 to 1 x Ir	C33542
Low setting	0.4 to 0.8 x Ir	C33543
High setting	0.8 to 1 x Ir	C33544
Without long-time protection	OFF	C33545

External sensors

External sensor for neutral + earth-fault protection (TCE)/1 part


DB128459.eps



CT rating: 1000/4000 A	34036
------------------------	-------

Source ground return (SGR) earth-fault protection + Vigi cable/1 part


DB128460.eps



External sensor (SGR)	33579
MDGF summing module	48891

Rectangular sensors


DB126100.eps



Inside dimensions (mm)	Ie (A)	
470 x 160	3200	33574

External power supply module (AD)/1 part

DB432608.eps



24-30 V DC	LV454440
48-60 V DC	LV454441
100-125 V DC	LV454442
110-130 V AC	LV454443
200-240 V AC	LV454444

Service Interface Test Kit

DB493117.ai



BTM	LV485500
-----	----------

F

Order form: ComPacT NS630b to NS3200

Circuit breakers and switch-disconnectors

Name of customer:

Address for delivery:

Requested delivery date:

Customer order no.:

To indicate your choices, check the applicable square boxes ☐and enter the appropriate information in the rectangles

Circuit breaker or switch-disconnector

ComPacT type	NS630b to NS1600 NS1600b to NS3200	
Rating	A	
Circuit breaker	N, H, L, LB	
Switch-disconnector	NA	
Number of poles	3 or 4	
Device	NS630b/3200 Fixed	
	NS630b/1600 Withdr. with chassis	
	Withdr. without chassis	
	(moving part only)	

Chassis alone without connections ☐

MicroLogic control unit

Basic protection	2.0	5.0	6.0	
------------------	-----	-----	-----	--

A - ammeter	2.0	5.0	6.0	7.0
-------------	-----	-----	-----	-----

E - energy	2.0	5.0	6.0	
------------	-----	-----	-----	--

P - power	2.0	5.0	6.0	7.0
-----------	-----	-----	-----	-----

only for NS630b/1600

5.0	6.0	7.0
-----	-----	-----

AD - external power-supply module ☐

ENVT - External Neutral Voltage Tap

(3P + N and MicroLogic E or P)

TCE - external sensor (CT) for neutral protection

Rectangular sensor NS630b/1600 280 x 115 mm

for earth-leakage protection NS1600b/3200 470 x 160 mm

TCW - external sensor for SGR protection

LR - long-time rating plug

Standard 0.4 to 1 Ir

Low setting 0.4 to 0.8 Ir

High setting 0.8 to 1 Ir

LT OFF

Communication

COM module

Device ☐ with Ethernet interface ☐ Cradle

(BCM-ULP) management with

with Ethernet interface + ☐ I/O application

Gateway module (Chassis)

with Modbus interface ☐

Eco COM module

Device ☐ with Ethernet interface ☐

(BCM-ULP) with Ethernet interface +

Gateway

with Modbus interface ☐Front Display Module ☐ Mounting accessories ☐

(FDM121)

Breaker ULP

Cord

L = 0.35 m

L = 1.3 m

L = 3 m

L = 5 m

NS630b/1600 connection

Horizontal rear connections Top Bottom

Vertical rear connections Top Bottom

Front connections Top Bottom

4 x 240² bare cable connectors + shields NS - FC fixed

Long connection shields NS - FC fixed

Vertical-connection adapters NS - FC fixed,

withdr.

Cable-lug adapters NS - FC fixed,

withdr.

Arc chute screen NS - FC fixed

Interphase barriers NS - FC fixed, withdrawable

Spreaders NS - FC fixed, withdrawable

NS1600b/3200 connection

Front connections NS - FC fixed

Vertical connection adaptor optional for NS1600b/2500

(standard for NS3200)

Indication contacts

NS630b/3200 SD trip indication (maximum 1) (only for manually operated devices)

☐ Wireless indication auxiliary 5 A-240 V AC qty 6 A-240 V AC qty☐ Low-level contact with SDE fault-trip indication (maximum 1)

(SDE integrated in electrically operated devices)

☐ Standard contact with 5 A-240 V AC qty 6 A-240 V AC qty

spring terminals OF ON/OFF indication contacts (maximum 3)

5 A-240 V AC qty 6 A-240 V AC qty

NS630b/1600 Carriage switches

(possible combinations: 3 CE, 2 CD, 1 CT)

CE - "connected" position 6 A-240 V AC qty Low level qty

CD - "disconnected" position 6 A-240 V AC qty Low level qty

CT - "test" position 6 A-240 V AC qty Low level qty

I/O application module

Auxiliary terminals for chassis alone Jumpers (set of 10)

3-wire terminal (30 parts) 6-wire terminal (10 parts)

Remote operation

Electrical operation Standard Communicating

(NS630b/1600) Power supply AC DC V

Voltage releases MX AC DC V

MN AC DC V

MN delay unit Adjustable Non adjustable

Rotary handles for NS630b/1600 fixed and withdrawable device

Direct Black Red on yellow front

CNOMO conversion access.

Extended Black Red on yellow front

Telescopic handle for withdrawable device

Indication auxiliary 6 A-240 V AC 2 early-make switches

2 early-break switches

Locking

Toggle (1 to 3 padlocks) Removable system Fixed system

Rotary handle OFF position ON and OFF positions

using a keylock Ronis 1351B.500 Profalux KS5 B24 D4Z

(NS630b/1600) Keylock kit (without keylock)

For electrically VBP - ON/OFF pushbutton locking

operated devices (by transparent cover + padlocks)

(NS630b/1600) OFF position locking:

VCPO - by padlocks

VSPO - by keylocks:

Keylock kit (w/o keylock) Profalux Ronis

1 keylock Profalux Ronis

2 identical keylocks, 1 key Profalux Ronis

Chassis locking in "disconnected" position:

VSPD - by keylocks Keylock kit (w/o keylock) Profalux Ronis

1 keylock Kirk Castell

2 identical keylocks, 1 key Profalux Ronis

2 keylocks, different keys Profalux Ronis

Optional connected/disconnected/test position locking

VPEC - door interlock On right-hand side of

chassis

VPOC - racking interlock On left-hand side of chassis

VDC - mismatch protection

Accessories

VO - safety shutters on chassis NS - withdrawable as standard

CDM - mechanical operation counter

CDP - escutcheon

CP - transparent cover for escutcheon

OP - blanking plate for escutcheon

Mounting brackets for fixed NS for mounting on horizontal plane

Mini test kit

MicroLogic control unit functions:

2.0: basic protection (long time + inst.)

5.0: selective protection (long time + short time + inst.)

6.0: selective + earth-fault protection

(long time + short time + inst. + earth-fault)

7.0: selective + earth-leakage protection

(long time + short time + inst. + earth-leakage)



Schneider Electric Industries SAS

35, rue Joseph Monier
CS 30323
92506 Rueil Malmaison Cedex
France

RCS Nanterre 954 503 439
Capital social 928 298 512 €
www.se.com

09-2022

© 2022 - Schneider Electric. All Rights Reserved.
All trademarks are owned by Schneider Electric Industries SAS or its affiliated companies.
Document reference: LVPED221008EN