



Shrouding kit (400/630A and 800A panelboards only)

Provides additional support for device and shrouding for front cover. One shrouding kit must be used per side when fitting either outgoing 400/630A MCCBs or outgoing ammeter and/or earth leakage protection. In addition to the shrouding kit an additional 25mm three stage filler piece is required when 4 pole 400A or 630A circuit breakers are fitted on the outgoing pan assembly **MGPTSF25**.

Number of outgoing ways		Part number
SP	TB	
18	6	MGPCH6
36	12	MGPCH12
54	18	MGPCH18

Extension enclosure

250A powerboard style A side extension

TP ways	Mounting arrangement	Part number
Side	Top/bottom	
3	W600	MG25EXC
4	W600	MG25EXC

250A panelboard style C top or bottom extension

5,7,9,13	H200	MG6CEX
----------	------	---------------

More than one extension can be added if required.

400/630A panelboard style D and 800A panelboard style E top or bottom extension

Top/bottom ext.	6,12,18	H200	MG6CEX
-----------------	---------	------	---------------

Side extensions

Side ext. 6	W250	MGPXC206
Side ext. 12	W250	MGPXC212
Side ext. 18	W250	MGPXC218
Side ext. 6	W500	MGPXC506
Side ext. 12	W500	MGPXC512
Side ext. 18	W500	MGPXC518

For side extensions with metering facility see page 8/20.

More than one extension can be added if required. Side extensions are recommended when 400A and 630A outgoers are fitted or when outgoing circuit breakers have earth fault protection.

Corner units style D/E

W250	H200	MGPC2025
W500	H200	MGPC2050
W250	H400	MGPC4025
W500	H400	MGPC4050

For squaring off a panelboard when a top or bottom extension and side extension are used together, and side extension are used together.

1600A panelboard style G side extension

14	W400	MG16CEX4
----	------	-----------------

More than one extension can be added if required.

Metering MG16CEM4