

EM4PBGMBP



### Accessories - Group Mounted approach

Description	used for	Eaton list number
Blanking plate		<b>EM4PBGMBP</b>
Finger guards are mandatory to each outgoing device cable termination for compliance with Form 4 Type 6	NZM1 SPN	<b>NZM1-1-XIPK</b>
	NZM1 TPN (non-switched neutral)	<b>NZM1-XIPK</b>
	NZM1 4P (switched neutral)	<b>NZM1-4-XIPK</b>
Finger guards are mandatory to each outgoing device cable termination for compliance with Form 4 Type 6	NZM2 TPN (non-switched neutral)	<b>NZM2-XIPK</b>
	NZM2 4P (switched neutral)	<b>NZM2-4-XIPK</b>

NZM1-4-XIPK



Form 4 Type 6 group mounted



### Possible outgoing arrangement of NZM1/NZM2 depending on form of separation

- Note a mixture of NZM1 and NZM2 breakers can be fitted (not part of the table) - see Selection tool for permutations

Board reference / description	Type of feeder	Max. number of NZM1 (only) breakers can be fitted		Max. number of NZM2 (only) breakers can be fitted	
		Compartmentalised	Group Mounted	Compartmentalised	Group Mounted
EM4PB840 / 8-way board	NZM1 - 1P and N	12	16	–	–
	NZM1 - 3P and N / 4P	6	8	–	–
	NZM2 - 3P and N / 4P	–	–	6	6
EM4PB1440 / 14-way board	NZM1 - 1P and N	20	28	–	–
	NZM1 - 3P and N / 4P	12	14	–	–
	NZM2 - 3P and N / 4P	–	–	10	12
EM4PB1840 / 18-way board	NZM1 - 1P and N	26	36	–	–
	NZM1 - 3P and N / 4P	14	18	–	–
	NZM2 - 3P and N / 4P	–	–	12	14

Form 4 Type 6 compartmentalised



### Compartmentalised kits to upgrade the standard Form 4 Type 6 group mounted design to higher form of separation

- Minimum ordering requirement for compartmentalisation: Overall fitting + incomer + outgoer kit per device or unused way (select neutral link when 3-pole devices are used as outgoer)

Type of Compartmentalised kit	used for	Form of separation	Eaton list number
Overall fitting kit	MCCB Panelboard EM4PB... 400/800A	Form 4 Type 2 / Type 6	<b>EM4PBCK</b>
Incomer kit	NZM3 MCCB / N3 switch disconnecter	Form 4 Type 2 / Type 6	<b>EM4PB40CKINC</b>
Outgoer kit	NZM1 SPN	Form 4 Type 2	<b>EM4PBCKN122</b>
	NZM1 TPN / 4-pole		<b>EM4PBCKN142</b>
	NZM2 TPN / 4-pole		<b>EM4PBCKN242</b>
Outgoer kit	NZM1 SPN	Form 4 Type 6	<b>EM4PBCKN126</b>
	NZM1 TPN / 4-pole		<b>EM4PBCKN146</b>
	NZM2 TPN / 4-pole		<b>EM4PBCKN246</b>
Neutral link	NZM1 Neutral	Form 4 Type 6	<b>EM4PBCKN1N</b>
	NZM2 Neutral		<b>EM4PBCKN2N</b>
Unused way	–	Form 4 Type 2 / Type 6	<b>EM4PBCKUW</b>

EM4PBCK



EM4PBCKN242



EM4PBCKN246



EM4PBCKN24BK



### Accessories - Compartmentalised approach

Description	Eaton list number
Blanking plate NZM1 SPN	<b>EM4PBCKN12BK</b>
Blanking plate NZM1 TPN / 4-pole	<b>EM4PBCKN14BK</b>
Blanking plate NZM2 TPN / 4-pole	<b>EM4PBCKN24BK</b>