

MR medium rating busbar technical information

Suspension brackets



Wall fixing bracket






Measuring bespoke dimensions

Straight lengths

Always measure from the long side of the casing as illustrated



Elbows

Measure from the long casing to the axis of the elbow

