


# AF400 ... AF2650 3 pole contactors

## Main accessories

Main accessories (other accessories available)



### Main accessory fitting details

Contactor types	Main poles	Available auxiliary contacts	Side-mounted accessories		
			Auxiliary contact blocks	Mechanical interlock units (between two contactors)	
			CAL18-11	CAL18-11B <sup>(3)</sup>	

### Contactors + auxiliary contact blocks

AF400 ... AF2650	3	0	1	1	1 x CAL18-11	+	2 x CAL18-11B	–
------------------	---	---	---	---	--------------	---	---------------	---

### Contactors with mechanical interlocking + auxiliary contact blocks

AF400 ... AF2650	3	0	1	1	2 x CAL18-11 <sup>(1)</sup>	+	4 x CAL18-11B <sup>(1)</sup>	+	VM...H <sup>(2)</sup>
------------------	---	---	---	---	-----------------------------	---	------------------------------	---	-----------------------

<sup>(1)</sup> Total number of auxiliary contact blocks for the two contactors.

<sup>(2)</sup> Interlock type, according to the contactor ratings (see "Accessories").

<sup>(3)</sup> The CAL18-.. auxiliary contact blocks can replace the CAL18-11 and CAL18-11B. Though, no auxiliary contact block can be mounted outside the CEL18-..

### Overload relays fitting details

Contactor types	Thermal overload relays	Electronic overload relays
	AF400, AF460	–
AF580, AF750	–	EF750 (250...800 A) <sup>(4)</sup>
AF1350, AF1650	–	E1250DU (375...1250 A) <sup>(4)</sup>

The addition of a thermal or electronic overload relay on the contactor does not prevent fitting of many other accessories as shown in "Main accessory fitting details" table.

<sup>(4)</sup> Mounting kit required (see "Motor protection").