



Gland plates




Trunking spreader



Nb. of rows	H1	H2
2	396	546
3	546	696
4	696	846
5	846	996
6	996	1146

Wall-mounted



Useful depth behind front plate

