



56SSW10, 56SSW10I



56SSW15



56SSW210, 56SSW215

IP56 10A & 15A SWITCHES WITH SLIDING SWITCH DOLLIES

(Designed to IEC60669-1, IEC60529)

56SSW10

10A 250V single sliding switch

56SSW10I

10A 250V intermediate sliding switch

56SSW15

15A 250V single sliding switch

56SSW210

10A 250V DP double sliding switch

56SSW215

15A 250V DP double sliding switch



56PB



56PBS



56PBS1



56PBS2

IP66 10A PUSH BUTTON CONTROL STATIONS

(Designed to IEC60669-1, IEC60529)

56PB

10A 250V start control station with green push button

56PBS

10A 250V stop control station with red push button

56PBS1

10A 250V emergency stop station with mushroom head twist reset & red push button

56PBS2

10A 250V stop station with mushroom head twist reset & red push button labelled stop only



562PB



562PBS1

IP66 10A PUSH BUTTON CONTROL STATIONS

(Designed to IEC60669-1, IEC60529)

562PB

10A 250V stopstart control station with a red extended head push button & green flush head start button

562PBS1

10A 250V stopstart control station with a red mushroom head push button & green flush head start button



M56PBS1

M56 10A PUSH BUTTON

(Designed to IEC60669-1, IEC60529)

M56PBS1

10A 240V emergency stop station with mushroom head twist reset & red push button